

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [hansgrohe](#) /

› hansgrohe Raindance Select S Handheld Shower Head Set Instruction Manual

hansgrohe 04905820

hansgrohe Raindance Select S Handheld Shower Head Set

INSTRUCTION MANUAL

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup & Installation](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#) [Support](#)

1. Introduction

Thank you for choosing the hansgrohe Raindance Select S Adjustable 5-inch Handheld Shower Head Set. This product is designed to enhance your showering experience with its versatile spray modes and durable construction. This manual provides essential information for the safe installation, operation, and maintenance of your new shower head set.





Figure 1: The hansgrohe Raindance Select S Handheld Shower Head Set, showcasing its sleek design in brushed nickel.

2. Safety Information

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in property damage, personal injury, or product malfunction.

- Ensure all water supply lines are turned off before beginning installation.
- Use appropriate tools and follow local plumbing codes.
- Do not overtighten connections, as this may damage the product.
- Keep small parts away from children to prevent choking hazards.
- This product is intended for domestic use only.

- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. Package Contents

Verify that all components are present before proceeding with installation:

- Raindance S 120 1.75 GPM Handshower with PowderRain
- Techniflex Shower Hose (63-inch)
- Handshower Showerarm Mount

4. Setup & Installation

The hansgrohe Raindance Select S Handheld Shower Head Set is designed for easy installation. However, hansgrohe recommends that a licensed plumber install this product to ensure proper function and adherence to all local codes.

General Installation Steps:

1. Turn off the main water supply to your shower.
2. Remove your existing shower head and clean the shower arm threads.
3. Apply plumber's tape to the shower arm threads.
4. Attach the Handshower Showerarm Mount to the shower arm and tighten securely.
5. Connect one end of the Techniflex Shower Hose to the Handshower Showerarm Mount.
6. Connect the other end of the Techniflex Shower Hose to the Raindance S 120 Handshower.
7. Place the handshower into the mount.
8. Turn on the water supply and check for leaks.



Figure 2: The complete hansgrohe shower set installed, showing the handshower in its mount and the flexible hose.

Your browser does not support the video tag.

Video 1: Official hansgrohe Raindance Select S Product Video. This video demonstrates the product's features and functionality, including spray modes and QuickClean technology.

5. Operating Instructions

Your hansgrohe Raindance Select S Handshower offers three distinct spray modes for a personalized showering experience. The spray type can be easily changed using the "Select" button located on the handshower handle.

- **PowderRain:** A gentle, enveloping spray for a soft and soothing experience.
- **Full Jet (Rain):** A powerful, invigorating spray for thorough rinsing.
- **Massage (Whirl):** A concentrated, pulsating spray for a relaxing massage.



PowderRain

**3 spray
modes**



Rain



Whirl

Figure 3: Visual representation of the three available spray modes: PowderRain, Rain, and Whirl.



Figure 4: A close-up view of the shower head delivering the fine, gentle PowderRain spray.

The handshower can be easily removed from its mount for targeted rinsing or for bathing children and pets. Simply lift the handshower from the holder and return it when finished.

6. Maintenance

To ensure the longevity and optimal performance of your hansgrohe shower head, regular cleaning is recommended.

- **QuickClean Technology:** The silicone nozzles on the shower head are designed for easy limescale removal. Simply rub your finger over the nozzles to dislodge any mineral buildup.
- Clean the exterior surfaces with a soft cloth and mild soap. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
- Rinse thoroughly after cleaning and wipe dry to prevent water spots.



Figure 5: A hand cleaning the silicone nozzles of the shower head, illustrating the QuickClean feature for easy limescale removal.

7. Troubleshooting

If you encounter issues with your shower head, refer to the following common solutions:

Problem	Possible Cause	Solution
Low Water Pressure	Clogged nozzles, water restrictor, or low household water pressure.	Clean nozzles using QuickClean. Check for and remove any water restrictors if permitted by local codes. Consult a plumber for household water pressure issues.
Leaking Connections	Loose connections or worn washers.	Ensure all connections are hand-tightened, then use a wrench for a quarter turn. Replace any damaged washers.
Difficulty Changing Spray Modes	Mineral buildup around the selector button.	Clean the area around the "Select" button to remove any limescale or debris.

8. Specifications

Brand: hansgrohe

Model Number: 04905820

Style: Modern Handshower Set

Color: Brushed Nickel

Material: Engineered wood (Note: This seems incorrect based on product type, likely a data error. Assuming metal for shower components.)

Flow Rate: 1.75 Gallons Per Minute (GPM)

Number of Settings: 3 (PowderRain, Full Jet, Massage)

Special Features: AirPower technology, QuickClean technology

Item Dimensions (L x W): 10.25"L x 6.5"W

Included Components: 63-inch Shower Hose, Handshower, Handshower Mount

9. Warranty Information

Hansgrohe, Inc. warrants to the original consumer purchaser that hansgrohe products will be free from defects in material and workmanship for as long as the original consumer purchaser owns both the product and the home in which the product was originally installed. For commercial purchasers, the warranty period is one (1) year for hansgrohe products from the date of purchase. The warranty period for products in Rubbed Bronze, Matte Black, and Matte White finishes is three (3) years from the date of purchase. This warranty is non-transferable. Because Hansgrohe, Inc. is unable to control the quality of hansgrohe products sold by unauthorized sellers, unless otherwise prohibited by law, this warranty does not cover hansgrohe products purchased from unauthorized sellers. Authorized sellers can be found on hansgrohe branded websites. Additional warranty restrictions apply. See manufacturer website for full warranty details.

10. Customer Support

For further assistance, technical support, or to inquire about replacement parts, please visit the official hansgrohe website or contact their customer service department. Refer to your product packaging or the hansgrohe website for the most current contact information.