

XIAOMI 26200

Xiaomi Mijia Robot 2-in-1 Sweeping and Wet Mopping Robot Vacuum Cleaner Instruction Manual

MODEL: 26200

Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your Xiaomi Mijia Robot 2-in-1 Sweeping and Wet Mopping Robot Vacuum Cleaner. Please read this manual thoroughly before using the product and retain it for future reference.

Important Safety Information

To reduce the risk of injury or damage, read and follow all safety precautions. This appliance is for household use only.

- Do not allow children to play with the appliance.
- Ensure the charging dock is placed on a level surface against a wall.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the robot in areas with open flames or explosive materials.
- Do not use the robot to pick up large debris, liquids, or burning objects.
- Always remove the water tank and dustbin before moving or cleaning the robot.
- Use only the original power adapter and charging dock provided by the manufacturer.

Package Contents

Verify that all items are present in the package:

- 1 x Xiaomi Mijia Sweeping Mopping Robot
- 1 x 2-in-1 Water Tank
- 2 x Side Brush
- 1 x Charging Stand

- 1 x Power Adapter
- 1 x Mop Bracket
- 2 x Wiper (Mopping Pad)

Product Overview

Familiarize yourself with the main components of your robot vacuum cleaner.



Image Description: Top view of the Xiaomi Mijia Robot Vacuum Cleaner, showing the main body, the LDS laser navigation system dome, and the power/home buttons.



Image Description: Top view of the Xiaomi Mijia Robot Vacuum Cleaner with its top lid open, revealing the dustbin compartment and internal mechanisms, including an orange component.



Image Description: Bottom view of the Xiaomi Mijia Robot Vacuum Cleaner, displaying the main roller brush (orange), side brushes, charging contacts, and various sensors.



Image Description: Side profile of the Xiaomi Mijia Robot Vacuum Cleaner, highlighting one of the side brushes and a main wheel.

Setup

1. Charging Dock Placement

Place the charging dock against a wall on a hard, level surface. Ensure there are no obstacles within 0.5 meters (1.6 feet) to either side and 1.5 meters (4.9 feet) in front of the dock. Connect the power adapter to the charging dock and plug it into a power outlet.



Image Description: The Xiaomi Mijia Robot Vacuum Cleaner positioned next to its compact white charging dock, ready for charging.

2. Initial Charging

Place the robot onto the charging dock. The robot will automatically align itself and begin charging. For first-time use, ensure the robot is fully charged before operation. A full charge typically takes several hours.

3. App Installation and Connection

Download the "Mi Home" app from your smartphone's app store. Follow the in-app instructions to add your Xiaomi Mijia Robot Vacuum Cleaner. This process involves connecting the robot to your home's 2.4 GHz Wi-Fi network. The app allows for remote control, scheduling, and map management.

Operating Instructions

1. Cleaning Modes

The robot supports three cleaning modes:

- **Sweeping and Mopping:** The robot simultaneously vacuums and mops the floor. Ensure the 2-in-1 water tank with a mop pad is installed.
- **Sweeping:** The robot only vacuums. Use the dustbin for this mode.
- **Mopping:** The robot only mops. Ensure the 2-in-1 water tank with a mop pad is installed and the HEPA filter is removed from the water tank if only mopping is desired.

2. Starting a Cleaning Cycle

Press the power button on the robot or use the Mi Home app to start a cleaning cycle. The robot will automatically map its environment using its LDS laser navigation system and begin cleaning.



Image Description: The Xiaomi Mijia Robot Vacuum Cleaner actively cleaning a modern room with light-colored flooring, demonstrating its compact size and ability to navigate open spaces.

3. Pausing and Stopping

Press the power button once to pause cleaning. Press it again to resume. To stop cleaning and send the robot back to its charging dock, press and hold the power button, or use the app.

4. Scheduled Cleaning

Use the Mi Home app to set up cleaning schedules. You can specify times and days for the robot to automatically start cleaning.

5. Zone Cleaning and Virtual Walls

Through the Mi Home app, you can define specific areas for cleaning (zone cleaning) or set up virtual walls and forbidden sweep areas to restrict the robot's access to certain zones.

6. Voice Control

The robot supports voice interaction via the Mi Home app and is compatible with Amazon Echo (Alexa). Follow the instructions in the Mi Home app to link your robot with your voice assistant for hands-free control.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your robot vacuum cleaner.

1. Dustbin and Water Tank Cleaning

Empty the dustbin after each cleaning cycle. Remove the 2-in-1 water tank, empty any remaining water, and clean the mop pad. The mop pad can be washed and reused.

2. Main Brush and Side Brush Cleaning

Periodically remove the main brush and side brushes to clear any tangled hair or debris. Use the cleaning tool provided (if any) or scissors to cut tangled hair.

3. Sensor Cleaning

Wipe the cliff sensors, wall sensors, and charging contacts with a soft, dry cloth to ensure they remain free of dust and debris. Clean the LDS laser navigation system dome as well.

4. Filter Replacement

The HEPA filter in the dustbin should be cleaned regularly and replaced every 3-6 months, depending on usage. Refer to the Mi Home app for filter status and replacement reminders.

Troubleshooting

If you encounter issues with your robot, refer to the following common solutions:

Problem	Possible Cause	Solution
Robot does not start or respond.	Low battery; power button not pressed correctly.	Ensure robot is fully charged. Press and hold the power button for a few seconds.
Robot cannot connect to Wi-Fi.	Incorrect Wi-Fi password; 5GHz network used; robot too far from router.	Ensure correct 2.4GHz Wi-Fi network and password. Move robot closer to router. Reset Wi-Fi on robot if necessary.
Poor cleaning performance.	Full dustbin; clogged brushes; dirty filter.	Empty dustbin. Clean main brush and side brushes. Clean or replace filter.
Robot gets stuck frequently.	Obstacles on the floor; high thresholds; dark surfaces (cliff sensors).	Clear floor of cables and small objects. Use virtual walls for problematic areas. Ensure sufficient lighting for dark floors.
Mopping function not working.	Water tank empty; mop pad not installed; water outlet clogged.	Fill water tank. Attach mop pad correctly. Clean water tank outlets.

Specifications

Feature	Detail
Brand	XIAOMI
Model Name	26200
Special Feature	High Precision Sensors, LDS Laser Navigation
Color	White






Included Components	Sweeping Mopping Robot, 2-in-1 Water Tank, Side Brushes, Charging Stand, Power Adapter, Mop Bracket, Wipers
Filter Type	Cloth (HEPA)
Battery Life	Up to 130 minutes (Sweeping), 60 minutes (Mopping)
Voltage	240 Volts (Input)
Dustbin Capacity	0.3 Liters
Power Source	Battery Powered
Control Method	App (Mi Home)
Compatible Devices	Amazon Echo (Alexa)
Form Factor	Robotic
Product Dimensions	13.58 x 13.58 x 3.78 inches (34.5 x 34.5 x 9.6 cm)
Item Weight	4.4 pounds (2 kg)
Battery Type	Lithium-ion (3200mAh capacity)
Climb Capability	2cm

Warranty and Support

For warranty information and technical support, please refer to the official XIAOMI website or contact their customer service. Keep your purchase receipt as proof of purchase.

Related Documents - 26200

<div>Руководство по эксплуатации робота-пылесоса Xiaomi Mijia Sweeping Robot G1</div>	<div>Xiaomi Mijia Sweeping Robot G1 User Manual and Specifications This document provides a comprehensive user manual for the Xiaomi Mijia Sweeping Robot G1 (Model MJSTG1). It includes detailed instructions on installation, operation, maintenance, troubleshooting common errors, and technical specifications for the robot vacuum, charging dock, and power adapter. Ensure safe and efficient use of your Xiaomi robot vacuum by following the guidelines provided.</div>
---	---

 <p>Руководство по эксплуатации Робота-пылесоса Xiaomi Mijia Sweeping Robot 1S для сведения к использованию и безопасности</p>	<p>Xiaomi Mijia Sweeping Robot 1S Instruction Manual - Setup, Operation, and Maintenance</p> <p>Comprehensive user manual for the Xiaomi Mijia Sweeping Robot 1S, covering setup, cleaning modes, maintenance, troubleshooting, and safety precautions.</p>
 <p>Руководство по эксплуатации робота-пылесоса Xiaomi Mijia G1 Sweeping Vacuum Cleaner</p>	<p>Xiaomi Mijia G1 Sweeping Vacuum Cleaner User Manual</p> <p>Comprehensive user manual for the Xiaomi Mijia G1 Sweeping Vacuum Cleaner, covering setup, operation, maintenance, troubleshooting, and safety precautions.</p>
 <p>Руководство по эксплуатации Робота-пылесоса Xiaomi Mijia Sweeping Robot 1S</p>	<p>Xiaomi Mijia Sweeping Robot 1S User Manual</p> <p>Comprehensive user manual for the Xiaomi Mijia Sweeping Robot 1S (SDJQR03RR), covering setup, operation, maintenance, troubleshooting, and technical specifications.</p>
 <p>Руководство по эксплуатации Робота-пылесоса Xiaomi Mijia Sweeping Robot 1C для сведения к использованию и безопасности</p>	<p>Xiaomi Mijia Sweeping Robot 1C Connection Guide</p> <p>User manual for connecting the Xiaomi Mijia Sweeping Robot 1C to the Mi Home app. Includes step-by-step instructions, setup, features, and troubleshooting tips.</p>
 <p>Руководство по эксплуатации Робота-пылесоса Xiaomi Robot Vacuum 5 Pro для сведения к использованию и безопасности</p>	<p>Xiaomi Robot Vacuum 5 Pro User Manual - Intelligent Cleaning Guide</p> <p>Comprehensive user manual for the Xiaomi Robot Vacuum 5 Pro, detailing setup, operation, features, maintenance, and troubleshooting for this smart home cleaning device.</p>