Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Bouncepad /
- Bouncepad Eddy Tablet Stand User Manual for 7-13 Inch Tablets, Model BP-EDY-COU

Bouncepad BP-EDY-COU

Bouncepad Eddy Tablet Stand User Manual

Model: BP-EDY-COU

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Bouncepad Eddy Tablet Stand. Designed for versatility and security, the Eddy stand is compatible with most 7-13 inch tablets, offering a robust and flexible solution for various applications, including Point of Sale (POS) systems and interactive displays.

Please read this manual thoroughly before using the product to ensure proper setup and to maximize its functionality and lifespan.

2. PRODUCT OVERVIEW AND FEATURES

The Bouncepad Eddy Tablet Stand is engineered from premium die-cast aluminum metal, combining durability with a modern aesthetic. Key features include:

- Universal Compatibility: Accommodates a wide range of 7-13 inch consumer tablets, including various iPad and Android models.
- Sleek and Secure Design: Constructed from robust aluminum, offering anti-theft security features. It is compatible with Kensington MicroSaver locks for enhanced security. The stand can be used freestanding or optionally mounted to a desk or countertop for added stability.
- Flexible and Functional: Features a rotating base and an adjustable screen angle of over 90 degrees, allowing for dynamic customer interactions and easy screen sharing.
- Optimized Workspace: Integrated cable management system keeps charging cables neatly organized and out of sight, maintaining a tidy counter area.



Image 1: The Bouncepad Eddy Tablet Stand in white, holding a tablet at an angle. This image showcases the stand's design and how a tablet is secured.

Universal Compatibility





Compatible with most 7" to 13" tablets including all iPads from Mini to Pro 12.9"

Image 2: Three Bouncepad Eddy stands in different colors (white, teal, black) demonstrating compatibility with 8-9", 9-11", and 12-13" tablets. This illustrates the stand's universal fit for various tablet sizes.

3. SETUP INSTRUCTIONS

3.1 Unboxing and Initial Inspection

- 1. Carefully remove all components from the packaging.
- 2. Inspect the stand for any signs of damage. If any damage is found, contact customer support immediately.
- 3. Ensure all parts are present: Eddy stand, tablet grips, and any included mounting hardware (if applicable).

3.2 Attaching Your Tablet


- 1. Adjust the tablet grips on the stand to match the width of your tablet. The grips are designed to securely hold tablets between 7 and 13 inches.
- 2. Gently place your tablet into the grips, ensuring it is centered and held firmly.

3.3 Optional Mounting (for enhanced stability)


The Eddy stand can be securely mounted to a desk, table, or countertop using screws (not always included, check packaging). This provides additional stability and theft deterrence.

- 1. Choose a suitable location on your surface for mounting.
- 2. Mark the screw holes on the surface using the stand's base as a template.
- 3. Drill pilot holes if necessary, according to the screw size and surface material.
- 4. Secure the stand to the surface using appropriate screws.

bouncepad® Sleek and Secure Design










Image 3: A Bouncepad Eddy stand in blue, illustrating its sleek design and highlighting features like adjustable jaws for locking, a freestanding base, and the option to mount the stand. This image demonstrates the stand's security and installation flexibility.

3.4 Cable Management

To maintain a tidy workspace, route your tablet's charging cable through the integrated cable management system located within the stand's base and arm. This keeps cables organized and prevents clutter.




Image 4: A Bouncepad Eddy stand in black on a desk, with a tablet displaying a "Welcome" screen. The image highlights the "Fuss-free cable management" feature, showing how cables are discreetly routed.

4. OPERATING INSTRUCTIONS

4.1 Adjusting Screen Angle

The Eddy stand allows for over 90 degrees of screen angle adjustment. Gently tilt the tablet holder to achieve your desired viewing angle. The mechanism is designed to hold the tablet securely at various inclinations.

4.2 Rotating the Base

The stand features a rotating base, enabling easy screen sharing and interaction. Simply rotate the entire stand on its base to face different directions or users.



Image 5: A Bouncepad Eddy stand in white, demonstrating its flexible and functional aspects. It shows the tablet holder tilting and the base rotating, highlighting over 90 degrees of screen angle adjustment and a rotating base for easy screen sharing.

4.3 Using with a Kensington Lock

For enhanced security, the Eddy stand is compatible with Kensington MicroSaver locks. Locate the security slot on the stand and insert a compatible Kensington lock (sold separately) to deter theft.




Image 6: A person writing on a notepad next to a Bouncepad Eddy stand in teal, holding a tablet. The image prominently features a lock icon and text indicating compatibility with Kensington Lock, emphasizing the stand's security features.

5. MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Inspection:** Periodically check all connections and mounting screws (if applicable) to ensure they are secure.
- Tablet Grips: Ensure the tablet grips are free from debris and continue to hold the tablet firmly.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Tablet does not fit securely.	Grips are not adjusted correctly or tablet size is outside 7-13 inch range.	Adjust the tablet grips to match your tablet's dimensions. Verify your tablet is within the supported 7-13 inch size range.
Stand feels unstable.	Not placed on a flat surface, or optional mounting not utilized.	Ensure the stand is on a flat, stable surface. Consider using the optional screw-down mounting for maximum stability.
Cables are messy.	Cable management system not utilized.	Route all cables through the integrated cable management channels in the stand's arm and base.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	7.87 x 6.69 x 11.42 inches
Item Weight	0.04 ounces
Model Number	BP-EDY-COU
Brand	Bouncepad
Color	White
Form Factor	Stativ (Stand)
Compatible Devices	Apple iPad, Apple iPad Mini, Apple iPad Pro, Samsung Galaxy Tab A, Samsung Galaxy Tab S (most 7-13 inch tablets)

8. WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your Bouncepad Eddy Tablet Stand, please contact Bouncepad customer service directly. Refer to the official Bouncepad website or your purchase documentation for contact details.

Bouncepad is committed to providing high-quality products and support to its customers.

Related Documents - BP-EDY-COU

