

Braun 50-B1200s

Braun Series 5 50-B1200s Electric Shaver User Manual

Model: 50-B1200s | Brand: Braun

INTRODUCTION

This manual provides instructions for the safe and effective use of your Braun Series 5 50-B1200s electric shaver. Please read all instructions carefully before using the appliance and retain them for future reference.

IMPORTANT SAFETY INFORMATION

WARNING:

- Risk of cuts if misused. Handle with care.
- May cause skin irritation for sensitive skin types.
- Clean the shaver regularly to prevent bacterial growth.
- Do not use the shaver near water or while charging. This appliance is designed for cordless operation in wet environments.
- Replace blades regularly for optimal performance and hygiene.

This appliance is suitable for cleaning under running tap water. Do not immerse the appliance in water for extended periods.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1x Braun Series 5 Electric Shaver (Model 50-B1200s)
- 1x Precision Trimmer Attachment
- 1x Protective Cap
- 1x Smart Plug (Power adapter for 100-240V automatic adjustment)
- 1x Cleaning Brush

SETUP AND CHARGING

Initial Charge

1. Before first use, fully charge the shaver.
2. Connect the smart plug to the shaver and then to an electrical outlet.
3. The charging indicator will show the charging status. A full charge takes approximately 1 hour and provides up to 50 minutes of shaving time.
4. A 5-minute quick charge provides enough power for one shave.

Attaching Accessories (EasyClick System)

The shaver features an EasyClick system for attaching various accessories, such as the included precision trimmer.

1. Ensure the shaver is turned off.
2. Remove the shaver head by pressing the release buttons on the sides.
3. Align the desired EasyClick attachment (e.g., precision trimmer) with the shaver body and press it on until it clicks into place.




Image: The EasyClick system allows for quick attachment of accessories like the precision trimmer. Simply remove the shaver head and click the attachment into place.

OPERATING INSTRUCTIONS

Shaving

The Braun Series 5 shaver is equipped with 3 flexible blades designed to adapt to your facial contours for a close shave.



Image: Close-up of the Braun Series 5 shaver head, highlighting its 3 flexible blades that adapt to facial contours.

- **Dry Shaving:** For a quick and convenient shave, ensure your face is dry before use.
- **Wet Shaving:** This shaver is 100% waterproof and suitable for use with foam, gel, or in the shower. Apply shaving foam or gel to your face before shaving.
- Press the power button to turn on the shaver.
- Hold the shaver at a right angle (90°) to your skin and shave against the direction of hair growth.
- Stretch your skin with your free hand to ensure a smooth surface.

Using the Precision Trimmer

Attach the precision trimmer accessory using the EasyClick system as described in the Setup section.

- Turn on the shaver.
- Use the trimmer to shape sideburns, moustaches, or trim longer beard hair before shaving.
- Move the trimmer slowly and with controlled movements.

CLEANING AND MAINTENANCE

EasyClean System

The EasyClean system allows for quick and easy cleaning without removing the shaver head.

1. Ensure the shaver is turned off.
2. Hold the shaver head under warm running tap water.
3. Press the EasyClean button (if available, or simply rinse thoroughly) to allow water to flow through the shaver head.
4. Rinse until all hair residue is removed.
5. Shake off excess water and allow the shaver to air dry.

Deep Cleaning

1. Turn off the shaver.

2. Remove the shaver head by pressing the release buttons.
3. Tap out any loose hair from the shaver head and the shaver body.
4. Use the provided cleaning brush to remove stubborn hair from the shaver head and the inner parts of the shaver body. Do not use the brush on the foil part of the shaver head as this may damage it.
5. Rinse both the shaver head and the shaver body under warm running water.
6. Allow all parts to dry completely before reattaching the shaver head.

Replacing Shaver Parts

For optimal shaving performance, it is recommended to replace the shaver head (foil and cutter block) every 18 months, or when worn.

- Replacement parts can be purchased from authorized Braun retailers.
- To replace, remove the old shaver head and click the new one into place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes, or fully charge for 1 hour.
Poor shaving performance.	Shaver head is dirty or worn.	Clean the shaver head thoroughly. If performance does not improve, replace the shaver head.
Skin irritation after shaving.	Sensitive skin, improper shaving technique, or dirty shaver head.	Ensure proper shaving technique (shave against hair growth, stretch skin). Clean shaver head. Consider using a pre-shave lotion or aftershave balm. If irritation persists, consult a dermatologist.
Shaver makes unusual noise.	Hair trapped in the shaver head or damaged parts.	Perform a deep clean. If noise persists or parts appear damaged, contact customer service.

SPECIFICATIONS

- **Model:** Braun Series 5 50-B1200s
- **Power Source:** Rechargeable Li-Ion Battery
- **Battery Life:** Up to 50 minutes (approx. 3 weeks of shaving)
- **Quick Charge:** 5 minutes for one shave
- **Charging Time:** 1 hour for full charge
- **Waterproof:** 100% Wet & Dry use
- **Blades:** 3 flexible blades
- **Special Features:** EasyClean system, EasyClick system for attachments
- **Input Voltage:** 100-240V (automatic adjustment)
- **Dimensions (L x W x H):** 13.7 x 6.7 x 25.2 cm (5.39 x 2.64 x 9.92 inches)
- **Weight:** 305 grams (10.76 ounces)
- **Blade Material:** Stainless Steel
- **Country of Origin:** Germany

WARRANTY AND SUPPORT

For warranty information, please refer to the separate warranty booklet included with your product or visit the official Braun website. For technical support, replacement parts, or service inquiries, please contact Braun customer service in your region. Keep your purchase receipt as proof of purchase.

Online Support: www.braun.com/global/consumer-service/contact.html

