

Manuals.plus /
› TOZO /
› TOZO T12 Wireless Earbuds User Manual

TOZO T12

TOZO T12 Wireless Earbuds User Manual

Model: T12

INTRODUCTION

The TOZO T12 Wireless Earbuds offer a premium audio experience with advanced Bluetooth 5.3 technology, intuitive touch controls, and a convenient LED digital display. Designed for comfort and durability, these earbuds provide clear sound and powerful bass, making them ideal for various activities from daily commutes to intense workouts.



Figure 1: TOZO T12 Wireless Earbuds in their charging case.

WHAT'S IN THE BOX

Your TOZO T12 package includes the following items:

- TOZO T12 Wireless Earbuds
- Wireless Charging Case
- Eartips (multiple sizes)
- USB-C (A to C) cable (20cm)
- User Manual

SETUP

Initial Pairing

The TOZO T12 earbuds feature advanced Bluetooth 5.3 technology for fast and stable transmission. Follow these steps for initial pairing:

1. Pick up both earbuds from the charging case. They will automatically power on and pair with each other.
2. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.

3. Search for available devices and select "TOZO-T12" to connect.
4. Once connected, the earbuds will provide stereo sound.

One Step Pairing

Pick up 2 Earbuds from Charging Box
Connect Bluetooth <TOZO-T12>



Figure 2: Visual guide for one-step Bluetooth pairing.

Charging the Earbuds and Case

The TOZO T12 offers convenient charging options to ensure you're always ready to listen.

- **Earbuds:** Place the earbuds back into the charging case. They will begin charging automatically. The smart LED digital screen on the case displays the battery consumption.
- **Charging Case:** The rechargeable case can be fully charged in under two hours using a wireless charger or in approximately 1.5 hours with the provided USB-C cable.

ORIGX Acoustic

TOZO research HI-FI digital, material and cavity acoustic technology that compensates for the frequency lost when the sound passes through the ear canal curve, keeping the sound that reaches the eardrum is closest to reality.



Figure 3: Wireless charging capability of the TOZO T12 case.

Portable Battery Case

Carrying Battery Case / Charging Box, Support 4 times fully charging for headsets



Figure 4: Battery capacity of earbuds (50mAh) and charging case (500mAh).

OPERATING INSTRUCTIONS

Touch Controls

The TOZO T12 headphones feature intuitive touch control sensors, minimizing pressure on your ears while providing easy access to various functions:

- **Play/Pause:** Single tap (X1) on either earbud.
- **Previous Song:** Double tap (X2) on the left earbud.
- **Next Song:** Double tap (X2) on the right earbud.
- **Volume Down:** Hold the left earbud.
- **Volume Up:** Hold the right earbud.
- **Answer/Hang Up Call:** Single tap (X1) on either earbud.
- **Activate Voice Assistant (Siri/Google Assistant):** Triple tap (X3) on either earbud.



 X2 Previous Song	 X2 Next Song	 X1 Play/Pause	 X3 Activate Siri
 X1 Answer / Hang up	 X3 Voice Recognition	 Hold Volume Down	 Hold Volume Up

Figure 5: Detailed touch control functions for left and right earbuds.

Sound Quality

The TOZO T12 delivers truly natural, authentic sound and powerful bass performance. Equipped with large 10mm speaker drivers, these earbuds provide a rich audio experience, ensuring clarity and depth in your music and calls.

IP-X8 Waterproof rating

Resistant to sweat, water and rain



Figure 6: Internal structure highlighting the 10mm large size speaker driver.

MAINTENANCE

IPX8 Waterproof Rating


Both the charging case and earbuds feature an IPX8 waterproof rating, thanks to a nano-coating inside. This makes them resistant to sweat, water, and rain, allowing for use during sports and workouts. You can even clean the earbuds and base with water.

Compatible with Wireless Charging

Immerse yourself in the music world all day long and the charging case extends playtime up to 34 hours.



8 hrs
On a single
Charge



34 hrs
With Charging
Case



< 2 hrs
Fast Charging



TOZO W1 Ultrathin Wireless Charger

Figure 7: TOZO T12's IPX8 waterproof capability.

TROUBLESHOOTING

If you encounter any issues with your TOZO T12 earbuds, please consider the following general troubleshooting steps:

- **No Sound:** Ensure earbuds are charged and properly paired. Check device volume.
- **Pairing Issues:** Place earbuds back in the case, then remove them to re-initiate pairing mode. Forget the device on your phone's Bluetooth settings and try pairing again.
- **One Earbud Not Working:** Ensure both earbuds are charged. Try resetting the earbuds (refer to the full user guide for specific reset instructions if needed).
- **Charging Problems:** Ensure the charging cable is securely connected or the wireless charger is properly aligned. Clean charging contacts on earbuds and case.

For more detailed troubleshooting or specific error codes, please refer to the official user guide PDF or contact TOZO customer support.

SPECIFICATIONS

Feature	Detail
Model Name	TOZO T12
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	15 Meters
Audio Driver Size	10 Millimeters
Noise Control	Sound Isolation
Water Resistance Level	IPX8 Waterproof
Earbuds Battery Life (single charge)	More than 11 hours
Total Playtime with Charging Case	Up to 48 hours
Charging Case Battery Capacity	500 Milliamp Hours
Charging Time (Case)	1.5 Hours (USB-C) / <2 Hours (Wireless)
Control Method	Touch
Item Weight	64.8 Grams (total)
Product Dimensions	1 x 0.8 x 1 inches (earbud)

WARRANTY & SUPPORT

TOZO is committed to customer satisfaction and provides warranty and friendly service for its products. For detailed warranty information and support, please refer to the official user guide or visit the TOZO website. You can access the official User Guide (PDF) [here](#).

© 2024 TOZO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B085DL3KMR>

More documents and user manuals: <https://manuals.plus/>