

Manuals.plus /

› **Mighty Fleet** /

› Mighty Fleet Motorized Garbage Truck Toy Model 57117 Instruction Manual

## Mighty Fleet 57117

# Mighty Fleet Motorized Garbage Truck Toy Instruction Manual

Model: 57117

## INTRODUCTION

Thank you for choosing the Mighty Fleet Motorized Garbage Truck Toy. This manual provides essential information for the safe and proper operation, setup, and maintenance of your new toy. Please read all instructions carefully before use to ensure a fun and safe experience.



Image: The Mighty Fleet Motorized Garbage Truck, green and white, with its accompanying blue garbage bin.

## WHAT'S IN THE BOX

---

- 1 x Mighty Fleet Motorized Garbage Truck
- 1 x Detachable Garbage Bin
- 3 x AA Batteries (pre-installed)

## SAFETY INFORMATION

---

**WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.**

- Adult supervision is recommended during play.
- Keep batteries away from small children. If swallowed, seek immediate medical attention.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are only to be charged under adult supervision.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Remove batteries if the toy will not be used for an extended period.



Image: Rear view of the garbage truck, displaying a "CAUTION" warning label, indicating areas requiring attention during play.

## SETUP

---

### Battery Installation/Replacement

The Mighty Fleet Motorized Garbage Truck comes with 3 AA batteries pre-installed. If replacement is needed:

1. Locate the battery compartment on the underside of the truck.
2. Using a Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Remove the old batteries and dispose of them properly.
4. Insert 3 new AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
5. Replace the battery compartment cover and secure it with the screw.

## OPERATING INSTRUCTIONS

---

The Mighty Fleet Motorized Garbage Truck features realistic lights, sounds, and a motorized front arm for interactive play.



Image: A child engaging with the garbage truck, demonstrating its interactive features.

### **Activating Lights and Sounds**

- Press the buttons located on the side of the truck's cab to activate realistic engine sounds, horn, and flashing lights.

### **Motorized Front Arm Operation**

1. Place the detachable garbage bin in front of the truck's motorized arm.
2. Use the levers on the side of the truck to control the front power arm.
3. Maneuver the arm to grab the garbage bin.
4. Lift the bin and dump its contents into the truck's main compartment.

### **Dumping Mechanism**

- To empty the truck's contents, open the back door.
- Lift the back end of the truck to simulate dumping the payload.

## MAINTENANCE

---

- Clean the toy with a soft, damp cloth. Do not immerse the toy in water.
- Avoid exposing the toy to extreme temperatures or direct sunlight for prolonged periods.
- Regularly check for any loose parts or damage. Discontinue use if damage is found.

## TROUBLESHOOTING

---

### Toy Not Functioning (No Lights/Sounds/Motorized Arm Movement)

- **Check Batteries:** Ensure batteries are correctly installed with proper polarity. Replace with fresh AA batteries if necessary.
- **Battery Compartment:** Verify the battery compartment cover is securely fastened.
- **Obstructions:** Check the motorized arm mechanism for any obstructions that might prevent movement.

## SPECIFICATIONS

---

Feature	Detail
Product Dimensions	16 x 6.5 x 8.5 inches (40.6 x 16.5 x 21.6 cm)
Item Weight	2.89 pounds (1.31 kg)
Model Number	57117
Recommended Age	36 months - 6 years
Batteries Required	3 AA batteries (included)
Manufacturer	FUNRISE
Release Date	April 21, 2020



Image: A visual representation of the garbage truck with its key dimensions labeled in inches and centimeters.

## WARRANTY AND SUPPORT

Mighty Fleet products are designed for durability and enjoyment. For any questions, concerns, or support regarding your Motorized Garbage Truck Toy, please contact the manufacturer, FUNRISE, directly through their official customer service channels. Please retain your proof of purchase for warranty claims. For more information, visit the [Mighty Fleet Store](#).