



Manuals.plus /

› Burg-Wächter /

› Burg Wächter Combi-Line CL 460 E Safety Cabinet Furniture Safe User Manual

Burg-Wächter 41250

Burg Wächter Combi-Line CL 460 E Safety Cabinet Furniture Safe User Manual

Model: 41250

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Burg Wächter Combi-Line CL 460 E Safety Cabinet Furniture Safe. Please read this manual carefully before using the safe to ensure proper functionality and security.

SAFETY INFORMATION

- Always secure the safe according to the installation instructions to prevent unauthorized removal.
- Keep your PIN code confidential and do not write it down near the safe.
- Ensure the safe is placed on a stable, level surface capable of supporting its weight (111 kg).
- Do not store flammable liquids or explosive materials inside the safe.
- Regularly check the battery status to ensure continuous operation of the electronic lock.

PACKAGE CONTENTS

Upon unpacking, please verify that all the following items are included:

- 1 x Burg Wächter Combi-Line CL 460 E Safety Cabinet
- 4 x AA Mignon LR 06 Batteries
- 1 x Adjustable Shelf
- Mounting Material (for floor mounting)
- Instruction Manual (this document)

SETUP AND INSTALLATION

Proper installation is crucial for the security of your safe. The Combi-Line CL 460 E is designed for floor mounting.

1. Unpacking and Placement

Carefully remove the safe from its packaging. Due to its weight (111 kg), it is recommended to have assistance during transport and placement. Choose a suitable location that is level and can support the safe's weight.



Figure 1: External dimensions of the Combi-Line CL 460 E safe. The safe measures approximately 820 mm (H) x 495 mm (W) x 445 mm (D).

2. Battery Installation

The electronic lock requires 4 AA batteries. Locate the battery compartment, typically on the inside of the safe door or near the lock mechanism. Insert the batteries, ensuring correct polarity. The lock will typically emit a beep or display a readiness indicator once batteries are correctly installed.

3. Securing the Safe (Floor Mounting)

Use the provided mounting material to secure the safe to the floor. This significantly enhances resistance against unauthorized removal. Follow the specific instructions in the detailed manual for drilling and anchoring procedures. Ensure the mounting surface is appropriate for secure fastening.

OPERATING INSTRUCTIONS

Your Combi-Line CL 460 E safe features an electronic combination lock for secure access.

1. Initial Setup and Code Programming

Upon first use, you will need to set your personal 6-digit PIN code. Refer to the detailed instructions provided with the safe for the exact steps to program your code. This typically involves pressing a programming button, entering a default code (if any), and then entering your new desired 6-digit PIN code twice for confirmation.



Figure 2: Detail of the electronic combination lock with numeric keypad and display.

2. Opening the Safe

To open the safe, enter your 6-digit PIN code on the electronic keypad. The lock will typically indicate successful code entry (e.g., a green light or beep). Once the code is accepted, turn the handle (if present) or pull the door open within a few seconds.

3. Closing and Locking the Safe

To close the safe, simply push the door shut firmly. The safe will automatically lock, or you may need to turn the handle to the locked position. Always ensure the door is fully closed and the lock has engaged before leaving the safe unattended.

4. Internal Organization

The safe includes one adjustable shelf, allowing you to customize the internal space for your valuables, documents, or file folders. The interior volume is 78 litres, providing ample storage. The design accommodates standard file folders, as shown in Figure 3.



Figure 3: The Combi-Line CL 460 E safe with its door open, demonstrating its capacity for storing file folders and other valuables.



Figure 4: Interior view of the safe with the adjustable shelf installed, providing flexible storage options.

MAINTENANCE

1. Battery Replacement

When the batteries are low, the electronic lock will typically provide a warning (e.g., a specific light indicator or sound). Replace all 4 AA batteries promptly to ensure continued operation. Use high-quality alkaline batteries for best performance. Refer to the battery installation section for guidance.

2. Cleaning

Clean the exterior of the safe with a soft, damp cloth. Avoid using abrasive cleaners or solvents, as these can damage the finish. Do not spray cleaning solutions directly onto the electronic lock or internal components.

TROUBLESHOOTING

- **Safe does not open after entering code:**

- Ensure batteries are not depleted. Replace them if necessary.
- Verify that the correct 6-digit PIN code is being entered.
- If the lock mechanism or electronics appear faulty, contact Burg Wächter customer support.

- **Lock makes unusual sounds:**

- This could indicate low batteries or a mechanical issue. Replace batteries first.
- If the issue persists, contact customer support.

- **Door does not close properly:**

- Check for any obstructions preventing the door from fully closing.
- Ensure the safe is on a level surface.

For complex issues or if the safe exhibits mechanical or electronic malfunctions, it is recommended to contact Burg Wächter customer support or a qualified technician. Do not attempt to force the safe open or repair complex internal

mechanisms yourself, as this may void warranties or cause further damage.

SPECIFICATIONS

Feature	Detail
Model Number	41250
Brand	Burg-Wächter
External Dimensions (H x W x D)	820 x 495 x 445 mm
Internal Dimensions (H x W x D)	694 x 380 x 297 mm
Weight	111 kg
Volume	78 litres
Material	Alloy Steel
Colour	Black
Lock Type	Electronic Combination Lock (6-digit PIN)
Fire Protection	LFS 30 P (30 minutes for paper, DIN 4102)
Burglary Protection	ECB S-certified (Class A), Safety Level S2 (DIN EN 14450)
Batteries Required	4 x AA (included)
Mounting Type	Floor Mount

WARRANTY AND SUPPORT

Burg Wächter has been a trusted manufacturer since 1920, known for high-quality security products. For detailed warranty information and customer support, please refer to the official documentation included with your safe or visit the Burg Wächter website.

Regarding insurance coverage, the safe complies with safety levels S2 (DIN EN 14450) and is ECB S-certified (Class A). As a guide, this typically allows for insurance coverage of up to €2,500 (commercial) or €20,000 (private). However, it is essential to discuss these values directly with your insurance provider to confirm your specific coverage.