L LAVAREDO L6606Man-Blue

User Manual for L LAVAREDO Men's Digital Sport Watch

Model: L6606Man-Blue

1. Introduction

Thank you for choosing the L LAVAREDO Men's Digital Sport Watch. This manual provides detailed instructions on how to set up, operate, and maintain your watch to ensure optimal performance and longevity. Please read this manual thoroughly before using your watch.

2. Product Overview

The L LAVAREDO Digital Sport Watch is designed for active individuals, featuring a robust build and multiple functions. It is equipped with a digital display, LED backlight, alarm, calendar, day, date, and stopwatch functions. The watch supports both 12-hour and 24-hour time formats.



Figure 2.1: Front view of the L LAVAREDO Digital Sport Watch (01-blue model).

Key Features:

- **Multifunctional Digital Display:** Shows time, date, day, and other functions clearly.
- **LED Backlight:** Provides clear visibility in low-light conditions.
- **Alarm Function:** Set daily alarms.
- **Chronograph (Stopwatch):** For timing activities.
- **Water Resistance:** 5ATM rated for daily use (splashes, rain, hand washing).
- **Durable Construction:** Features a highly transparent resin glass mirror, imported PC case, stainless steel button, and high-quality silicone band.



Figure 2.2: Visual representation of the watch's main functions including daily time, alarm, 50M water resistance, LED lighting, calendar, and 12/24 hour format.

3. Button Functions

Your watch has four primary buttons: LIGHT, MODE, START, and RESET. Refer to the diagram below for their locations.



Figure 3.1: Watch display and strap features. The image highlights the LED digital display, the metal buckle, and the free strap adjustment mechanism.

- **LIGHT Button:** Activates the LED backlight.
- **MODE Button:** Cycles through different modes (Time, Alarm, Stopwatch).
- **START Button:** Used to start/stop functions in Stopwatch mode, and to adjust values in setting modes.
- **RESET Button:** Used to reset functions in Stopwatch mode, and to select items in setting modes.

4. Setup Instructions

4.1 Setting Time and Date

1. From the normal time display, press the**MODE** button three times to enter the Time Setting mode. The seconds will start flashing.
2. Press the **RESET** button to cycle through the settings: Seconds → Hour → Minute → Month → Date → Day of

Week.

3. Use the **START** button to adjust the flashing value.
4. Once all settings are correct, press the **MODE** button to exit the Time Setting mode and return to the normal time display.

4.2 Setting the Alarm

1. From the normal time display, press the **MODE** button once to enter the Alarm mode.
2. Press the **RESET** button to select the hour or minute setting. The selected value will flash.
3. Use the **START** button to adjust the flashing hour or minute.
4. Press the **MODE** button to exit the Alarm setting mode.
5. To turn the alarm ON/OFF, in Alarm mode, press the **START** button. An alarm icon will appear/disappear to indicate its status.

5. Operating Instructions

5.1 Using the Stopwatch (Chronograph)

1. From the normal time display, press the **MODE** button twice to enter the Stopwatch mode. The display will show "00:00:00".
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to reset the stopwatch to "00:00:00".
5. Press the **MODE** button to exit Stopwatch mode and return to the normal time display.

5.2 Activating the Backlight

Press the **LIGHT** button at any time to illuminate the display for a few seconds, allowing for clear viewing in dark environments.

6. Maintenance and Care

Proper care will extend the life of your L LAVAREDO watch.

- **Cleaning:** Clean the watch with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by drying. Avoid harsh chemicals or abrasive materials.
- **Water Resistance:** The watch is 5ATM water resistant, suitable for daily splashes, rain, and hand washing. **DO NOT** wear the watch while swimming, showering, or in a sauna. Avoid pulling buttons underwater, as this can compromise the seal. Frequent contact with water, especially hot water, can reduce the watch's lifespan.
- **Temperature Exposure:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect the internal components and waterproof seals.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields (e.g., magnets, mobile phones, refrigerators, computers), as these can cause inaccuracies or temporary stoppage of the watch's functions.
- **Impact:** While designed to be shock-resistant, avoid severe impacts or dropping the watch.



Figure 6.1: Illustration of 5ATM water resistance, suitable for hand washing, rain, and splashes, but not for submersion.

7. Troubleshooting

If you encounter any issues with your watch, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the CR2032 battery. (Professional replacement recommended).
Time is inaccurate.	Incorrect setting; exposure to strong magnetic fields.	Re-set the time following Section 4.1. Keep watch away from magnets.

Problem	Possible Cause	Solution
Water inside the watch or fogging.	Exposure to water beyond 5ATM rating; buttons pressed underwater.	Stop using the watch immediately. Seek professional repair. Avoid improper water exposure.
Buttons are unresponsive.	Stuck button; internal malfunction.	Gently press buttons to ensure they are not stuck. If issue persists, contact support.

8. Specifications

Feature	Detail
Model Number	L6606Man-Blue
Dial Diameter	50 mm
Dial Thickness	17 mm
Band Length	270 mm
Band Width	20 mm
Watch Weight	64 g (approx.)
Water Resistance	5ATM (50 meters)
Battery Type	1 x CR2032 (required)
Case Material	Imported PC
Band Material	High quality silicone resin
Mirror Material	Highly transparent resin glass



Figure 8.1: Detailed dimensions and specifications of the watch.

9. Warranty and Support

L LAVAREDO is committed to providing high-quality products. If you have any questions or require assistance with your watch, please do not hesitate to contact the seller or L LAVAREDO customer support. We aim to provide a satisfactory solution for any product-related inquiries.

For support, please refer to the contact information provided at the point of purchase or visit the official L LAVAREDO store page on Amazon: L LAVAREDO Store.

© 2024 L LAVAREDO. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question