

Dyson 700059075

Dyson Lightcycle Morph Desk Lamp User Manual

Model: 700059075

Color: White/Silver

INTRODUCTION

The Dyson Lightcycle Morph Desk Lamp is designed to intelligently track your local daylight, providing optimal light for various tasks and environments. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your lamp.

WHAT'S IN THE BOX

- Dyson Lightcycle Morph Desk Lamp
- Remote Control
- Power Adapter (100-240V compatible)



An image showing the Dyson Lightcycle Morph Desk Lamp in its packaging, highlighting its sleek design and adjustable arm. The lamp is white and silver, with a textured base.

SETUP

Unpacking

Carefully remove all components from the packaging. Retain packaging for future transport or storage.

Assembly

The Dyson Lightcycle Morph Desk Lamp typically comes pre-assembled. Ensure the base is stable on a flat surface. Connect the power adapter to the lamp's power input and then to a suitable electrical outlet (100-240V).

Initial Power On

Press the power button located on the lamp head to turn it on. The lamp will perform a brief calibration sequence.

OPERATING YOUR LAMP

Light Modes

The Lightcycle Morph offers four primary light modes:

- **Task Light:** Direct, focused light for detailed work.
- **Indirect Light:** Soft, diffused light for ambient illumination.
- **Feature Light:** Highlights specific objects or areas.
- **Ambient Light:** Creates a relaxing atmosphere.

Adjust modes using the controls on the lamp head or via the Dyson Link app.

Adjusting Brightness and Color Temperature

Use the touch-sensitive controls on the lamp head to adjust brightness and color temperature (2700K-6500K when undocked, 1800K-3400K when docked).

Dyson Link App Control

Download the Dyson Link app from your device's app store. Follow the in-app instructions to connect your lamp. The app allows for intelligent tracking of local daylight, personalized light settings, and scheduling.

Magnetic Touch-Glide Docking

The lamp head can be magnetically docked to the stem for a different light projection.

MAINTENANCE

Cleaning

Ensure the lamp is unplugged before cleaning. Wipe the lamp surfaces with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.

LED Life

The integrated LEDs are designed for long life (up to 181,000 hours) and are not user-replaceable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on	No power supply	Check power cable connection and wall outlet. Ensure the lamp is plugged into a 100-240V supply.
Light flickers	Power fluctuation or internal issue	Ensure stable power supply. If flickering persists, contact Dyson support.
Cannot connect to Dyson Link app	Bluetooth/Wi-Fi issue or app error	Ensure Bluetooth is enabled on your device. Restart the app and lamp. Refer to the app's help section for detailed connection steps.
Light color/brightness not adjusting	Controls unresponsive	Clean the touch-sensitive controls. If unresponsive, try resetting the lamp by unplugging and replugging it.

SPECIFICATIONS

Feature	Detail
Model Name	Dyson Lightcycle Morph
Model Number	700059075
Dimensions (HxLxW)	523 x 414.4 x 200.2 mm (20.59"H x 16.31"D x 7.88"W)
Weight	3.5 kg (7.7 pounds)
Color	White / Silver
Material	Aluminum, Metal
Light Source	LED
Color Temperature (Undocked)	2700-6500 K
Color Temperature (Docked)	1800-3400 K
Rated Power	11.2 W
Luminous Efficacy	75 l/W
Light Output	850 lm
Average Lux Level	1,546 lx
LED Lifetime	181,000 hrs
Input Voltage	100-240 V
Frequency	50/60 Hz
Beam Angle	78 degrees

Feature	Detail
CRI	90 MIN
R9	48 MIN
Flicker	<1%
Standby Power Consumption	<0.5 W
Electrical Class	Class III
Control Method	App, Push Button
Connectivity Technology	USB (for charging/updates, not primary control), App

WARRANTY AND SUPPORT

For warranty information and technical support, please visit the official Dyson website or contact Dyson customer service. Keep your proof of purchase for warranty claims. You can find more information at the [Dyson Store on Amazon](#).