

[Manuals.plus](#) /

› [Ball & Cast](#) /

› Ball & Cast Swivel Counter Height Barstool (HSA-1001B-2) Instruction Manual

Ball & Cast HSA-1001B-2

Ball & Cast Swivel Counter Height Barstool (HSA-1001B-2) Instruction Manual

This manual provides detailed instructions for the assembly, operation, and maintenance of your Ball & Cast Swivel Counter Height Barstool.

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble the barstool on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly.
- Regularly check all fasteners to ensure they remain tight.
- Do not stand on the barstool.
- Maximum weight recommendation: **250 Pounds**. Do not exceed this limit.
- Keep children away from the assembly area.

PRODUCT FEATURES

The Ball & Cast Swivel Counter Height Barstool is designed for comfort and durability, featuring:

- **Versatile Usage:** Suitable for kitchens, dining areas, bistros, cafes, patios, and home bars.
- **Durable and Comfortable:** Constructed with a solid wood and metal frame, an upholstered seat filled with high-density, fire-retardant foam, and covered with breathable fabric for long-lasting comfort.
- **Functional Swivel:** A 360-degree swivel design allows for freedom of movement and easy communication.
- **Design Style:** Features a light brown finish with a wire-brushed effect and antiqued nail-head trim, blending modern and farmhouse aesthetics.



Image 1: The Ball & Cast Swivel Counter Height Barstool, showcasing its design and taupe fabric with nailhead trim.

SPECIFICATIONS

Feature	Detail
Model Number	HSA-1001B-2
Overall Dimensions	19.3"D x 19.25"W x 37.25"H
Seat Height	24 Inches
Seat Width	16 Inches
Color	Taupe Seat
Frame Material	Wood

Feature	Detail
Seat Material Type	Fabric
Furniture Finish	Light Brown
Maximum Weight Recommendation	250 Pounds
Assembly Required	Yes
Number of Pieces	1

Note: Product dimensions are approximate and may vary slightly.






Image 2: Detailed diagram illustrating the overall dimensions (depth, width, height) of the barstool.



Counter height Bar Stool-24 Inch Seat Height

Pub height Bar Stool-29 Inch Seat Height

Image 3: Informational graphic demonstrating how to choose the appropriate barstool height for various counter or island heights.

ASSEMBLY INSTRUCTIONS

This barstool requires assembly. Please follow the steps below carefully. It is recommended to have two people for easier assembly.

Package Contents

Before starting, ensure all components are present. Refer to the included assembly instructions for a complete list of parts and hardware.

Step-by-Step Assembly

1. **Prepare the Seat Base:** Place the upholstered seat (A) upside down on a soft, clean surface.
2. **Attach the Legs:** Carefully align each leg (B) with the pre-drilled holes on the underside of the seat base. Insert the bolts (C) and washers (D) through the holes and loosely tighten them with the provided Allen wrench (E). Do not fully tighten yet.
3. **Install the Footrest Ring:** Connect the metal footrest ring (F) to the legs using the smaller screws (G). Ensure the ring is evenly positioned and all connections are secure. Loosely tighten the screws.
4. **Attach the Backrest:** Align the backrest (H) with the metal supports (I) on the seat base. Secure the backrest to the supports using the remaining bolts (J) and washers (K). Loosely tighten.
5. **Final Tightening:** Once all components are assembled and aligned, carefully turn the barstool upright. Apply gentle pressure to the seat to ensure it is level, then progressively tighten all bolts and screws until they are firm. Do not overtighten.
6. **Check Stability:** Ensure the barstool is stable and does not wobble. If it wobbles, loosen the leg bolts slightly, press down on the seat, and retighten.

Overall Dimension: 19.3"D*19.25"W*37.25"H

Seet Height: 24"H Seat Width:16"W



Image 4: Underside view of the barstool seat, illustrating the attachment points for the legs and the swivel mechanism.



Image 5: Detail of the backrest attachment to the seat, showing the metal supports and connection points.

OPERATING INSTRUCTIONS

Swivel Function

The barstool features a 360-degree swivel mechanism. To operate, simply rotate the seat in any desired direction. Ensure there are no obstructions around the base of the stool that could impede the swivel motion.



Image 6: Close-up view of the upholstered seat with nailhead trim, demonstrating the smooth swivel action.

Proper Usage

- Always sit centrally on the seat to maintain balance and stability.
- Use the footrest ring for comfortable foot placement.
- Avoid sudden, forceful movements when swiveling to prevent excessive wear on the mechanism.

MAINTENANCE

Cleaning

- **Fabric Seat:** For general cleaning, wipe the fabric seat with a dry cloth. For spills, blot immediately with a clean, dry cloth. Do not rub. For stubborn stains, consult a professional upholstery cleaner.
- **Wood and Metal Frame:** Wipe the wood and metal surfaces with a soft, dry cloth to remove dust and debris. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.

General Care

- Periodically check all bolts and screws and tighten them if necessary to ensure the barstool remains stable.
- Avoid exposing the barstool to direct sunlight or extreme temperature changes, which can cause the wood to warp or fade.
- Do not place hot items directly on the seat or wooden surfaces.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Barstool wobbles	Loose fasteners; uneven floor	Check and tighten all bolts and screws. Ensure the barstool is on a level surface. If wobbling persists, slightly loosen leg bolts, press down on the seat, and retighten.
Swivel mechanism is stiff or noisy	Lack of lubrication; debris in mechanism	Apply a small amount of silicone-based lubricant to the swivel mechanism. Ensure no debris is obstructing the movement.
Parts do not align during assembly	Incorrect orientation of parts; bolts overtightened prematurely	Review the assembly instructions to ensure all parts are oriented correctly. Loosen all bolts and re-align components before tightening.

WARRANTY AND SUPPORT

For warranty information or assistance with your Ball & Cast Swivel Counter Height Barstool, please refer to the documentation included with your purchase or contact Ball & Cast customer support directly.

Contact Information: Please visit the official Ball & Cast website for the most up-to-date contact details.

[Visit the Ball & Cast Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question