

[Manuals.plus](#) /

› [Sojag](#) /

› Sojag Monteserra Gazebo 10' x 12' Instruction Manual

Sojag 500-9166842

Sojag Monteserra Gazebo 10' x 12' Instruction Manual

Model: 500-9166842

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Sojag Monteserra 10' x 12' Gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and safe use of your gazebo.

The Sojag Monteserra Gazebo is designed to provide a protective shade structure for outdoor living spaces, patios, or yards. It features a durable light grey powder-coated aluminum steel frame, a white nylon fabric roof, and integrated mosquito netting.



Image: The Sojag Monteserra Gazebo installed in a backyard, showcasing its design and utility as an outdoor living space.

SAFETY INFORMATION

- Always follow all assembly instructions carefully.
- Assembly requires two or more people. Do not attempt to assemble alone.
- Ensure all parts are securely fastened before use.
- The gazebo is certified flame resistant and meets CPAI-84 flame-resistant international safety standards. However, keep all heat sources and open flames away from the fabric.
- Remove the nylon roof and mosquito net during winter months or in anticipation of heavy snow, strong winds, or severe weather conditions to prevent damage.
- Do not hang heavy objects from the gazebo frame.
- Periodically inspect the structure for any loose parts or damage and address them promptly.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The package includes:

- 1 x Gazebo structure (frame components)
- 1 x Fabric roof
- Mosquito netting set
- Hardware kit (bolts, screws, connectors, etc.)
- Instruction manual (this document)
- Warranty manual

SETUP AND ASSEMBLY

Assembly of the Sojag Monteserra Gazebo typically requires two or more individuals and takes approximately 5 hours. Follow the step-by-step instructions provided in the included assembly guide for detailed guidance. Ensure you have adequate space and all necessary tools before starting.



Image: The assembled gazebo frame before the fabric roof and mosquito netting are installed. This image illustrates the structural components.

Key Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components and verify against the parts list in the separate assembly guide.
2. **Assemble Base Frame:** Connect the horizontal and vertical support beams to form the base structure.
3. **Install Posts:** Attach the main support posts to the base frame.
4. **Construct Roof Frame:** Assemble the roof support beams and connect them to the top of the posts.
5. **Attach Fabric Roof:** Carefully spread and secure the white nylon fabric roof onto the roof frame. Ensure it is taut and evenly distributed.
6. **Install Mosquito Netting:** Attach the mosquito netting to the designated tracks or hooks on the gazebo frame.
7. **Final Checks:** Double-check all connections for tightness and stability.




Image: Technical drawing showing the dimensions of the Sojag Montessera 10' x 12' Gazebo, including height, length, and width measurements.

Assembly Video:

Your browser does not support the video tag.

Video: An official video demonstrating the features and potential uses of the Montessera Gazebo. This video may provide visual guidance for assembly and operation.

OPERATING INSTRUCTIONS

The Sojag Montessera Gazebo is designed for ease of use and provides a comfortable outdoor environment.

Mosquito Netting:

- The included mesh mosquito net can be deployed to protect against insects.
- For easy entry and exit, the mosquito nets can be tied back to the gazebo posts using the integrated straps.
- To fully enclose the gazebo, untie the nets and zip them together as needed.



Image: The Sojag Monteserra Gazebo with its mosquito netting panels neatly tied back to the support posts, allowing for open access.



Image: The Sojag Monteserra Gazebo with its mosquito netting fully closed, providing an enclosed space protected from insects.

Seasonal Use:

- The aluminum structure is designed to be left up year-round.
- The fabric roof and mosquito netting **must be removed** for the winter season or during periods of heavy snow, strong winds, or other severe weather conditions to prevent damage to the fabric and frame.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your gazebo.

- **Frame:** The powder-coated aluminum steel frame is designed to be low maintenance and resistant to corrosion, rust, and UV rays. Clean the frame periodically with mild soap and water, then rinse thoroughly. Avoid abrasive cleaners or tools that could scratch the finish.
- **Fabric Roof and Netting:** Clean the nylon fabric roof and mosquito netting with mild soap and water. Ensure they are completely dry before storing them for the winter to prevent mildew.
- **Winter Storage:** As noted in the operating instructions, the fabric roof and mosquito netting must be removed and stored in a dry, protected area during winter or severe weather.
- **Hardware:** Periodically check all bolts, screws, and connections to ensure they remain tight. Tighten any loose hardware as needed.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Sojag Monteserra Gazebo.

- **Loose Connections:** If the gazebo feels unstable, check all bolts and screws. Tighten any loose hardware. Refer to the assembly manual for specific connection points.
- **Water Accumulation on Roof:** Ensure the fabric roof is installed tautly and evenly to allow for proper water runoff. Sagging fabric can lead to water pooling.
- **Damaged Fabric:** Small tears in the fabric roof or netting can often be repaired with a suitable fabric repair kit. For significant damage, replacement parts may be available. Contact customer support for assistance.
- **Missing Parts:** If you discover missing parts during assembly, refer to the parts list in your assembly manual and contact Sojag customer support immediately.

For issues not covered here, please contact Sojag customer support.

SPECIFICATIONS

Feature	Detail
Brand	Sojag
Model Number	500-9166842
Assembled Dimensions (L x W x H)	142.9" x 118.1" x 105.9" (approximately 11.9' x 9.8' x 8.8')
Floor Area	120 square feet
Item Weight	147.7 pounds
Frame Material	Powder-coated Aluminum Steel
Roof Material	Nylon Fabric

Feature	Detail
Color	Gray (Frame), White (Roof), Black (Netting)
Water Resistance Level	Water Resistant
UV Protection	True
Flame Resistance	Certified (CPAI-84 standards)
UPC	772830166842

WARRANTY INFORMATION

The Sojag Monteserra Gazebo comes with a **1 Year Limited Manufacturer Warranty**. Please refer to the separate warranty manual included in your package for full details regarding coverage, terms, and conditions. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to order replacement parts, please contact Sojag customer support. Refer to the contact information provided in your warranty manual or visit the official Sojag website for support options. For additional information and product registration, please visit: www.sojag.ca

© 2023 Sojag. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question