



[Manuals.plus](#) /

> [Lunar](#) /

> Lunar Turntable Belt Instruction Manual for Technics Models SL-B2, SL-B3, SL-B4, SL-BL3

Lunar GEN-FBM-23-6-M241

Lunar Turntable Belt Instruction Manual

For Technics Models SL-B2, SL-B3, SL-B4, SL-BL3

INTRODUCTION

This manual provides instructions for the proper installation and maintenance of your Lunar replacement turntable belt. This belt is specifically designed for select Technics turntable models to ensure optimal performance and longevity of your audio equipment.

COMPATIBLE MODELS

This Lunar turntable belt is compatible with the following Technics turntable models:

- Technics SL-B2
- Technics SL-B3
- Technics SL-B4
- Technics SL-BL3


INSTALLATION GUIDE

Follow these steps carefully to replace your turntable belt. Ensure the turntable is powered off and unplugged before beginning.

1. **Prepare the Turntable:** Carefully remove the platter from your Technics turntable. Consult your turntable's original manual for specific instructions on platter removal, as this can vary by model.
2. **Remove Old Belt (if present):** If an old belt is still on the turntable, gently remove it. Note its path for reference, if possible.
3. **Clean Pulley and Platter Rim:** Use a clean, lint-free cloth and a small amount of isopropyl alcohol to clean the motor pulley and the inner rim of the platter where the belt makes contact. This removes any residue that could affect the new belt's performance.
4. **Install New Belt:** Carefully stretch the new Lunar belt around the motor pulley and the inner rim of the platter.

Ensure the belt is seated evenly and without twists. Avoid overstretching the belt during installation.

5. **Reassemble Turntable:** Carefully place the platter back onto the turntable spindle. Ensure it is seated correctly and spins freely. Do not force it.
6. **Test Operation:** Plug in and power on your turntable. Select a record and test the playback to ensure the platter rotates smoothly and at the correct speed.



An image showing the black rubber Lunar turntable belt, designed for Technics models, laid out in an elongated loop shape.

OPERATION

Once installed, the turntable belt operates automatically with your turntable. Ensure the belt remains free of debris and is properly seated for consistent speed and sound quality. No specific user interaction with the belt itself is required during normal operation.

MAINTENANCE

Regular maintenance helps prolong the life of your turntable belt and ensures optimal audio performance.

- **Regular Inspection:** Periodically inspect the belt for signs of wear, cracking, stretching, or deterioration. A worn belt can lead to inconsistent platter speed.
- **Cleaning:** If dust or debris accumulates on the belt, gently wipe it with a dry, lint-free cloth. Avoid using harsh chemicals.
- **Storage:** If the turntable is to be stored for an extended period, it is recommended to remove the belt to prevent it from developing flat spots or becoming permanently stretched.
- **Replacement:** Replace the belt if it shows significant signs of wear or if you notice inconsistent playback speed, even after cleaning.

TROUBLESHOOTING

If you encounter issues after installing the new belt, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Platter not spinning or spinning too slowly	Belt is not properly seated or is twisted.	Power off and unplug the turntable. Re-seat the belt, ensuring it is flat and correctly positioned on the motor pulley and platter rim.

Problem	Possible Cause	Solution
Inconsistent playback speed (wow and flutter)	Belt is dirty, worn, or stretched.	Clean the belt and pulley. If the problem persists, the belt may need replacement.
Belt slips off the pulley	Motor pulley or platter rim is dirty or oily.	Clean the motor pulley and platter rim thoroughly with isopropyl alcohol.

PRODUCT SPECIFICATIONS

Brand: Lunar

Model Number: GEN-FBM-23-6-M241

Material: Rubber

Belt Style: Flat Belt

Width: Approximately 0.187" (3/16") to 0.203" (13/64") (4.8-5.2mm)

Length (FBM): 25.0" (63.5cm)

Compatible Devices: Turntables (specifically Technics SL-B2, SL-B3, SL-B4, SL-BL3)

Color: Black

Item Weight: 0.01 Kilograms

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Lunar turntable belt, please refer to the seller's return policy or contact the seller directly through the platform where the purchase was made.

Seller: Dynamic Lamps

Return Policy: 30 days for refund/replacement

Lunar is a registered trademark.