

Dolphin SP-17RBT

Dolphin SP-17RBT 15 Inch Party Speaker User Manual

Model: SP-17RBT | Brand: Dolphin

1. INTRODUCTION

Thank you for purchasing the Dolphin SP-17RBT 15 Inch Party Speaker. This portable PA system is designed to deliver powerful audio with its 15-inch woofer and horn tweeter, complemented by an engaging LED light display. Featuring WaveSync Technology for wireless stereo pairing, multiple input options (Bluetooth, AUX, USB), and included accessories like a microphone and tripod stand, the SP-17RBT is ideal for various audio applications. This manual provides essential information for safe operation, setup, and maintenance of your speaker.

2. SAFETY INSTRUCTIONS

- Read all instructions carefully before operating the speaker.
- Keep the speaker away from water, moisture, and extreme temperatures.
- Ensure proper ventilation; do not block any ventilation openings.
- Use only the power adapter supplied by the manufacturer.
- Do not attempt to open or repair the speaker yourself. Refer all servicing to qualified personnel.
- Clean the speaker only with a dry, soft cloth.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.

3. PACKAGE CONTENTS

Please check that all items listed below are included in your package:

- Dolphin SP-17RBT 15 Inch Party Speaker
- Tripod Stand
- Microphone
- Remote Control
- 9V Power Adaptor

4. PRODUCT OVERVIEW



Figure 4.1: Front view of the Dolphin SP-17RBT speaker with its included tripod stand, showcasing the main woofer, horn tweeter, LED light strips, and control panel at the top. The speaker features a black finish with blue LED accents.



Figure 4.2: Close-up of the speaker's control panel, displaying buttons for power, LED light control, input selection (Bluetooth, AUX, USB), microphone inputs, volume controls, and an equalizer display. The display shows 'BLUE' indicating Bluetooth mode.



Figure 4.3: Detail of the speaker's base, highlighting the integrated wheels for portability and the sturdy feet for stable placement. The wheels facilitate easy transport of the unit.

Control Panel Functions:

- **POWER Switch:** Turns the speaker ON or OFF.
- **LED LIGHT Switch:** Toggles the LED light display ON or OFF.
- **MODE Button:** Switches between input modes (Bluetooth, AUX, USB).
- **PLAY/PAUSE Button:** Plays or pauses audio playback in Bluetooth/USB mode.
- **PREVIOUS/NEXT Buttons:** Skips to the previous or next track in Bluetooth/USB mode.
- **MIC IN (6.35mm):** Input jack for connecting the included microphone.
- **AUX IN (3.5mm):** Input jack for connecting external audio devices via an AUX cable.
- **USB Port:** For playing audio files from a USB flash drive.

- **MIC VOL Knob:** Adjusts the volume of the connected microphone.
- **ECHO Knob:** Adjusts the echo effect for the microphone.
- **VOLUME Knob:** Controls the master volume of the speaker.
- **Equalizer Display:** Visual representation of audio levels.
- **DC 9V Input:** Power input for charging the speaker.

5. SETUP

5.1 Unpacking

Carefully remove all components from the packaging. Retain the packaging for future transport or storage.

5.2 Speaker Stand Assembly

1. Unfold the legs of the tripod stand until they are fully extended and stable.
2. Adjust the height of the stand to your desired level, ensuring the locking pin is securely engaged.
3. Carefully place the Dolphin SP-17RBT speaker onto the pole of the tripod stand. Ensure it is seated firmly and balanced.

Alternatively, the speaker can be placed directly on a flat, stable surface.

5.3 Powering On and Charging

1. Connect the supplied 9V power adapter to the DC 9V input port on the speaker and then to a power outlet.
2. For first-time use, it is recommended to fully charge the speaker for approximately 3 hours. The charging indicator light will show the charging status.
3. Flip the POWER switch to the 'ON' position to turn on the speaker.

A full charge provides over 5 hours of playback time.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

To turn the speaker on, flip the POWER switch located on the control panel to the 'ON' position. To turn it off, flip the switch to the 'OFF' position.

6.2 Bluetooth Connection

1. Turn on the speaker. The default mode is typically Bluetooth, indicated by 'BLUE' on the display and a blinking Bluetooth icon. If not, press the MODE button until Bluetooth mode is selected.
2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).
3. Search for available Bluetooth devices and select "Dolphin SP-17RBT" from the list.
4. Once paired, the speaker will emit a confirmation sound, and the Bluetooth icon will stop blinking. You can now play audio from your device through the speaker.

6.3 AUX Input

1. Connect one end of a 3.5mm audio cable (not included) to the AUX IN port on the speaker.
2. Connect the other end of the cable to the headphone jack or audio output of your external device.

3. Press the MODE button on the speaker until 'AUX' is displayed.
4. Play audio from your external device.

6.4 USB Playback

1. Insert a USB flash drive containing MP3 audio files into the USB port on the speaker.
2. The speaker will automatically switch to USB mode and begin playing the audio files. If not, press the MODE button to select USB mode.
3. Use the PLAY/PAUSE, PREVIOUS, and NEXT buttons to control playback.

6.5 Microphone Use

1. Connect the included microphone to the MIC IN (6.35mm) port on the speaker.
2. Adjust the MIC VOL knob to control the microphone's volume.
3. Turn the ECHO knob to add or reduce the echo effect for vocals.

6.6 WaveSync Technology (TWS Pairing)

WaveSync Technology allows you to wirelessly connect two Dolphin SP-17RBT speakers for a true stereo sound experience.

1. Ensure both SP-17RBT speakers are powered on and in Bluetooth mode.
2. On one of the speakers (this will be your primary speaker), press and hold the dedicated WaveSync button (if available, or a combination of buttons as per specific model instructions, typically the PLAY/PAUSE button for a few seconds).
3. The primary speaker will search for the secondary speaker. Once connected, both speakers will emit a confirmation sound.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described in section 6.2. Audio will play simultaneously through both speakers in stereo.

6.7 LED Light Display

The speaker features an integrated LED light display that dances and changes color with the music. To turn the LED lights ON or OFF, use the dedicated LED LIGHT switch on the control panel.

6.8 Remote Control

The included remote control provides convenient access to various functions:

- **Power:** Turns the speaker ON/OFF.
- **Mode:** Switches input sources.
- **Volume +/-:** Adjusts master volume.
- **Play/Pause:** Controls media playback.
- **Previous/Next:** Skips tracks.
- **EQ:** Cycles through equalizer presets (if available).

7. MAINTENANCE

7.1 Cleaning

Wipe the speaker's exterior with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents, as they may damage the

finish. Avoid spraying liquids directly onto the speaker.

7.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures. If possible, use the original packaging for protection.

7.3 Battery Care

To prolong the life of the built-in Lithium Ion battery, charge it regularly, even if the speaker is not in frequent use. Avoid completely draining the battery before recharging.

8. TROUBLESHOOTING

- **No Power:**

Ensure the power adapter is securely connected to both the speaker and a working power outlet. Check if the POWER switch is in the 'ON' position. If operating on battery, ensure the battery is charged.

- **No Sound:**

Check the master VOLUME knob on the speaker and the volume on your connected audio device. Ensure the correct input MODE (Bluetooth, AUX, USB) is selected. Verify all audio cables are securely connected.

- **Bluetooth Not Connecting:**

Make sure the speaker is in Bluetooth mode and discoverable (Bluetooth icon blinking). Ensure Bluetooth is enabled on your device and it's within range (typically 10 meters). Try forgetting "Dolphin SP-17RBT" from your device's Bluetooth list and re-pairing.

- **Distorted Sound:**

Reduce the volume on both the speaker and the audio source. Check if the audio source itself is of good quality. Ensure no cables are damaged or loosely connected.

- **Microphone Not Working:**

Ensure the microphone is securely plugged into the MIC IN port. Adjust the MIC VOL knob. Check if the microphone itself is functional.

- **WaveSync Pairing Fails:**

Ensure both speakers are SP-17RBT models and are in Bluetooth mode before attempting to pair them via WaveSync. Make sure they are close to each other.





9. SPECIFICATIONS

- **Model:** SP-17RBT
- **Output Wattage:** 2700 Watts (Peak)
- **Woofer Size:** 15 Inch
- **Connectivity Technology:** AUX, Bluetooth, USB
- **Power Source:** Battery Powered (Built-in Lithium Ion)
- **Battery Life:** Over 5 Hours (approx.)
- **Charge Time:** 3 Hours (approx.)
- **Item Weight:** 18 Pounds
- **Color:** Black
- **Mounting Type:** Pole Mount
- **UPC:** 850006218448

10. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the official Dolphin website or contact their customer support directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Related Documents

 <p>DOLPHIN DOLPHINAUDIO.COM/SP-210RBT</p> <p>INSTRUCTION MANUAL MANUAL DE INSTRUCCIONES MANUEL D'INSTRUCTIONS</p>	<p>Dolphin SP-210RBT Portable Bluetooth Party Speaker - Instruction Manual</p> <p>Comprehensive instruction manual for the Dolphin SP-210RBT portable Bluetooth party speaker, covering setup, features like Bluetooth connectivity, WaveSync, USB/SD playback, FM radio, and battery management.</p>
 <p>DOLPHIN DOLPHINAUDIO.COM/SP-880RBT</p> <p>INSTRUCTION MANUAL MANUAL DE INSTRUCCIONES MANUEL D'INSTRUCTIONS</p>	<p>Dolphin SP-880RBT Portable Bluetooth Speaker Instruction Manual</p> <p>Comprehensive instruction manual for the Dolphin SP-880RBT portable Bluetooth speaker, covering setup, features like Bluetooth, WaveSync, USB/TF playback, FM radio, AUX input, and battery management.</p>
 <p>DOLPHIN DOLPHINAUDIO.COM/SP-210RBT</p> <p>INSTRUCTION MANUAL MANUAL DE INSTRUCCIONES MANUEL D'INSTRUCTIONS</p>	<p>Dolphin SP-210RBT Portable Bluetooth Speaker Instruction Manual</p> <p>Comprehensive instruction manual for the Dolphin SP-210RBT portable Bluetooth speaker, covering setup, features, and troubleshooting in English, Spanish, and French.</p>
 <p>DOLPHIN DOLPHINAUDIO.COM/SP-2100RBT</p> <p>INSTRUCTION MANUAL MANUAL DE INSTRUCCIONES MANUEL D'INSTRUCTIONS</p>	<p>Dolphin SP-2100RBT Portable Bluetooth Speaker Instruction Manual</p> <p>User guide for the Dolphin SP-2100RBT portable Bluetooth speaker, detailing setup, controls, features like WaveSync, Bluetooth connectivity, USB/SD/FM playback, and battery management.</p>



SHOP ONLINE March VIDEO CHAT Madness ORBYPHONE 32 - SAVE 52 198 32
SMART LED HDTV 720p HD Resol ... 15 Woofers and Horn Tweeter WaveSync
Panel LED lights change color One 1/4 Microphone Jacks **SP-17RBT** 198 DOLPHIN
PARTY SPEAKER 8 Woofer 1800 Watts Bluetooth Portable Sound Activated L...
lang:en score:17 filesize: 1.47 M page_count: 2 document date: 2024-03-11