

[Manuals.plus](#) /

› [PANDORA](#) /

› PANDORA Paw Print Charm User Manual

PANDORA 798869C00

PANDORA Paw Print Charm User Manual

Model: 798869C00

PRODUCT OVERVIEW

The PANDORA Paw Print Charm, model 798869C00, is a sterling silver charm designed for women. It features an openwork paw print design, symbolizing the bond with pets. This charm is intended to be added to compatible PANDORA bracelets or necklaces.



Image: Front view of the PANDORA Paw Print Charm, showcasing its intricate openwork design.

SETUP AND INSTALLATION

To attach the PANDORA Paw Print Charm to your bracelet or necklace:

1. Ensure your PANDORA bracelet or necklace is open and ready to receive charms.
2. Gently slide the charm onto the bracelet or necklace. The charm is designed to fit standard PANDORA charm carriers.
3. Once the charm is in place, secure the bracelet or necklace clasp.



Image: The PANDORA Paw Print Charm displayed on a bracelet, demonstrating how it appears when worn.

CARE AND MAINTENANCE

Proper care will help maintain the beauty and longevity of your PANDORA charm.

- **Cleaning:** Clean your sterling silver charm regularly with a soft polishing cloth specifically designed for jewelry. For deeper cleaning, use a mild soap and warm water solution, then rinse thoroughly and dry completely with a soft cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store your charm in a dry, airtight jewelry box or pouch to prevent tarnishing. Keep it separate from other jewelry to avoid scratches.
- **Avoid Exposure:** Remove your charm before showering, swimming, exercising, or applying lotions, perfumes, or hairspray. These substances can cause damage or accelerate tarnishing.
- **Professional Cleaning:** Consider professional cleaning periodically to restore its original shine.

TROUBLESHOOTING

Most issues with jewelry charms are related to tarnishing or damage from improper care. Follow the maintenance guidelines to prevent common problems.

- **Tarnishing:** If your charm appears dull or discolored, it is likely tarnished. Use a silver polishing cloth to restore its shine. Persistent tarnishing may require professional cleaning.
- **Damage:** If the charm is bent, broken, or has lost any components, it may require professional repair. Avoid attempting to repair it yourself to prevent further damage.

SPECIFICATIONS

Feature	Detail
Model Number	798869C00
Brand	PANDORA
Material	925ML Sterling Silver
Color	Silver
Product Dimensions	1.2 x 1 x 1 cm
Item Weight	1.4 g
Department	Women's
First Available Date	March 10, 2020

WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to inquire about repairs, please refer to the official PANDORA website or contact PANDORA customer service directly. Specific warranty terms may vary by region and purchase location.

Please retain your proof of purchase for any warranty claims or service requests.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B085QJV8T3>

More documents and user manuals: <https://manuals.plus/>