Zilan ZLN-4000

Zilan Cordless Table Fan User Manual

Model: ZLN-4000

1. Introduction

Thank you for purchasing the Zilan Cordless Table Fan. This fan is designed to provide quiet and efficient cooling with its 4000 mAh battery, offering up to 15 hours of cordless operation. Its 90° adjustable tilt and compact design make it ideal for various settings, including offices, bedrooms, and other personal spaces. Please read this manual carefully before use to ensure proper operation and maintenance.

2. Safety Instructions

To prevent injury or damage, please observe the following safety precautions:

- Do not insert fingers or any objects into the fan grille when the fan is operating.
- Keep the fan away from water and other liquids. Do not use in wet environments.
- Ensure the fan is placed on a stable, flat surface to prevent tipping.
- Do not block the air intake or outlet.
- Keep out of reach of children and pets.
- Use only the provided charging cable.
- Do not attempt to disassemble or repair the fan yourself. Contact qualified service personnel for assistance.
- Unplug the fan before cleaning or when not in use for extended periods.

3. Package Contents

Please check the package for the following items:

- 1 x Zilan Cordless Table Fan
- 1 x Micro USB Type B Charging Cable (approx. 150 cm length)
- 1 x User Manual (this document)

4. Product Overview

The Zilan Table Fan is designed for personal cooling with a focus on portability and quiet operation.



Figure 4.1: Zilan Cordless Table Fan in Anthracite. This image shows the fan from the front, highlighting its sleek design and the Zilan logo on the central hub.



Figure 4.2: The Zilan fan positioned on a desk next to a computer, illustrating its compact size and the benefit of its 4000 mAh battery for cordless operation, providing 4 to 15 hours of runtime.



Figure 4.3: The Zilan fan demonstrating its 90-degree adjustable tilt feature, allowing for flexible airflow direction. The fan head can be angled upwards or downwards.



Figure 4.4: The Zilan fan placed on a wooden surface in a bedroom setting, emphasizing its quiet operation for a comfortable room climate, suitable for undisturbed sleep.



Figure 4.5: A user working at a desk with the Zilan fan beside them, highlighting the fan's stable base for maximum safety and secure placement during use.



Figure 4.6: An illustration of the Zilan fan's dimensions, showing its compact size of approximately 18 cm width and 27.5 cm height, making it suitable for any home or office space.



Figure 4.7: A diagram illustrating the 90-degree tilt mechanism of the Zilan fan, showing how the fan head can be adjusted from a vertical to a horizontal position.

Key Features:

- **4 Speed Settings:** Adjust airflow to your preference.
- **5 Watt Power:** Efficient cooling performance.
- **90° Adjustable Tilt Angle:** Direct airflow precisely where needed.
- **4000 mAh Battery:** Provides extended cordless operation (up to 15 hours).
- **Very Quiet Operation:** Ideal for use in quiet environments like bedrooms or offices.
- **Protective Grille:** Ensures safety during operation.
- **Secure Stand:** Stable base prevents accidental tipping.
- **Compact and Portable:** Easy to move and fits well in small spaces.

5. Setup

1. **Unpacking:** Carefully remove the fan and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for proper air circulation.
3. **Initial Charge:** Before first use, fully charge the fan's 4000 mAh battery. Connect the Micro USB Type B charging cable to the fan's charging port and the other end to a compatible USB power adapter (not included) or a USB port on a computer. The charging indicator light will show the charging status.
4. **Adjust Tilt:** Gently adjust the fan head to the desired angle (up to 90 degrees) by tilting it manually.

6. Operating Instructions

The Zilan Table Fan is simple to operate:

1. **Power On/Off:** Press the power button located on the base of the fan to turn it on. Press it again to turn it off.

2. **Adjusting Fan Speed:** Once powered on, repeatedly press the power button to cycle through the 4 available speed settings (Low, Medium, High, Turbo). The indicator lights on the base will show the current speed setting.
3. **Adjusting Tilt:** Manually tilt the fan head up or down to direct the airflow. The fan head can be adjusted up to 90 degrees vertically.
4. **Cordless Operation:** The fan can operate without being plugged in once the battery is charged. The battery life can last up to 15 hours depending on the speed setting used.
5. **Charging During Use:** The fan can also be used while connected to a power source via the USB charging cable.

7. Maintenance

Regular cleaning and proper storage will ensure the longevity of your Zilan Table Fan:

- **Cleaning:**
  - Always unplug the fan before cleaning.
  - Use a soft, damp cloth to wipe the exterior surfaces of the fan.
  - For the fan blades and grilles, use a soft brush or a vacuum cleaner with a brush attachment to remove dust. Do not use abrasive cleaners or solvents.
  - Ensure no water enters the motor housing.
- **Storage:**
  - If storing the fan for an extended period, ensure it is clean and dry.
  - Store in a cool, dry place, away from direct sunlight and extreme temperatures.
  - It is recommended to charge the battery every 3-6 months during storage to maintain battery health.

8. Troubleshooting

If you encounter issues with your fan, please refer to the following table:

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted. Power button not pressed correctly.	Charge the fan using the USB cable. Press the power button firmly.
Weak airflow.	Fan speed is too low. Air intake/outlet blocked. Dust accumulation on blades/grille.	Increase fan speed. Ensure nothing is obstructing airflow. Clean the fan blades and grilles.
Fan makes unusual noise.	Fan not on a stable surface. Foreign object inside the grille.	Place the fan on a flat, stable surface. Turn off and unplug the fan, then carefully check for and remove any foreign objects.
Battery life is shorter than expected.	Using higher speed settings. Battery degradation over time.	Lower the fan speed for longer battery life. This is normal for rechargeable batteries. Ensure full charges.

If the problem persists after trying these solutions, please contact Zilan customer support.

9. Specifications

Feature	Detail
Brand	Zilan
Model Number	ZLN-4000
Color	Allegra Anthracite
Dimensions (WxHxD)	Approx. 18 x 27.5 cm (18T x 18B x 27.5H cm)
Weight	860 g
Power	5 Watt
Voltage	230 Volt (for charging adapter, fan is battery operated)
Battery Capacity	4000 mAh
Operating Time (Cordless)	Up to 15 hours (depending on speed setting)
Speed Settings	4 Levels
Tilt Adjustment	90° Vertical
Charging Cable	Micro USB Type B (approx. 150 cm)

10. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact Zilan customer service directly. Keep your proof of purchase for any warranty claims.
While this product has a return policy of 30 days, specific warranty terms and conditions are provided by the manufacturer.

© 2024 Zilan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question