

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [AirMyFun](#) /

› [AirMyFun Inflatable Bounce House with Double Slide \(Model B085QL1FJN\) Instruction Manual](#)

## AirMyFun B085QL1FJN

# AirMyFun Inflatable Bounce House with Double Slide (Model B085QL1FJN) Instruction Manual

Brand: AirMyFun | Model: B085QL1FJN

## 1. INTRODUCTION

---

This manual provides essential information for the safe and proper setup, operation, and maintenance of your AirMyFun Inflatable Bounce House with Double Slide. Please read all instructions carefully before use to ensure a safe and enjoyable experience for all users.

The AirMyFun Inflatable Bounce House is a versatile 5-in-1 play structure designed for children aged 36 months to 8 years. It features a bounce area, a long slide, a small slide, a ball pit, and a climbing wall, offering multiple entertainment zones. Constructed from durable 420D Oxford and 840D PVC fabric, this bounce house is built for resilience and comfort.



Figure 1: The AirMyFun Inflatable Bounce House with Double Slide in an outdoor setting.

## 2. SAFETY INFORMATION

- **Adult Supervision Required:** Always ensure constant and active adult supervision when the bounce house is in use.
- **Age and Weight Limits:** This bounce house is recommended for children aged 36 months to 8 years. The maximum weight recommendation is 300 pounds, with a maximum of 3 players at one time. Each user should weigh less than 99 pounds.
- **Clearance:** Ensure adequate clearance around the bounce house (at least 6 feet on all sides) from structures, fences, trees, and other obstacles.
- **Surface:** Set up the bounce house on a soft, level surface such as grass or sand. Avoid hard surfaces like concrete or asphalt.
- **Anchoring:** Always use the provided stakes to securely anchor the bounce house to the ground to prevent tipping or movement during use.
- **Weather Conditions:** Do not use the bounce house in windy conditions (over 15 mph), rain, or lightning. Deflate and store the unit during adverse weather.
- **No Sharp Objects:** Ensure children remove shoes, jewelry, and any sharp objects before entering the bounce house.
- **No Food or Drink:** Do not allow food, drinks, or chewing gum inside the bounce house.
- **No Rough Play:** Prohibit roughhousing, flips, or climbing on walls or netting.

## 3. INCLUDED COMPONENTS

Your AirMyFun Inflatable Bounce House package includes:

- 1 x Inflatable Bounce House
- 1 x 450W Electric Air Blower
- 6 x Ground Stakes for Bounce House

- 1 x Repair Kit (patches)
- 1 x Carrying Bag



Figure 2: Overview of included accessories for the AirMyFun Bounce House.

## 4. SETUP INSTRUCTIONS

1. **Unpack and Unfold:** Remove the bounce house from its carrying bag and unfold it completely on a clean, level surface. Ensure the air intake tube is straight and unobstructed.
2. **Connect Blower:** Attach the air intake tube of the bounce house securely to the outlet of the 450W electric air blower. Ensure the connection is tight to prevent air leakage.
3. **Position Blower:** Place the blower on a stable, dry surface away from water and potential tripping hazards.
4. **Inflate:** Plug the blower into a grounded electrical outlet and turn it on. The bounce house will inflate within a few minutes. Ensure the blower remains continuously on during use.
5. **Secure with Stakes:** Once fully inflated, use the provided ground stakes to secure the bounce house to the ground through the designated loops. This prevents movement and ensures stability.
6. **Check for Stability:** Before allowing children to enter, ensure the bounce house is fully inflated, stable, and securely anchored.

Your browser does not support the video tag.

Video 1: A quick demonstration of the AirMyFun Inflatable Bounce House setup and inflation process.

## 5. OPERATING INSTRUCTIONS

Once the bounce house is fully inflated and secured, children can begin playing. Always remind children of the safety rules outlined in Section 2.

- **Bouncing Area:** The central area is designed for bouncing. Ensure children do not overcrowd the area.
- **Slides:** Children should slide down feet first, one at a time. The slides are designed with extra thickness for durability.
- **Climbing Wall:** The climbing wall features handholds to assist children in ascending to the slide platform.
- **Ball Pit:** The designated ball pit area can be used with play balls (not included) for additional fun.



Figure 3: Various play zones within the AirMyFun Bounce House, including the basketball hoop, slides, climbing wall, and ball pit.

## 6. MAINTENANCE

- **Cleaning:** The durable Oxford and PVC fabric is washable. Use a mild soap and water solution to clean the surface. Rinse thoroughly and allow to air dry completely before storage.
- **Repairs:** A repair kit with patches is included for minor punctures. Follow the instructions provided with the repair kit for proper application.
- **Storage:** After use, ensure the bounce house is completely dry. Deflate by turning off the blower and allowing air to escape through the long outlet tube. Fold or roll the bounce house neatly and store it in the provided carrying bag in a cool, dry place away from direct sunlight.
- **Pinhole Note:** It is normal for inflatable products to have small pinholes, which are part of the manufacturing process and do not affect performance.



Figure 4: Details on the construction, including double-sewn seams and extra thickness on the slide, and a note regarding normal pinholes.

## 7. TROUBLESHOOTING

- **Bounce House Not Inflating Fully:**
  - Ensure the blower is continuously running and connected securely to the air intake tube.
  - Check for any large tears or openings in the fabric. Use the repair kit for small punctures.
  - Verify that all zippers or openings are properly closed.
- **Blower Noise:** The electric air blower will produce a continuous operating sound, which is normal.
- **Stability Issues:** Ensure all ground stakes are firmly inserted into the ground and the bounce house is on a flat, level surface.

## 8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	AirMyFun
Model Number	B085QL1FJN
Product Dimensions	145.2 x 110.16 x 72.84 inches
Item Weight	42.2 pounds
Material	420D Oxford + 840D PVC Fabric
Age Recommendation	36 months - 8 years
Maximum Weight Capacity	300 Pounds
Maximum Number of Players	3
Blower Wattage	450W
UPC	707338959221



Figure 5: Detailed dimensions and specifications of the AirMyFun Inflatable Bounce House.

## 9. WARRANTY AND SUPPORT

---

For warranty information or customer support, please refer to the contact details provided with your product packaging or visit the official AirMyFun website. Keep your purchase receipt for warranty claims.

© 2023 AirMyFun. All rights reserved.

### Related Documents - B085QL1FJN

 <p>The image shows the cover of the AirMyFun User Manual for the Inflatable Castle. It features the AirMyFun logo at the top, the text 'User Manual' in a large font, and a circular icon indicating 'AGES 3-8'. Below the text is a stylized orange line-art illustration of a castle with two towers and a central archway. At the bottom, it says 'INCLUDES THE USER MANUAL'.</p>	<p><a href="#">AirMyFun Inflatable Castle User Manual</a></p> <p>User manual for the AirMyFun inflatable castle for kids aged 3-8. Provides instructions on setup, usage, maintenance, safety precautions, and troubleshooting for inflatable bounce houses.</p>
--	--