

BarcaLounger Adler 15-3723-3618-80

BarcaLounger Adler Pedestal Recliner and Ottoman Instruction Manual

Model: Adler 15-3723-3618-80

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your BarcaLounger Adler Pedestal Recliner and Ottoman. Please read this manual thoroughly before using your new furniture to ensure safe and correct operation.

Important Safety Information

- Do not exceed the maximum weight capacity of **250 pounds**. Exceeding this limit may cause damage to the chair or personal injury.
- Ensure proper assembly for stability. Verify all connections are secure before use.
- Prevent the chair from tipping over during use, especially when swiveling. Always maintain a balanced posture.
- Keep children and pets away from moving parts to avoid injury.

SETUP AND INITIAL PLACEMENT

Your BarcaLounger Adler Recliner and Ottoman are designed for minimal assembly. While the product specifications indicate "No Required Assembly," some minor component attachment or adjustment may be necessary upon unboxing. It is recommended to have two people for safe handling and placement.

Unpacking and Positioning

1. Carefully remove all packaging materials. Retain packaging for future transport if needed.
2. Place the recliner and ottoman on a level, stable surface. Ensure adequate space around the chair for reclining and swiveling. The chair requires approximately 13.8 inches of wall proximity for full recline.
3. Inspect all components for any signs of damage. If any parts are damaged or missing, do not proceed with setup and contact customer support.



Figure 1: Front view of the BarcaLounger Adler Pedestal Recliner and Ottoman. Ensure both pieces are placed on a stable, level surface.



Figure 2: The Adler Recliner and Ottoman in their upright position. Note the chrome finish spider base on both units.

OPERATING INSTRUCTIONS

The Adler Pedestal Recliner offers multiple adjustments for personalized comfort.

Reclining Function

The recliner features a lever-controlled reclining back with synchronized movement of the back and seat. The recline angle ranges from 115 to 160 degrees.

1. Locate the reclining lever on the side of the chair (typically on the right side when seated).
2. To recline, pull the lever and lean back gently. The chair will smoothly move into your desired reclining position.
3. To return to an upright position, push the lever and lean forward. The chair will return to its original position.



Figure 3: Close-up of the reclining lever mechanism. Use this lever to adjust the backrest angle.



Figure 4: The recliner and ottoman shown in a reclined position, demonstrating the synchronized movement.

Adjustable Headrest

The chair features a 35-degree forward adjustable headrest to provide optimal neck and head support.

1. To adjust the headrest, gently push or pull the top portion of the headrest to your desired angle.
2. The headrest will hold its position once released.



Figure 5: The adjustable headrest in a neutral position.



Figure 6: The headrest tilted forward for increased neck support.



Figure 7: The headrest tilted backward, demonstrating its range of motion.

360-Degree Swivel

The pedestal chair allows for a full 360-degree swivel, providing flexibility and ease of movement.

- To swivel, simply rotate the chair in any direction. The smooth mechanism allows for effortless turning.
- The chair features an auto-return function, meaning it will naturally return to a forward-facing position when not actively swiveled.

Ottoman Adjustment

The accompanying ottoman offers a 15-degree angle adjustment for optimal leg support.

- To adjust the ottoman angle, apply gentle pressure to the footrest surface. It will pivot to accommodate your leg position.
- The ottoman is designed to adjust with your leg movement, providing dynamic support.



Figure 8: The ottoman base, featuring a chrome spider design similar to the recliner's base.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your leather recliner and ottoman.

Cleaning Instructions

- **Spot Wash:** For spills or stains, immediately blot the affected area with a clean, dry cloth. Do not rub.
- For stubborn stains, use a mild leather cleaner specifically designed for the type of leather on your chair. Test the cleaner on an inconspicuous area first.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the leather finish.
- Regularly dust the chair with a soft, dry cloth to prevent dirt buildup.

General Care

- Keep the furniture away from direct sunlight and heat sources to prevent fading and drying of the leather.
- Avoid placing sharp objects on the leather surface to prevent scratches or punctures.
- Periodically check all bolts and connections to ensure they remain tight. Tighten if necessary.

TROUBLESHOOTING

This section addresses common concerns you might encounter with your recliner and ottoman.

Chair Feels Too Firm

New furniture, especially those with foam filling, may initially feel firm. With regular use, the foam will soften and conform to your body, increasing comfort over time.

Headrest Does Not Feel Right

The Adler recliner features a 35-degree adjustable headrest. Experiment with different angles by gently pushing or pulling the headrest to find the position that best supports your neck and head. Personal comfort can vary based on individual height and posture.

Reclining Mechanism Stiff or Not Smooth

- Ensure no obstructions are preventing the mechanism from moving freely. Check for objects caught under the chair or between moving parts.
- Verify that the chair is placed on a level surface. Uneven flooring can sometimes affect the smooth operation of reclining mechanisms.
- If the issue persists, contact customer support for further assistance. Do not attempt to force the mechanism.

Ottoman Does Not Stay in Position

The ottoman is designed with a 15-degree angle adjustment that responds to leg movement. It is not intended to lock into a fixed position, but rather to provide dynamic support. If you experience excessive looseness or instability, check the base connections for tightness.

PRODUCT SPECIFICATIONS

Brand	BarcaLounger
Model Name	Adler
Model Number	15-3723-3618-80
Color	Capri-white
Material	Leather (All Leather)
Product Dimensions (D x W x H)	32.3"D x 29.5"W x 43.7"H
Item Weight	5 Pounds
Maximum Weight Recommendation	250 Pounds
Recline Angle	115 to 160 degrees
Headrest Adjustment	35-degree forward adjustable
Swivel Feature	360-degree with auto return
Ottoman Adjustment	15-degree angle adjustable
Wall Proximity	13.8 inches
Required Assembly	No (Minimal setup expected)
Care Instructions	Spot Wash

WARRANTY AND SUPPORT

For specific warranty information regarding your BarcaLounger Adler Pedestal Recliner and Ottoman, please refer to the documentation provided at the time of purchase or contact BarcaLounger customer service directly.

If you require assistance with assembly, operation, or troubleshooting beyond the scope of this manual, please reach out to the manufacturer's customer support or the retailer from whom you purchased the product.

Manufacturer: Barcalounger

Website: [Visit the BarcaLounger Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question