

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [RIVER OF GOODS](#) /

› RIVER OF GOODS 52-Inch Glam Crystal Double-Lit LED Ceiling Fan User Manual

## RIVER OF GOODS 20131

# RIVER OF GOODS 52-Inch Glam Crystal Double-Lit LED Ceiling Fan User Manual

Model: 20131

## 1. INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your RIVER OF GOODS 52-Inch Glam Crystal Double-Lit LED Ceiling Fan, Model 20131. Please read all instructions carefully before beginning installation to ensure safe and proper use.

For any questions or assistance, please refer to the troubleshooting section or contact customer support.

## 2. SAFETY INFORMATION

---

**WARNING:** To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Read all instructions before installing the fan.
- Ensure the installation site is structurally sound and can support the fan's weight.
- All wiring must be in accordance with national and local electrical codes.
- Turn off power at the circuit breaker before installation or servicing.
- Do not operate the fan with damaged parts.
- Keep hands, feet, and other objects away from rotating fan blades.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning installation.

- Ceiling Fan Motor Housing
- 5 Reversible Fan Blades (Mahogany/Antiqued Black)
- Crystal Light Kit (with 70 clear faceted K-9 crystals)
- Downrod (for adjustable height)
- Remote Control
- Light Bulbs: 2 dimmable E12 LED 6W/40W incandescent, and 4 E12 LED 1W/15W incandescent bulbs

- Mounting Hardware
- Instruction Manual



Image: The complete RIVER OF GOODS 52-Inch Glam Crystal Double-Lit LED Ceiling Fan with its remote control, showcasing the crystal light fixture and reversible blades.

## 4. SETUP AND INSTALLATION

---

Professional installation is recommended for this ceiling fan.

### 4.1. Pre-Installation Steps

1. **Turn off Power:** Before starting, ensure the power supply to the installation area is turned off at the circuit breaker.
2. **Mounting Location:** Select a location where the fan blades will be at least 7 feet from the floor and 2 feet from any walls or obstructions.
3. **Support Structure:** Ensure the outlet box is securely attached to the building structure and can support the fan's weight (approximately 17.5 lbs).

## 4.2. Mounting the Fan


1. Attach the mounting bracket to the ceiling outlet box using the provided screws.
2. Secure the downrod to the motor housing. The fan offers adjustable height options (15" H, 18" H, or 35" H with included downrod).
3. Carefully lift the fan assembly and hang it from the mounting bracket.

## 4.3. Wiring Connections

- Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the full manual. Ensure all connections are secure.
- Tuck all wires neatly into the outlet box.

## 4.4. Attaching Fan Blades

- Attach the 5 reversible fan blades to the blade arms. You can choose between the mahogany or antiqued black finish.
- Secure the blade arms to the motor housing.



The diagram features a central text block with a lightning bolt icon above it. To the left, a fan icon with red arrows pointing down is labeled 'RECIRCULATES HEAT FORCING AIR DOWN'. To the right, a fan icon with blue arrows pointing down is labeled 'WIND CHILL'. Below the central text is a large light blue box with a red border containing promotional text.

**ENERGY EFFICIENT**

Reversible blades allow for maximum air flow and comfort. The pull chain can be used to control the light strength and blade speed. There is a three-speed (reversible) motor, a blade pitch of 12 degrees and more.

RECIRCULATES HEAT  
FORCING AIR DOWN

WIND CHILL

Experience a world of passion,  
global inspiration, and innovation.

From trendsetting lighting and furnishings to handcrafted artisan accent pieces, let River of Goods take you on a journey that will transform and revitalize your home forever.

Image: Close-up view of the reversible fan blades, showing both the mahogany and antiqued black finish options.

## 4.5. Installing the Light Kit

- Connect the light kit wires to the fan's light kit wires.
- Secure the crystal light kit to the bottom of the fan motor housing.
- Install the provided E12 LED bulbs into the sockets.



Image: Detailed view of the crystal light fixture, highlighting the faceted K-9 crystals and the chrome silver metal finish.

## 5. OPERATING INSTRUCTIONS

---

Your ceiling fan can be operated using the included remote control or the pull chains.

### 5.1. Remote Control Operation

- **Fan Speed:** Use the "HI", "MED", "LOW" buttons to adjust fan speed.
- **Fan Off:** Press the "OFF" button to turn the fan off.
- **Light Control:** Use the light button (often depicted as a light bulb icon) to turn the lights on/off and cycle through light settings (e.g., top lights only, bottom lights only, all lights).



Image: The remote control for the ceiling fan, showing buttons for fan speed (HI, MED, LOW, OFF) and light control.

## 5.2. Pull Chain Operation

- One pull chain controls the fan speed (High, Medium, Low, Off).
- The other pull chain controls the light (On/Off).

## 5.3. Reversible Motor Function

The fan features a reversible motor for year-round comfort.

- **Summer Mode (Counter-clockwise):** Creates a "wind chill" effect, circulating cool air downwards.
- **Winter Mode (Clockwise):** Recirculates warm air from the ceiling, forcing it down to the living area.

To change the direction, locate the reverse switch on the fan motor housing (usually a small slide switch). Ensure the fan is off before changing direction.

# CEILING FAN ENERGY EFFICIENT




Image: An illustration demonstrating how the reversible motor functions for summer cooling (counter-clockwise rotation) and winter heating (clockwise rotation).

## 6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Crystal Cleaning:** Gently wipe the crystal components with a soft, lint-free cloth. A mild glass cleaner can be used sparingly if needed.
- **Tighten Fasteners:** Check all screws and fasteners annually to ensure they are secure.
- **Bulb Replacement:** To replace light bulbs, ensure power is off. Unscrew the old bulb and replace with a new E12 LED bulb of the specified wattage (6W/40W incandescent equivalent for dimmable, 1W/15W incandescent equivalent for mood lighting).

*Note:* Changing bulbs in the top section may require disassembling the bottom globe and fan blades. Refer to the full installation guide for detailed steps.

## 7. TROUBLESHOOTING

---

If you experience issues with your ceiling fan, consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low.	Check circuit breaker; Verify all wire connections are secure; Replace remote control battery.
Lights do not work	Bulbs are loose or burned out; Incorrect wiring; Light switch is off.	Tighten or replace bulbs; Check light kit wiring; Ensure light switch is on.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit (not included) to balance blades; Ensure mounting bracket is secure.
Noisy operation (grinding)	Loose motor housing screws; Internal motor issue.	Check and tighten motor housing screws. If noise persists, contact customer support.

## 8. SPECIFICATIONS

---

Feature	Detail
Brand	RIVER OF GOODS
Model Name	Glam Crystal Double-Lit Ceiling Fan
Model Number	20131
Product Dimensions	52"D x 52"W x 15"H (Adjustable height up to 35"H with downrod)
Item Weight	17.5 Pounds
Number of Blades	5
Blade Length	20.5 Inches
Blade Finish	Reversible (Mahogany / Antiqued Black)
Light Kit	Integrated, Double-Lit with 70 K-9 crystals
Bulb Type	E12 LED (2 x 6W/40W equivalent dimmable, 4 x 1W/15W equivalent mood lighting)
Control Type	Remote Control, Pull Chain
Fan Speeds	3 (High, Medium, Low)
Motor	Reversible
Voltage	120 Volts
Wattage	62 watts
Noise Level	2 Sones

Feature	Detail
Installation Type	Flush Mount, Downrod Mount
Indoor/Outdoor Usage	Indoor
UPC	818140025179

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please contact RIVER OF GOODS customer service. Details are typically provided with your purchase documentation or on the manufacturer's official website.

**Online Resources:** You may find additional support and FAQs on the [RIVER OF GOODS Store on Amazon](#).

