

[Manuals.plus](#) /

> [Nespresso](#) /

> Nespresso Vertuo Next Coffee and Espresso Machine by Breville (Model BNV520GRY1BUC1) - User Manual

## Nespresso BNV520GRY1BUC1

# Nespresso Vertuo Next Coffee and Espresso Machine by Breville

Model: BNV520GRY1BUC1

## INTRODUCTION

Welcome to the world of Nespresso Vertuo Next. This machine is designed to deliver an extraordinary coffee experience, from authentic espresso to a large cup of coffee, all topped with a smooth layer of crema. Utilizing patented Centrifusion technology, the Vertuo Next system precisely recognizes each capsule and adjusts brewing parameters to ensure optimal results every time.



*Image: Nespresso Vertuo Next Coffee and Espresso Machine, Gray.*

## SETUP

### Unboxing and Initial Placement

Carefully remove all components from the packaging. Ensure all protective films are removed from the machine. Place the machine on a clean, stable, and level surface away from water splashes and heat sources.



*Image: All components of the Nespresso Vertuo Next machine, including the main unit, water tank, drip tray, and a welcome set of capsules.*

## Filling the Water Tank

1. Remove the water tank from the back of the machine.
2. Fill the water tank with fresh, potable water.
3. Place the water tank back onto the machine.

# VERTUO


La gamme complète de cafés  
*The full range of coffee styles*



7 formats de tasses  
*7 cup sizes*



Une seule touche  
*Simple one-touch button*



Fabriquée à partir de 54%  
de plastique recyclé  
*Made from 54% recycled plastic*

*Image: The back of the Nespresso Vertuo Next machine, highlighting the transparent, removable water tank.*

## First Use and Rinsing

Before first use, or after a long period of non-use, rinse the machine to ensure optimal hygiene and coffee quality.

1. Ensure the water tank is filled.
2. Place a container (at least 0.5L / 17 fl oz) under the coffee outlet.
3. Close the machine head and lock the lever by turning it left.
4. Press the button three times within two seconds. The button will blink white during the rinsing process.
5. The rinsing cycle will automatically stop. The button will become steady white when ready.

## OPERATING INSTRUCTIONS

### Brewing Coffee or Espresso

1. Ensure the water tank is filled with fresh water.
2. Turn the lever to the right to unlock and open the machine head.
3. Insert a Nespresso Vertuo capsule into the capsule holder. The machine automatically recognizes the capsule type.
4. Close the machine head and lock the lever by turning it left.
5. Place a cup of appropriate size under the coffee outlet.

6. Press the button once. The button will blink white during brewing.
7. The machine will automatically stop when brewing is complete.

# VERTUO

La gamme complète de cafés  
*The full range of coffee styles*



Capacité du réservoir  
à eau amovible  
*Removable water tank  
capacity*

1.1  
litre(s)  
*liter(s)*



Capacité du  
contenant de  
capsules usagées  
*Used capsule container  
capacity*

10

*Image: A hand placing a Nespresso Vertuo capsule into the machine's brewing chamber.*

# DESIGN INTUITIF

## INTUITIVE DESIGN



*Image: The Nespresso Vertuo Next machine actively brewing coffee into a cup, showing the coffee stream and crema.*

### **Brew Sizes**

The Nespresso Vertuo Next machine supports various brew sizes, automatically detected by the capsule's barcode:

- Espresso (1.35 oz)
- Double Espresso (2.7 oz)
- Gran Lungo (5 oz)
- Coffee (8 oz, 12 oz, 18 oz)

# 7 FORMATS VERTUO NEXT

## 7 VERTUO NEXT CUP SIZES



*Image: A visual representation of the different coffee and espresso sizes that can be brewed with the Nespresso Vertuo Next machine.*

### Emptying Used Capsules

After each brew, the used capsule is automatically ejected into the integrated capsule container. Regularly empty this container to prevent overflow.

1. Open the machine head by turning the lever to the right. The used capsule will drop into the container.
2. Pull out the used capsule container from the side of the machine.
3. Dispose of the used capsules.
4. Slide the container back into place.

## MAINTENANCE

### Cleaning the Machine

Regular cleaning ensures optimal performance and coffee quality. Clean the machine with a damp cloth and mild, odorless detergent. Do not immerse the machine in water.

- **Water Tank:** Wash the water tank regularly with warm water and mild detergent. Rinse thoroughly.
- **Drip Tray and Cup Support:** Remove and clean the drip tray and cup support with warm water and mild detergent.

- **Capsule Container:** Empty and clean the used capsule container regularly.

## Descaling

Descaling is crucial for maintaining the machine's lifespan and ensuring consistent coffee quality. The machine will indicate when descaling is needed (refer to the full instruction booklet for specific light indicators).

1. Empty the drip tray and used capsule container.
2. Fill the water tank with 0.5L (17 fl oz) of fresh water and add the Nespresso descaling agent.
3. Place a container (at least 1L / 34 fl oz) under the coffee outlet.
4. Follow the specific descaling procedure outlined in the full instruction booklet. This typically involves pressing and holding the button for a certain duration to enter descaling mode.
5. Rinse the machine thoroughly after descaling by running several cycles with fresh water.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No coffee flow	Water tank empty; machine not primed; descaling needed.	Fill water tank; perform first use rinsing; descale machine.
Coffee is cold	Cup not preheated; machine not heated up.	Rinse machine with hot water before brewing; preheat cup.
Machine is noisy	Normal operation sound; air in system.	This is often normal. If excessive, perform a rinsing cycle to clear air.
Used capsule not ejected	Capsule container full; mechanism jammed.	Empty capsule container; ensure no obstructions.

For more detailed troubleshooting or persistent issues, please refer to the comprehensive instruction booklet or contact Nespresso Customer Support.

## SPECIFICATIONS

- **Brand:** Nespresso
- **Model Name:** Vertuo Next Coffee & Espresso Machine
- **Model Number:** BNV520GRY1BUC1
- **Capacity:** 1.1 Liters (Water Tank)
- **Product Dimensions:** 6"D x 17"W x 12"H
- **Item Weight:** 9.46 Pounds
- **Wattage:** 1500 watts
- **Voltage:** 120V
- **Operation Mode:** Fully Automatic
- **Coffee Input Type:** Nespresso Vertuo Capsules
- **Special Features:** Programmable, Removable Tank, Bluetooth and Wi-Fi Connectivity
- **Material:** Glossy Design Finish

## WARRANTY AND SUPPORT

## Warranty Information

The Nespresso Vertuo Next machine comes with a **1-year warranty** from the date of purchase and registration. Please retain your proof of purchase for warranty claims.

## Customer Support

For personalized advice, technical support, or machine repair, please contact Nespresso through the following channels:

- **Mobile App:** Download the Nespresso mobile app for assistance.
- **Online:** Visit [Nespresso.com](https://www.nespresso.com).
- **Telephone:** Contact Nespresso Customer Service by phone (number available on Nespresso website).
- **Boutiques:** Visit one of our Nespresso Boutiques for in-person support.