

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Sony](#) /

› [Sony PlayStation 4 Pro 1TB Console - Call of Duty: Modern Warfare Bundle Instruction Manual](#)

Sony PlayStation 4 Pro

Sony PlayStation 4 Pro 1TB Console

CALL OF DUTY: MODERN WARFARE BUNDLE INSTRUCTION MANUAL

Introduction

This manual provides essential information for setting up, operating, and maintaining your Sony PlayStation 4 Pro 1TB Console, bundled with Call of Duty: Modern Warfare. The PlayStation 4 Pro offers enhanced gaming experiences with 4K resolution support, HDR technology, and boosted frame rates for compatible games. This renewed product has been professionally inspected and tested to function like new.

Package Contents

Verify that all items listed below are included in your package:

- PlayStation 4 Pro 1TB Console (Jet Black)
- DUALSHOCK 4 Wireless Controller (Jet Black)
- Call of Duty: Modern Warfare Blu-ray Disc
- HDMI Cable
- Power Cable
- USB Charging Cable for DUALSHOCK 4 Controller
- Mono Headset



Image: The PlayStation 4 Pro 1TB console, a DUALSHOCK 4 wireless controller, and the Call of Duty: Modern Warfare game disc are displayed alongside the product's retail packaging.

Setup

1. **Placement:** Place the PS4 Pro console on a flat, stable surface with adequate ventilation. Avoid enclosed spaces.
2. **Connect to TV:** Connect one end of the HDMI cable to the HDMI OUT port on the back of the PS4 Pro and the other end to an HDMI input on your television.
3. **Connect Power:** Plug the power cable into the AC IN connector on the back of the PS4 Pro, then plug the other end into an electrical outlet.
4. **Connect Controller:** Connect the DUALSHOCK 4 wireless controller to the PS4 Pro using the supplied USB cable. This will pair the controller and charge it. Press the PS button on the controller to turn it on.
5. **Initial Setup:** Follow the on-screen instructions to complete the initial setup, including language selection, internet connection, and user account creation or login.

Operating the Console

Powering On/Off

- **To Power On:** Press the power button on the console or the PS button on a paired DUALSHOCK 4 controller.
- **To Power Off:** From the function screen, select *(Power) > Turn Off PS4*. Alternatively, hold the power button on the console for at least 7 seconds until it beeps twice.
- **Rest Mode:** Select *(Power) > Enter Rest Mode*. The console will enter a low-power state, allowing for background downloads and USB charging.

Inserting and Ejecting Discs

- **To Insert:** Hold the disc with the label side facing up and gently slide it into the disc slot until it is pulled in automatically.

- **To Eject:** Select the game icon on the home screen, press the OPTIONS button, and then select *Remove Disc*. Alternatively, press the eject button on the console.

Using the DUALSHOCK 4 Controller

The DUALSHOCK 4 controller features a touchpad, light bar, motion sensors, and built-in speaker. Refer to the on-screen guides for specific game controls. Ensure the controller is charged by connecting it to the PS4 Pro via the USB cable.

Playing Games

Once a game disc is inserted or a digital game is downloaded, select its icon from the home screen to start playing. For Call of Duty: Modern Warfare, ensure the game is fully installed and any necessary updates are applied before playing.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the console and controller. Do not use liquid cleaners or solvents. Keep ventilation ports clear of dust and debris.
- **Software Updates:** Regularly check for and install system software updates to ensure optimal performance and access to new features. Updates can be found under *Settings > System Software Update*.
- **Storage Management:** Monitor your 1TB storage space. Delete unused games or applications to free up space if needed. You can manage storage under *Settings > Storage*.

Troubleshooting

If you encounter issues with your PS4 Pro, try the following common solutions:

- **No Power:** Ensure the power cable is securely connected to both the console and the electrical outlet. Try a different outlet.
- **No Video/Black Screen:** Check that the HDMI cable is firmly connected to both the PS4 Pro and your TV. Try a different HDMI port on your TV or a different HDMI cable. Ensure your TV is set to the correct HDMI input.
- **Controller Not Connecting:** Connect the DUALSHOCK 4 controller to the PS4 Pro with the USB cable and press the PS button to re-pair it. Ensure the controller is charged.
- **Disc Read Errors:** Ensure the game disc is clean and free of scratches. Try ejecting and re-inserting the disc. If the issue persists with multiple discs, the console's disc drive may require service.
- **Internet Connection Issues:** Verify your Wi-Fi password and router settings. Try restarting your router and modem. You can test your internet connection under *Settings > Network > Test Internet Connection*.

For further assistance, refer to the official PlayStation support website or contact customer service.

Specifications

Model Name	PlayStation 4 Pro
Storage Capacity	1TB (1000 GB)
Included Game	Call of Duty: Modern Warfare (Blu-ray Disc)
Included Controller	DUALSHOCK 4 Wireless Controller
Manufacturer	Sony Interactive Entertainment LLC

Product Dimensions	Approximately 1 x 2 x 2 inches
Item Weight	Approximately 11.13 pounds
Video Output	HDMI (4K/HDR support)

Warranty and Support

As a renewed product, this PlayStation 4 Pro console is eligible for replacement or refund under the Amazon Renewed Guarantee. This guarantee typically covers the product for 90 days after receipt if it does not work as expected. For specific terms and conditions, please refer to the Amazon Renewed program details.

For technical support, software updates, and additional resources, visit the official PlayStation support website: playstation.com/support.

© 2026 Sony Interactive Entertainment LLC. All rights reserved. PlayStation and DUALSHOCK are registered trademarks of Sony Interactive Entertainment Inc. Call of Duty: Modern Warfare is a trademark of Activision Publishing, Inc.