

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Havells](#) /

> [Havells Grande Air Fryer Prolife Grande Instruction Manual](#)

Havells Prolife Grande

Havells Grande Air Fryer Instruction Manual

Model: Prolife Grande

1. INTRODUCTION

Welcome to the Havells Grande Air Fryer user manual. This appliance is designed to provide a healthier way to cook your favorite foods, utilizing advanced Aero Crisp Technology for 360-degree air circulation. This manual contains important information regarding the safe operation, maintenance, and troubleshooting of your new air fryer. Please read it thoroughly before first use and keep it for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse the cord, plugs, or the appliance body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other appliances to allow adequate air circulation.
- Never operate the air fryer without the basket properly inserted.
- Do not block any ventilation openings.

- The appliance operates at 1700 Watts and 220-230 Volts. Ensure your power supply matches these specifications.

3. PRODUCT COMPONENTS

Your Havells Grande Air Fryer comes with the following main components:

- **Main Unit:** The primary housing containing the heating element and control panel.
- **6.5 Litre Pan:** The outer pan that holds the food basket.
- **5 Litre Food Basket:** The inner basket where food is placed for air frying.
- **Instruction Manual:** This document.
- **Recipe Book:** A collection of recipes to get you started.



Image: The main unit of the Havells Grande Air Fryer, showcasing its sleek black design and digital touch control panel.

4. SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Cleaning:** Wash the food basket and pan with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the main unit with a damp cloth. Ensure all parts are completely dry before use.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space at the back and sides of the appliance, and 10 cm (4 inches) above it, to allow for proper air circulation.
4. **Initial Preheating (Important):** Before cooking food for the first time, it is recommended to preheat the air fryer twice for 10 minutes each time without any food. This helps to eliminate any manufacturing odors or plastic smells. You may notice a slight odor during this process, which is normal and will dissipate.
5. **Power Connection:** Plug the power cord into a grounded wall outlet.

5. OPERATING INSTRUCTIONS

Digital Touch Control Panel



Image: A close-up view of the Havells Grande Air Fryer's digital touch control panel, showing the various icons for pre-set menus,

temperature, and time adjustments.

The Havells Grande Air Fryer features an intuitive digital touch control panel for easy operation.

1. **Power On/Off:** Press the power icon () to turn the appliance on or off.
2. **Temperature Adjustment:** Use the temperature control icons (+ / - next to °C) to set the desired cooking temperature between 99°C and 200°C.
3. **Time Adjustment:** Use the time control icons (+ / - next to 'min') to set the cooking time up to 60 minutes.
4. **Pre-set Menu Selection:** Press the 'M' button to cycle through the 10 pre-set cooking options. Once a pre-set is selected, the air fryer will automatically set the optimal time and temperature.
5. **Start/Pause:** The appliance will start automatically after setting time/temperature or selecting a pre-set. Press the power icon again to pause cooking.
6. **Auto Shut-off:** The air fryer will automatically shut off after the set cooking time has elapsed or if the basket is removed during operation.

Cooking Process

1. Place the food in the 5-litre food basket. Do not overfill the basket to ensure even cooking.
2. Slide the food basket and pan back into the main unit until it clicks into place.
3. Set the desired temperature and time manually, or select one of the 10 pre-set menus.
4. The air fryer will begin heating. The LED display will indicate the cooking time and temperature.
5. For best results, especially with larger quantities or certain foods, shake the basket halfway through the cooking time. To do this, carefully pull out the pan, shake the basket, and then slide it back in. The appliance will resume cooking automatically.
6. Once the cooking time is complete, the air fryer will beep and automatically shut off.
7. Carefully pull out the pan and remove the food basket. Use heat-resistant tongs to remove cooked food.

PROLIFE
grande
AIR-FRYER 1700 W

**COOK FOOD
WITH 85%
LESS OIL**



Image: The Havells Grande Air Fryer shown alongside a traditional deep fryer, illustrating its ability to cook food with significantly less oil, promoting healthier meals.

6. PRE-SET MENUS

The Havells Grande Air Fryer offers 10 convenient pre-set menus for various food types. These settings provide optimal time and temperature for common dishes.

PROLIFE
grande
AIR-FRYER 1700 W



10 AUTO PRE-SET OPTIONS

Image: A visual representation of the 10 auto pre-set options available on the Havells Grande Air Fryer, with icons for different food categories like fries, chicken, fish, and more.

- **Fries:** Ideal for crispy French fries and potato wedges.
- **Kebabs:** Suitable for various meat or vegetable kebabs.
- **Shrimp:** Perfect for cooking shrimp and other small seafood.
- **Chicken:** For chicken pieces, wings, or small whole chickens.
- **Fish:** Optimized for cooking fish fillets or whole small fish.
- **Vegetables:** For roasting or grilling a variety of vegetables.
- **Pie/Baked Goods:** For small pies, pastries, or other baked items.
- **Sandwiches:** For toasted sandwiches or paninis.
- **Meatballs/Patties:** For cooking meatballs, burgers, or similar items.
- **Roast:** For larger cuts of meat or poultry.

Note: Cooking times and temperatures may vary based on food quantity, size, and desired crispness. Always check food for doneness.

7. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your air fryer.

1. **Unplug and Cool:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Basket and Pan:** The food basket and pan are **not dishwasher safe**. Wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak them in hot water for about 10 minutes.
3. **Interior:** Wipe the interior of the appliance with a damp cloth. For stubborn food residues, use a non-abrasive sponge and mild detergent.
4. **Exterior:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or scouring pads.
5. **Heating Element:** Clean the heating element with a cleaning brush to remove any food residue.
6. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

8. TROUBLESHOOTING

If you encounter any issues with your Havells Grande Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet not working; basket not inserted correctly.	Ensure the power cord is securely plugged into a working outlet. Check if the pan and basket are fully inserted and clicked into place.
Food is not cooked evenly.	Basket is overcrowded; food not shaken/flipped.	Cook food in smaller batches. Shake or flip food halfway through cooking time.
White smoke coming from the appliance.	Grease residue from previous use; fatty food being cooked.	Clean the pan and basket thoroughly after each use. For fatty foods, add a small amount of water to the pan to prevent smoke.
Food is not crispy.	Too much moisture in food; not enough oil (if desired); incorrect temperature/time.	Pat food dry before cooking. Lightly brush or spray with oil for extra crispness. Adjust temperature or extend cooking time.

9. SPECIFICATIONS

Technical specifications for the Havells Grande Air Fryer:

- **Model Name:** Prolife Grande
- **Capacity:** 6.5 Litres (Pan), 5 Litres (Food Basket)
- **Power:** 1700 Watts
- **Operating Voltage:** 220 - 230 Volts
- **Temperature Control:** 99°C to 200°C
- **Timer:** Up to 60 minutes with auto shut-off
- **Control Method:** Digital Touch Control
- **Air Frying Technology:** Aero Crisp Technology (360° Air Circulation)
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Colour:** Black
- **Product Dimensions:** 38D x 38W x 43H Centimeters

- **Item Weight:** 6.7 kg
- **Non-stick Coating:** Yes
- **Dishwasher Safe:** No (Basket and Pan)



Image: A side view of the Havells Grande Air Fryer with its dimensions (38cm D x 38cm W x 43cm H) clearly marked.

10. WARRANTY AND SUPPORT

Your Havells Grande Air Fryer comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use. Please retain your purchase receipt as proof of purchase. For warranty claims, technical assistance, or any product-related inquiries, please contact Havells customer support. Refer to the contact information provided in your warranty card or visit the official Havells website for the latest support details.

Manufacturer: HAVELLS INDIA LIMITED

Address: Havells India Ltd. QRG Tower 2D Sector- 126 Expressway Noida 201304 (U.P)

11. PRODUCT VIDEO OVERVIEW

Your browser does not support the video tag.

Video: An official product overview video showcasing the key features and benefits of the Havells Grande Air Fryer, including its Aero Crisp Technology and digital control panel.

