

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [besrey](#) /

› [besrey 5 in 1 Toddler Bike Instruction Manual](#)

besrey BR-C7276

besrey 5 in 1 Toddler Bike Instruction Manual

Model: **BR-C7276** | Brand: **besrey**

1. INTRODUCTION AND OVERVIEW

The besrey 5 in 1 Toddler Bike is a versatile and adaptable ride-on toy designed to grow with your child from 10 months up to 4 years old. Its innovative design allows for easy transformation between multiple modes, supporting different stages of development from walking to balancing and pedaling.

This upgraded kids' tricycle features an enlarged body size to accommodate a wider age range, ensuring long-term usability. It helps children quickly learn to ride by providing a stable and safe platform for balance training and motor skill development.

Multi-use



Balance Bike

Baby Walker



Tricycle



Cycling and Sliding Mode



Balance Training



Triangular Design Stability

Figure 1: The besrey 5 in 1 Toddler Bike demonstrating its multi-use capabilities including Balance Bike, Baby Walker, and Tricycle modes.

2. SAFETY INFORMATION

WARNING: Use under adult supervision. Always ensure your child wears appropriate safety gear, including a helmet, when operating the bike in any mode.

- Regularly inspect all parts for wear and tear, especially wheels, pedals, and adjustable mechanisms.
- Ensure all locking mechanisms are securely engaged before each use.
- Do not use on public roads, near motor vehicles, or on steep inclines.
- Keep away from water, fire, and extreme temperatures.
- The bike features a limited 70° steering angle to prevent rollover. Do not attempt to force the handlebars beyond this limit.

- Maximum bearing weight: 25 kg (55 lbs).

Prevent Roll Over

Stable Carbon Steel Triangular Design
& Safety Limited 70° Steering



Figure 2: Stable Carbon Steel Triangular Design and Safety Limited 70° Steering for enhanced child safety.

3. SETUP AND ASSEMBLY

The besrey 5 in 1 Toddler Bike features a simple structure for quick and easy assembly. Refer to the included

manual for detailed step-by-step instructions. Typically, assembly can be completed within a few minutes.

Key Assembly Steps:

1. Unpack all components and verify against the parts list in the manual.
2. Attach the front wheel and handlebar assembly to the main frame.
3. Secure the seat to the frame, ensuring it is at an appropriate height for the child's current mode of use.
4. Attach or detach pedals as required for the desired operating mode.
5. Adjust the rear wheels for tricycle or balance bike configuration.



Figure 3: Quick assembly of the tricycle with a modular design, allowing for easy setup.

4. OPERATING MODES

The besrey 5 in 1 Toddler Bike offers five distinct modes to support your child's development:

- Tricycle without Pedals (Learn to Walk - Stage 1):** In this mode, the pedals are removed, and the rear wheels are in the wide tricycle position. This allows very young children (approx. 10-24 months) to push off the ground with their feet, developing balance and coordination before introducing pedals.
- Baby Walker without Pedals (Learn to Walk - Stage 2):** Similar to Stage 1, but the rear wheels can be adjusted closer together to provide a narrower base, encouraging more independent balance while still offering stability.
- Tricycle with Pedals (Learn to Ride):** Attach the pedals to the front wheel. The rear wheels remain in the wide tricycle position, providing stability as your child learns to pedal and steer. This mode is ideal for building leg strength and understanding pedaling motion.
- Baby Walker with Pedals (Learn to Ride - Stage 2):** With pedals attached, the rear wheels are adjusted closer together. This configuration challenges the child to maintain more balance while pedaling, preparing them for a two-wheeled bike.
- Balance Bike without Pedals (For Sliding):** Remove the pedals and adjust the rear wheels to their closest position, effectively creating a two-wheeled balance bike. This mode is crucial for developing advanced balance skills, allowing children to glide and steer using their feet.



Figure 4: Visual representation of the Sliding Trike (10m-2yrs), Pedal Trike (2yrs-3yrs), and Balance Bike (3yrs-4yrs) modes.

Video 1: Official besrey video demonstrating the 5-in-1 Toddler Bike in various modes, including tricycle and balance bike, for children aged 1-3 years. This video highlights the versatility and ease of transformation.

5. ADJUSTMENTS

The besrey 5 in 1 Toddler Bike is designed for easy adjustments to adapt to your child's growth and skill level:

- Seat Height:** The soft, ergonomically designed saddle can be adjusted up or down to ensure your child's feet can comfortably reach the ground in pedal-less modes or pedals in tricycle modes. This adjustment is crucial for proper posture and control.
- Handlebar Angle:** The handlebar angle can be adjusted to provide a comfortable and controlled grip for your child, suitable for different arm lengths and riding styles.
- Rear Wheel Configuration:** The rear wheels can be quickly adjusted between a wide tricycle stance for maximum stability and a narrow, closer stance for balance bike or advanced walker modes. This "one-click deformation" allows for seamless transitions.
- Removable Pedals:** The quick-disassembly pedal system allows for easy attachment and removal of pedals, enabling a smooth switch between pedaling and balance training modes. The pedals can be stored conveniently on the bike when not in use.

Adjustable

Seat Height & Handlebar Angle

Suitable for kids of
different heights and ages



Figure 5: Adjustable seat height and handlebar angle suitable for kids of different heights and ages.

6. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your besrey 5 in 1 Toddler Bike:

- **Cleaning:** Wipe down the frame and wheels with a damp cloth. Avoid harsh chemicals that may damage the finish or materials.
- **Lubrication:** Periodically apply a small amount of lubricant to moving parts such as wheel axles and pedal mechanisms to ensure smooth operation.
- **Fasteners:** Check all screws, bolts, and quick-release levers regularly to ensure they are tight and secure. Tighten as needed.
- **Wheels:** The durable EVE foam wheels are designed for various terrains. Inspect them for any damage or excessive wear.
- **Storage:** Store the bike in a dry, cool place away from direct sunlight and extreme temperatures to prevent

material degradation.



Figure 6: Durable EVE foam wheels designed to conquer various terrains.

7. TROUBLESHOOTING

If you encounter any issues with your besrey 5 in 1 Toddler Bike, please refer to the following common solutions:

Problem	Possible Cause	Solution
Difficulty assembling / parts not aligning	Incorrect orientation of parts; manufacturing tolerance.	Review the assembly manual carefully. Ensure parts are oriented correctly. Apply gentle pressure or slightly adjust alignment. If issues persist, contact customer support.

Problem	Possible Cause	Solution
Wheels not rolling smoothly	Debris in axles; loose wheel fasteners; worn bearings.	Clean around the wheel axles. Ensure wheel fasteners are secure but not overtightened. If bearings are worn, contact customer support for replacement parts.
Pedals difficult to attach/detach	Misalignment; debris in the slot.	Ensure the pedal mechanism is clean and free of obstructions. Align the pedal correctly with the slot and apply firm, even pressure.
Bike feels unstable	Loose connections; incorrect mode configuration.	Check all fasteners and ensure they are tight. Verify that the rear wheels are correctly locked into the desired wide or narrow position. Ensure the child's height is appropriate for the seat setting.

For further assistance, please refer to the official besrey customer support channels.

8. SPECIFICATIONS

- **Model:** BR-C7276
- **Brand:** besrey
- **Material:** Alloy Steel
- **Color:** Black (as per current product variant)
- **Item Weight:** 7.3 Pounds (approx. 3.3 kg)
- **Item Dimensions (LxWxH):** 23.62 x 17.72 x 18.11 inches (approx. 60 x 45 x 46 cm)
- **Recommended Age:** 10 months to 4 years old
- **Max Bearing Weight:** 25 kg (55 lbs)
- **Steering Limit:** 70° (anti-rollover design)
- **Wheels:** Durable EVE foam wheels



Figure 7: The besrey 5 in 1 Toddler Bike in its black color variant.


9. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please visit the official besrey website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

Online Resources:

- Official besrey Store: [Visit the besrey Store on Amazon](#)
- User Manual (PDF): [Download User Manual](#)

Related Documents - BR-C7276

 <p>BR-C727S Foldable Children Tricycle</p> <p>• Please read this manual carefully before using the product. In order to avoid the safety problem, please use this tricycle in correct way according to this manual. • Product must be assembled by adult before use.</p>	<p><u>Besrey BR-C727S Foldable Children Tricycle User Manual</u></p> <p>Comprehensive user manual for the Besrey BR-C727S Foldable Children Tricycle, covering assembly, usage, maintenance, and safety warnings in multiple languages.</p>
 <p>BR-C727S Foldable Children Tricycle</p> <p>• Please read this manual carefully before using the product. In order to avoid the safety problem, please use this tricycle in correct way according to this manual. • Toy is to be assembled by an adult. It contains potentially hazardous small parts. If the toy is not assembled in a safe state, please keep out of reach of children.</p>	<p><u>Besrey BR-C727S Foldable Children Tricycle User Manual</u></p> <p>This manual provides instructions for assembling, using, and maintaining the Besrey BR-C727S Foldable Children Tricycle. It includes safety warnings, component descriptions, and step-by-step assembly guides.</p>
 <p>Toddler Tricycle User Manual BR-C718S</p> <p>⚠ WARNING • Please read this instruction carefully before using. Correct assembly and operation procedures are vital to avoid causing any damage to the product. • Toy is to be assembled by an adult. It contains potentially hazardous small parts. If the toy is not assembled in a safe state, please keep out of reach of children.</p>	<p><u>Besrey BR-C718S Toddler Tricycle User Manual</u></p> <p>User manual for the Besrey BR-C718S Toddler Tricycle, providing assembly instructions, safety warnings, and usage guidelines.</p>
 <p>Foldable Children Tricycle User Manual BR-C727S</p> <p>⚠ WARNING • Please read this manual carefully before using the product. • In order to avoid the safety problem, please use this tricycle in correct way according to this manual. • Toy is to be assembled by an adult. It contains potentially hazardous small parts. If the toy is not assembled in a safe state, please keep out of reach of children.</p>	<p><u>Besrey BR-C727S Foldable Children Tricycle User Manual</u></p> <p>User manual for the Besrey BR-C727S Foldable Children Tricycle, including assembly instructions, safety warnings, and care guidelines.</p>
 <p>BR-C727S Foldable Children Tricycle</p> <p>• Please read this manual carefully before using the product. In order to avoid the safety problem, please use this tricycle in correct way according to this manual.</p>	<p><u>besrey BR-C727S Foldable Children Tricycle User Manual</u></p> <p>User manual for the besrey BR-C727S Foldable Children Tricycle, providing assembly instructions, safety warnings, and maintenance guidelines.</p>
 <p>BR-C727S Foldable Children Tricycle</p> <p>• Please read this manual carefully before using the product. In order to avoid the safety problem, please use this tricycle in correct way according to this manual.</p>	<p><u>besrey BR-C727S Foldable Children Tricycle User Manual</u></p> <p>Comprehensive user manual for the besrey BR-C727S Foldable Children Tricycle, including assembly instructions, safety warnings, and maintenance guidelines.</p>

