

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [La Crosse Technology](#) /

› [La Crosse Technology CA80994 Color Mood Light Alarm Clock with Melody Sounds User Manual](#)

## La Crosse Technology CA80994

# La Crosse Technology CA80994 Color Mood Light Alarm Clock with Melody Sounds User Manual

Model: CA80994

## INTRODUCTION

---

This manual provides detailed instructions for the setup, operation, and maintenance of your La Crosse Technology CA80994 Color Mood Light Alarm Clock. This device combines an alarm clock with a versatile mood light, offering various color options and melody sounds to enhance your daily routine. Please read this manual thoroughly before using the product to ensure proper function and longevity.

## PACKAGE CONTENTS

---

Upon unpacking, please verify that all items listed below are present and in good condition:

- La Crosse Technology CA80994 Color Mood Light Alarm Clock
- Power Adapter
- User Manual (this document)



This image displays the La Crosse Technology CA80994 Color Mood Light Alarm Clock and its power adapter, still sealed in their protective plastic within the product's cardboard packaging. The clock features a circular design with control buttons visible at the bottom.

## SETUP

- Unpacking:** Carefully remove the alarm clock and all accessories from the packaging. Retain the packaging for future storage or transport.
- Power Connection:** Insert the small end of the power adapter into the DC IN port located on the back of the alarm clock. Plug the other end of the power adapter into a standard electrical outlet. The clock display should illuminate.
- Battery Installation (Optional for backup):** If your model supports battery backup, insert the required batteries (e.g., 2 x AAA, not included) following the polarity indicators in the battery compartment on the underside. This will preserve time settings during a power outage.
- Initial Time Setting:**
  - Press and hold the "SET" button (or similar button, refer to device markings) for 3 seconds to enter time setting mode.
  - Use the "+" or "-" buttons to adjust the hour. Press "SET" to confirm.
  - Use the "+" or "-" buttons to adjust the minute. Press "SET" to confirm.
  - Continue to set the year, month, and day if applicable, confirming each with the "SET" button.

## OPERATING INSTRUCTIONS

### Setting the Alarm

- Press and hold the "ALARM" button (or similar icon) for 3 seconds to enter alarm setting mode.
- Use the "+" or "-" buttons to adjust the desired alarm hour. Press "ALARM" to confirm.

3. Use the "+" or "-" buttons to adjust the desired alarm minute. Press "ALARM" to confirm.
4. Select your preferred alarm melody sound using the "+" or "-" buttons. Press "ALARM" to confirm.
5. To activate or deactivate the alarm, press the "ALARM" button once. An alarm icon will appear or disappear on the display.

## Using the Mood Light

1. **Turning On/Off:** Press the "LIGHT" button (often represented by a light bulb icon) to turn the mood light on or off.
2. **Changing Light Modes:** While the light is on, press the "LIGHT" button repeatedly to cycle through the available light modes:
  - Solid Color Mode (20 unique color options)
  - Vibrant Color Gradient Mode
  - Color Cycle Mode (automatically transitions through all colors)
3. **Adjusting Brightness:** Use the "Brightness" button (often represented by a sun icon) or the "+" and "-" buttons when in light mode to adjust the intensity of the light.

## Snooze Function

When the alarm sounds, press the "SNOOZE" button (often marked with "Zz" or a large button on top) to temporarily silence the alarm. The alarm will sound again after a preset snooze interval (typically 5-10 minutes). To turn off the alarm completely, press any other button or allow it to sound for its full duration.

## Adjusting Display Brightness

Press the "DIMMER" button (or similar) to cycle through different display brightness levels (e.g., High, Medium, Low, Off). This allows you to adjust the display's visibility to your preference, especially in a dark room.

## MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the surface of the alarm clock. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- **Power Disconnection:** If the device will not be used for an extended period, disconnect the power adapter from the wall outlet.
- **Battery Replacement:** If using battery backup, replace batteries annually or when the display shows signs of dimming during a power outage.

## TROUBLESHOOTING

---

Problem	Possible Solution
<b>No display or power.</b>	Ensure the power adapter is securely plugged into both the alarm clock and a working electrical outlet. Check the outlet with another device.
<b>Alarm does not sound.</b>	Verify that the alarm is activated (alarm icon visible on display). Check that the alarm volume is not set to zero. Ensure the alarm time is correctly set.
<b>Mood light not working.</b>	Press the "LIGHT" button to ensure it is turned on. If the light is on but not changing colors, try cycling through the light modes again.
<b>Incorrect time display.</b>	Reset the time according to the "Initial Time Setting" instructions in the Setup section. If using battery backup, ensure batteries are fresh.

## SPECIFICATIONS

---

- **Model:** CA80994
- **Brand:** La Crosse Technology
- **Special Features:** Alarm, Color Mood Light, Melody Sounds
- **Power:** AC Adapter (included), Battery Backup (type and quantity not specified, typically AAA or AA)
- **Item Weight:** 650 g
- **Parcel Dimensions:** 24.2 x 20 x 8.8 cm
- **Date First Available:** March 12, 2020

*Note: Specifications are subject to change without notice.*

## WARRANTY AND SUPPORT

---

La Crosse Technology products are designed to provide reliable performance. For specific warranty information, please refer to the warranty card included with your product or visit the official La Crosse Technology website. For technical support or service inquiries, please contact La Crosse Technology customer service through their official channels.

**Website:** [www.lacrossetechnology.com](http://www.lacrossetechnology.com)