

- Manuals.plus /
- › SmartGames /
- › SmartGames Puzzle Beach Magnetic Puzzle Game Instruction Manual

SmartGames SGT300

SmartGames Puzzle Beach Magnetic Puzzle Game

Official Instruction Manual

INTRODUCTION

Welcome to the world of SmartGames Puzzle Beach! This magnetic puzzle game is designed to challenge your cognitive skills with 48 multi-level challenges. It's a compact and portable game, perfect for travel and on-the-go fun. The objective is to place all magnetic puzzle pieces on the game board so that only the objects and characters shown in the challenge are visible.



Image: The SmartGames Puzzle Beach game box, featuring colorful beach illustrations and game details.

COMPONENTS

Your SmartGames Puzzle Beach package includes the following components:

- **Booklet:** Contains the magnetic grid, 48 challenges, and their solutions.
- **5 Magnetic Puzzle Pieces:** Uniquely shaped pieces with various beach-themed images.



Image: An open view of the SmartGames Puzzle Beach booklet showing challenge pages and the five magnetic puzzle pieces laid out.

SETUP

1. **Open the Booklet:** Unfold the game booklet to reveal the magnetic game board on one side and the challenge pages on the other.
2. **Select a Challenge:** Choose one of the 48 challenges from the booklet. Challenges are numbered and increase in difficulty.
3. **Identify Visible Elements:** Each challenge shows a specific set of beach-themed objects and characters that must remain visible on the game board.



OPERATING (GAMEPLAY)

The goal of SmartGames Puzzle Beach is to cover all elements on the magnetic game board except for those specified in the chosen challenge. Each challenge has only one correct solution.

Gameplay Steps:

1. **Analyze the Challenge:** Look at the challenge image to see which characters and objects should be visible.
2. **Place Puzzle Pieces:** Strategically place the 5 magnetic puzzle pieces onto the game board. The pieces are designed to cover certain areas.
3. **Cover Unwanted Elements:** Ensure that all elements not shown in the challenge are covered by the puzzle pieces.
4. **Verify Solution:** Once all pieces are placed, check if only the required elements are visible. If so, you have solved the challenge!

Challenge Levels:

The challenges are categorized by difficulty:

- **Starter:** Challenges 1-12
- **Junior:** Challenges 13-24
- **Expert:** Challenges 25-36
- **Master:** Challenges 37-48

Solutions for all challenges are provided at the back of the booklet.



Image: A child's hand holding one of the magnetic puzzle pieces, showing its intricate design and beach-themed elements.

MAINTENANCE

To ensure the longevity of your SmartGames Puzzle Beach game, please follow these maintenance guidelines:

- **Cleaning:** Wipe the magnetic pieces and booklet with a soft, dry cloth. Avoid using abrasive cleaners or excessive moisture.
- **Storage:** Store the game in its original packaging or a similar protective case to prevent loss of pieces and damage to the booklet. Keep it away from extreme temperatures and direct sunlight.
- **Handling:** Handle the magnetic pieces and booklet gently to avoid bending or creasing, which could affect their magnetic properties or appearance.

TROUBLESHOOTING

If you encounter any issues while playing SmartGames Puzzle Beach, consider the following common solutions:

Problem	Solution
Cannot solve a challenge.	Double-check the challenge requirements. Ensure all non-required elements are covered. Refer to the solution section at the back of the booklet if needed.
Magnetic pieces do not stick well.	Ensure the game board and pieces are clean and dry. Avoid storing the game near strong magnetic fields or in very high temperatures.
Missing a puzzle piece.	Carefully check all compartments of the game and its packaging. If a piece is genuinely missing, contact SmartGames customer support.

SPECIFICATIONS

Product Model: SGT300

ASIN: B085W9S34J

Manufacturer: SmartGames

Recommended Age: 6 years and up

Number of Challenges: 48

Number of Players: 1

Product Dimensions: 2.2 x 0.89 x 0.04 inches (5.59 x 2.26 x 0.1 cm)

Item Weight: 3.53 ounces (100 grams)




Image: A visual representation of the SmartGames Puzzle Beach game's dimensions, showing it is approximately 16 cm tall.

SUPPORT

For further assistance, questions, or to report missing parts, please contact SmartGames customer support. You can often find contact information on the SmartGames official website or through the retailer where you purchased the product. Visit the official SmartGames website for more information and other products: www.smartgames.eu

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B085W9S34J>

More documents and user manuals: <https://manuals.plus/>