

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Oreck](#) /

› [Oreck HEPA Swivel Upright Vacuum Cleaner \(Model UK30305PC\) - Instruction Manual](#)

Oreck UK30305PC

Oreck HEPA Swivel Upright Vacuum Cleaner (Model UK30305PC) - Instruction Manual

MODEL: UK30305PC

Introduction

The Oreck HEPA Swivel Upright Vacuum combines low-profile convenience, powerful performance, and advanced filtration for a seamless cleaning experience. Its two-speed controllable brush roll provides effective cleaning on carpets, hardwood, tile, and more, while the ultra-lightweight, low-profile design makes it easy to carry throughout your home. Swivel steering provides the maneuverability to clean anywhere. Equipped with a HEPA Media filter, this powerful upright vacuum captures 99.97% of pet dander and particles as small as 0.3 microns, paired with SaniSeal bags to help lock in dirt during disposal. With a bag capacity that holds up to 4X more debris than standard bagless vacuums, the Oreck HEPA Swivel reduces the need for frequent emptying, making it a convenient and reliable solution for whole-home cleaning.

Important Safety Information

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury. Keep this manual for future reference.

- Always unplug the vacuum cleaner from the electrical outlet before cleaning or servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.

- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bag and/or filters in place.

Package Contents

Verify that all items are included in your package:

- Oreck HEPA Swivel Upright Vacuum Base
- Upper Handle Assembly
- Dust Bag Cover Assembly
- SaniSeal HEPA Media Bags (8 included to start)
- Power Cord
- Instruction Manual & Quick Start Guide

Assembly Instructions

Follow these steps to assemble your Oreck HEPA Swivel Upright Vacuum Cleaner:

1. **Attach Upper Handle:** Insert the upper handle assembly into the top of the dust bag cover assembly until it locks securely into place.
2. **Connect Bag Assembly to Base:** Slide the combined handle and bag assembly onto the vacuum base. Ensure it slides down fully and aligns with the connection point on the base.
3. **Secure Connection:** Once in place, lock the assembly to the base using the designated latch.
4. **Manage Power Cord:** Wrap the power cord around the cord hooks on the side of the vacuum for neat storage.

Video: Oreck HEPA Swivel Bagged Vacuum Cleaner UK30305PC Assembly Guide. This video demonstrates the step-by-step assembly process of the vacuum cleaner, including attaching the handle and bag assembly to the base, and securing the power cord.

Operating Instructions

Your Oreck HEPA Swivel Upright Vacuum Cleaner is designed for efficient cleaning across various floor types.

1. **Power On/Off:** Plug the power cord into a suitable electrical outlet. The power switch is conveniently located on the handle. Push it once for low speed (ideal for hard floors) and twice for high speed (for carpets).
2. **Floor Type Selection:** The two-speed controllable brush roll allows you to optimize cleaning for different surfaces. Use the low speed for delicate hard floors and the high speed for effective carpet cleaning.
3. **Swivel Steering:** Utilize the swivel steering for enhanced maneuverability around furniture and obstacles.
4. **Low-Profile Cleaning:** The vacuum's low-profile design enables it to reach under most furniture, ensuring thorough cleaning in hard-to-reach areas.
5. **LED Headlights:** The integrated LED headlights illuminate your cleaning path, making dirt and debris more visible, especially in dimly lit areas.



Image: A person using the Oreck HEPA Swivel Upright Vacuum Cleaner on a light-colored carpet in a living room, demonstrating its ease of use.



Image: A close-up view of the vacuum head on a carpet, highlighting the LED lights that illuminate the cleaning area.



Image: The Oreck HEPA Swivel Upright Vacuum Cleaner positioned to clean under a bed, illustrating its ability to reach low spaces.

Maintenance

Regular maintenance ensures optimal performance and longevity of your vacuum cleaner.

- Replacing SaniSeal Bags:** The vacuum uses SaniSeal bags that hold up to 4X more debris than standard bagless vacuums. When the bag is full, simply unlatch the bag cover, remove the full bag, and replace it with a new SaniSeal bag. The SaniSeal feature helps to lock in dirt and dust during disposal, minimizing airborne allergens.
- HEPA Media Filter:** The vacuum is equipped with a HEPA Media filter. Refer to the included manual for specific instructions on checking and replacing the filter to maintain optimal filtration efficiency.
- Cleaning the Brush Roll:** Periodically check the brush roll for tangled hair or debris. The brush roll can be accessed by removing screws on the base plate. Carefully cut away any tangled hair or threads to ensure the brush roll spins freely.



Image: A close-up of hands replacing a SaniSeal bag in the Oreck HEPA Swivel Upright Vacuum Cleaner, highlighting the easy replacement process.

Troubleshooting

If you encounter any issues with your Oreck HEPA Swivel Upright Vacuum Cleaner, refer to the following common solutions:

- **No Power:** Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker if necessary.
- **Loss of Suction:** Check if the SaniSeal bag is full and needs replacement. Inspect the hose and nozzle for any clogs or obstructions. Ensure the HEPA Media filter is clean and properly installed.
- **Brush Roll Not Rotating:** Unplug the vacuum and check the brush roll for tangled hair or debris. Clear any obstructions. Ensure the brush roll is properly seated.
- **Unusual Noise:** Unplug the vacuum and inspect the brush roll and internal components for any foreign objects or damage.

For further assistance, please contact Oreck Customer Support.

Specifications

Brand	Oreck
Model Number	UK30305PC
Special Feature	HEPA Media Filtration, Swivel Steering
Filter Type	HEPA Filter
Included Components	Brush, HEPA Filter
Is Cordless?	No
Capacity	10 Pounds (debris capacity)
Wattage	600 watts
Form Factor	Upright
Color	Blue
Noise Level	80 Decibels
Number of Speeds	2
Product Dimensions	15.75 x 15.75 x 39.5 inches
Item Weight	10 pounds
UPC	743808958523

Warranty & Support

Oreck products come with a guaranteed warranty when purchased from authorized sellers. To ensure your product is authentic and covered by the manufacturer's warranty, always purchase from authorized retailers such as Amazon.com, Floorcare Direct, or Galaxy Vacuum.

Video: Oreck Buy With Confidence. This video provides information on purchasing authentic Oreck products and understanding warranty coverage from authorized sellers.

For customer support, product registration, or warranty claims, please visit the official Oreck website or contact their customer service line. Refer to the contact information provided in your product packaging or on the Oreck website.