

## ICQN OT-100038001

# ICQN Universal Oven Rack Instruction Manual

Model: OT-100038001

[Introduction](#)

[Safety Information](#)

[Setup](#)

[Operating  
Instructions](#)

[Care and  
Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

## 1. INTRODUCTION

This manual provides essential information for the safe and effective use of your ICQN Universal Oven Rack. Please read these instructions carefully before first use and retain them for future reference.

The ICQN Universal Oven Rack is designed to be a versatile accessory for your oven, suitable for various baking and cooking needs. It is constructed from chrome-plated material, offering durability and heat resistance up to 600°C (1112°F).



Figure 1: The ICQN Universal Oven Rack, a chrome-plated wire grid designed for oven use.

## 2. SAFETY INFORMATION


- Always use oven mitts or heat-resistant gloves when handling the oven rack, especially when it is hot.
- Ensure the oven rack is properly seated on the oven's rack supports before placing items on it.
- Do not overload the oven rack. Distribute weight evenly to prevent tipping.
- Keep children and pets away from a hot oven and hot oven racks.
- Avoid sudden temperature changes, such as placing a hot rack directly into cold water, as this may cause warping or damage.

- This oven rack is designed for use inside an oven. Do not use it over an open flame or on a stovetop.

### 3. SETUP AND INSTALLATION

---

The ICQN Universal Oven Rack is designed for easy placement within your oven. Before installation, it is crucial to verify compatibility with your specific oven model by checking the dimensions.



#### **ACHTUNG!**

Backbleche variieren je nach Modell. Bitte vor der Bestellung Maße prüfen oder uns kontaktieren – wir helfen gern.

Figure 2: Dimensions of the ICQN Universal Oven Rack (465mm x 375mm).

1. **Measure Your Oven:** Before first use, measure the interior width and depth of your oven to ensure the rack (465 mm x 375 mm) will fit correctly.
2. **Initial Cleaning:** Wash the oven rack with warm, soapy water and rinse thoroughly before its first use to remove any manufacturing residues. Dry completely.
3. **Placement:** Slide the oven rack onto the desired rack supports inside your oven. Ensure it is level and securely seated.

#### **Important Compatibility Note:**

While this rack is universal, it is specifically designed to be compatible with various models from Bosch, Neff, Constructa, Beko, Samsung, and Teka. It is *not suitable* for all Bosch/Siemens/Neff/Constructa/Balay/Pitsos cookers. Always verify dimensions against your oven's requirements. Refer to the "Specifications" section for a list of compatible model numbers.

### 4. OPERATING INSTRUCTIONS

---

The ICQN Universal Oven Rack functions as a standard oven rack, providing a stable surface for baking, roasting, and

cooling.



Figure 3: The oven rack supporting a pizza during baking.

- **Baking and Roasting:** Place your bakeware, roasting pans, or other oven-safe dishes directly onto the rack. Ensure there is adequate space for air circulation around the items.
- **Cooling:** The rack can also be used outside the oven as a cooling rack for baked goods, allowing air to circulate underneath for even cooling.
- **Temperature Resistance:** The rack is resistant to temperatures up to 600°C (1112°F), making it suitable for most standard oven temperatures.

## 5. CARE AND MAINTENANCE

Proper care will extend the life of your ICQN Universal Oven Rack.

- **Cleaning:** The oven rack is dishwasher safe for convenient cleaning. For hand washing, use warm water and a mild dish soap. A non-abrasive sponge or brush can be used to remove stubborn food residues.
- **Drying:** Ensure the rack is thoroughly dry before storing to prevent water spots or potential corrosion.
- **Storage:** Store the rack in a dry place when not in use.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Rack does not fit in oven.	Incorrect dimensions for your oven model.	Verify your oven's internal dimensions against the rack's dimensions (465 mm x 375 mm). This rack is not universally compatible with all oven brands/models.
Food residue stuck on rack.	Baked-on food or insufficient cleaning.	Soak the rack in warm, soapy water before cleaning. Use a non-abrasive brush or place in a dishwasher.
Rack appears discolored or tarnished.	Exposure to high heat over time or certain food acids.	This is normal wear and tear for chrome-plated items. Ensure regular cleaning. If severe, consider replacement.

## 7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	ICQN
Model Number	OT-100038001
Material	Chrome plated
Color	Stainless Steel appearance
Product Dimensions (L x W x H)	465 mm x 375 mm (18.31"D x 14.57"H)
Wire Spacing	2.1 cm (0.82 inch)
Heat Resistance	Up to 600°C (1112°F)
Dishwasher Safe	Yes
Item Weight	2.11 Pounds
Compatible Models (Examples)	Bosch, Neff, Constructa, Beko, Samsung, Teka. Specific compatible model numbers include: 00435847, 00574912, 00434175, 00574876, 00574909, 00662999, 00742283, 00742635, 00675876, 00438155, 00574910, 00434176, 00434178, 219440101, 332000, 434175, 434176, 434178, 438822, 435847, 574912, 574909, 574876, 675876, 662999, 742635, 742283, 82405901, 83115003, BF3ON3T11P, Z1432X3, 5Z1343X1, Z1232X0, Z1232X3, CZ1247X0, CCZ1247X000, FQ115T002, HI435ME, HE720ME, HZ332070, HEZ331072, HEZ331070, HB9TI50GB10.

## 8. WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support for your ICQN Universal Oven Rack, please refer to the product packaging or contact the retailer from whom you purchased the product. You may also visit the official ICQN website for further assistance.

For general inquiries, please contact customer service at your point of purchase.

