

[Manuals.plus](#) /

› [KitchenAid](#) /

› KitchenAid ARTISAN 5KEK1522EPT 1.5L Electric Kettle User Manual

KitchenAid 5KEK1522EPT

KitchenAid ARTISAN 5KEK1522EPT 1.5L Electric Kettle User Manual

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your KitchenAid ARTISAN 5KEK1522EPT 1.5L Electric Kettle. Please read all instructions carefully before first use and retain for future reference.

The KitchenAid ARTISAN kettle is designed for heating water to various temperatures, offering precision for different beverage preparations. Its robust construction and intuitive controls ensure reliable performance.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the kettle.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the heating cycle.

- Ensure the lid is securely closed before operating.

3. PARTS AND FEATURES

Familiarize yourself with the components of your KitchenAid ARTISAN Electric Kettle.



Figure 3.1: Front view of the kettle, displaying the temperature gauge and the temperature selection lever on the base.

- **Lid:** Removable lid for easy filling and cleaning.
- **Handle:** Ergonomically designed for comfortable pouring.
- **Spout:** Designed for controlled pouring.
- **Water Level Window:** Indicates the current water level.
- **Temperature Gauge:** Displays the current water temperature.
- **Power Base:** Cordless base with 360-degree rotation.
- **Temperature Selector:** Lever on the base to choose desired water temperature (50-100°C).
- **On/Off Switch:** Located on the base for activating the heating element.



Figure 3.2: The kettle detached from its power base, illustrating the cordless design and central connector.

4. SETUP

4.1 Unpacking

1. Remove all packaging materials and promotional labels from the kettle and its base.
2. Ensure all parts are present and undamaged.

4.2 First Use Cleaning

Before using your kettle for the first time, or if it has been unused for a long period, it is recommended to clean it.

1. Fill the kettle with fresh water to the maximum fill line.
2. Boil the water (see Operating Instructions).
3. Discard the boiled water.
4. Repeat this process two to three times to ensure thorough cleaning.

4.3 Positioning the Kettle

1. Place the power base on a flat, stable, heat-resistant, and dry surface.
2. Ensure the power cord is not dangling or in contact with hot surfaces.
3. Place the kettle securely onto the power base.

5. OPERATING INSTRUCTIONS

5.1 Filling the Kettle

1. Remove the kettle from its power base.
2. Press the lid release button to open the lid.
3. Fill the kettle with fresh water to the desired level, observing the minimum and maximum fill lines. Do not overfill.
4. Close the lid securely until it clicks into place.
5. Place the kettle back onto its power base.

5.2 Selecting Temperature and Boiling Water

1. Plug the power base into a grounded electrical outlet.
2. Use the temperature selector lever on the base to choose your desired water temperature (e.g., 50°C, 60°C, 70°C, 80°C, 90°C, 95°C, 100°C).
3. Press the On/Off switch on the base to start the heating process. The indicator light will illuminate.
4. The kettle will automatically shut off once the selected temperature is reached. The indicator light will turn off.
5. The temperature gauge on the kettle will display the current water temperature during heating and cooling.



Figure 5.1: Demonstrating the pouring action of the kettle after water has been heated.

5.3 Pouring Water

Carefully lift the kettle from its base and pour the hot water. Always pour slowly and steadily to avoid splashing. Be mindful of steam escaping from the spout.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your kettle.

6.1 Exterior Cleaning

1. Unplug the kettle from the power outlet and allow it to cool completely.
2. Wipe the exterior of the kettle and the power base with a soft, damp cloth.
3. Do not use abrasive cleaners or scouring pads, as these can damage the finish.
4. Ensure all parts are dry before storing or next use.

6.2 Descaling

Mineral deposits (limescale) can build up inside the kettle, especially in hard water areas. Descaling regularly will maintain efficiency and extend the kettle's life.

1. Fill the kettle with a mixture of one part white vinegar and two parts water.
2. Boil the mixture and let it stand for at least 30 minutes, or longer for heavy scale.
3. Discard the mixture and rinse the kettle thoroughly with fresh water several times.
4. For stubborn deposits, a commercial descaling solution designed for kettles can be used following the product's instructions.
5. After descaling, boil fresh water in the kettle and discard it two to three times to remove any residual descaling agent.

7. TROUBLESHOOTING

If you encounter issues with your kettle, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Kettle does not heat.	Not plugged in; power switch not activated; kettle not properly seated on base.	Ensure plug is firmly in outlet; press On/Off switch; reseal kettle on base.
Water takes too long to boil.	Limescale buildup.	Descale the kettle as per Section 6.2.
Kettle leaks.	Overfilled; lid not closed properly; internal damage.	Do not fill above max line; ensure lid is securely closed; if damage suspected, contact customer support.
Kettle switches off before boiling.	Limescale buildup; faulty thermostat.	Descale the kettle; if problem persists, contact customer support.

If the problem persists after attempting these solutions, please contact KitchenAid customer support.

8. SPECIFICATIONS

Feature	Specification
Model Number	5KEK1522EPT
Capacity	1.5 Liters
Power	900 Watts
Voltage	240 Volts
Material	Metal

Feature	Specification
Dimensions (L x W x H)	21 x 26.3 x 21.8 cm
Item Weight	2.5 Kilograms
Special Feature	Portable (Cordless Kettle)
Color	Pistachio

9. WARRANTY AND SUPPORT

KitchenAid products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or visit the official KitchenAid website.

For technical assistance, spare parts, or service inquiries, please contact KitchenAid customer support. Contact details can typically be found on the KitchenAid website or in your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B085Z1FRJZ>

More documents and user manuals: <https://manuals.plus/>