



[Manuals.plus](#) /

> [Haier](#) /

> Haier 325 L 3 Star Frost Free Bottom Mount Double Door Refrigerator HEB-333GB-P User Manual

Haier HEB-333GB-P

Haier 325 L 3 Star Frost Free Bottom Mount Double Door Refrigerator User Manual

Model: HEB-333GB-P

1. INTRODUCTION

Thank you for choosing the Haier 325 L 3 Star Frost Free Bottom Mount Double Door Refrigerator, model HEB-333GB-P. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read it thoroughly before use and retain it for future reference.



Figure 1: Front view of the Haier 325 L Bottom Mount Refrigerator.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury. This appliance is intended for household use only.

- Ensure the refrigerator is properly grounded.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- Keep ventilation openings clear of obstruction.
- Unplug the appliance before cleaning or performing maintenance.
- Keep children away from packaging materials and the appliance itself.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove all packaging materials, including tape and protective films. Inspect the refrigerator for any damage. Report any damage to your retailer immediately.

3.2 Placement

Place the refrigerator on a firm, level surface. Ensure adequate ventilation around the appliance. Maintain a minimum clearance of 10 cm (4 inches) from the back and sides to allow for proper air circulation and heat dissipation. Avoid direct sunlight or proximity to heat sources.



Figure 2: Refrigerator dimensions (W x D x H): 623 mm x 665 mm x 1640 mm.

3.3 Power Connection

Connect the refrigerator to a dedicated 220 Volt AC power outlet. Do not use extension cords or multiple adapters. Allow the refrigerator to stand for at least 2-4 hours before plugging it in to allow refrigerants to settle.

3.4 Initial Operation

After plugging in, the refrigerator will begin cooling. It may take several hours for the internal temperature to reach the desired level. Avoid placing food inside during the first 2-4 hours of operation.

4. OPERATING INSTRUCTIONS

4.1 Control Panel and Temperature Settings

The refrigerator features a digital display panel for easy temperature control and mode selection. Refer to the display for current settings and adjust as needed using the control buttons.

4.2 14-in-1 Convertible Modes

Your Haier refrigerator offers 14 versatile convertible modes to adapt to your storage needs. These modes allow you to optimize the freezer compartment for various functions, from extra refrigeration to specific food preservation.



Figure 3: Overview of key features including 14-in-1 Convertible Modes.

Examples of modes include:

- **Normal Mode:** Standard refrigeration and freezing.
- **Veg Mode:** Optimizes conditions for vegetable storage.
- **Cold Drink Mode:** Rapid cooling for beverages.
- **Soft Freezer Mode:** Ideal for items requiring less intense freezing.

- **Vacation Mode:** Energy-saving mode for extended absences.
- **Power Cool Mode:** Quickly chills the refrigerator compartment.
- **Power Saving Mode:** Reduces energy consumption.
- **Surprise Party Mode:** Prepares for increased cooling demand.
- **Turbo Mode:** Boosts cooling performance temporarily.
- **Holiday Mode:** Similar to Vacation Mode, for longer periods.
- **Freezer Mode:** Dedicated freezing.
- **Preserve Curd Mode:** Specific setting for curd preservation.
- **Snow Beverages Mode:** For specific beverage chilling.
- **Dessert Mode:** Optimized for dessert storage.

Consult the digital display and user interface for detailed instructions on selecting and activating each mode.

4.3 Twist Ice Maker and 1 Hour Icing Technology

The integrated Twist Ice Maker allows for convenient ice production. Simply fill the tray with water, allow it to freeze, and then twist the knob to release ice cubes into the storage bin. The 1 Hour Icing Technology ensures rapid ice formation when needed.



Figure 4: The Twist Ice Maker for convenient ice production.

4.4 Storage Features

The refrigerator is designed with various storage solutions for optimal organization:

- **Toughened Glass Shelves:** Durable and easy to clean, these shelves can hold heavy items.
- **2X Bigger Vegetable Box:** Provides ample space for fresh produce, helping to keep fruits and vegetables fresh longer.
- **Bottle Guard:** Securely holds bottles in the door compartment.
- **Recess Handle:** Integrated handle design for a sleek look and easy access.
- **Door Lock:** For added security.



Figure 5: Interior layout highlighting storage features.

5. MAINTENANCE

5.1 Cleaning

Regular cleaning helps maintain hygiene and efficiency. Always unplug the refrigerator before cleaning.

- **Interior:** Wipe with a soft cloth dampened with a solution of mild detergent and warm water. Rinse with clean water and dry thoroughly.
- **Exterior:** Clean with a soft, damp cloth. For stubborn stains, use a mild, non-abrasive cleaner.
- **Anti-Bacterial Gasket:** The door gasket is designed to prevent bacterial growth. Clean it regularly with warm soapy water to ensure a tight seal.



Figure 6: Close-up of the Anti-Bacterial Gasket and Twist Ice Maker.

5.2 Defrosting

This is a frost-free refrigerator, meaning manual defrosting is not required. The appliance automatically manages frost buildup.

5.3 Power Saving Tips

- Do not open the doors frequently or leave them open for long periods.
- Ensure the door gaskets are clean and sealing properly.
- Avoid placing hot food directly into the refrigerator. Allow it to cool down first.
- Keep the condenser coils at the back clean for efficient operation.

6. TROUBLESHOOTING

Before contacting service, review the following common issues and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Refrigerator not cooling	Power outage; plug loose; temperature setting too high; door left open.	Check power supply; ensure plug is secure; adjust temperature; close door properly.
Unusual noises	Appliance not level; items vibrating inside; compressor noise (normal).	Adjust leveling feet; rearrange items; normal compressor operation is quiet but audible.
Water on floor	Drain tube blocked; drip tray overflowing.	Clear drain tube; empty and clean drip tray.
Door not closing properly	Door gasket dirty or damaged; food packages obstructing.	Clean or replace gasket; rearrange food items.

If the problem persists after attempting these solutions, please contact customer support.

7. SPECIFICATIONS

Key technical specifications for the Haier HEB-333GB-P Refrigerator:

Feature	Specification
Brand	Haier
Model	HEB-333GB-P
Capacity	325 Litres
Energy Efficiency	3 Star
Annual Energy Consumption	250 Kilowatt Hours Per Year
Refrigerator Fresh Food Capacity	240 Litres
Freezer Capacity	85 Litres
Defrost System	Frost Free
Compressor Type	Triple Inverter Compressor
Shelf Type	Toughened Glass
Colour	GE Black
Item Dimensions (LxWxH)	66.5 x 62.3 x 164 Centimeters
Item Weight	65 kg
Included Components	1 unit Refrigerator, User Manual, Warranty cards




Figure 7: Power Savings Guide (Energy Label) for the refrigerator.

8. WARRANTY INFORMATION

Your Haier Refrigerator comes with the following warranty:

- **Product Warranty:** 1 year comprehensive warranty from the date of purchase.
- **Compressor Warranty:** 10 years warranty on the Triple Inverter Compressor.

Please retain your purchase receipt and warranty card for any warranty claims. The warranty covers manufacturing defects under normal household use. It does not cover damage due to misuse, improper installation, or unauthorized repairs.

9. CUSTOMER SUPPORT

For service, technical assistance, or any queries regarding your Haier refrigerator, please contact Haier customer service. Refer to the warranty card or Haier's official website for the most current contact information.

Manufacturer: Haier Appliances India Pvt Ltd

Address: Plot No. H-6, DMIC Integrated Industrial Township, Greater Noida, Uttar Pradesh, Pin -201310, India