

[Manuals.plus](#) /

> [Skywin](#) /

> Skywin Toy Action Set Instruction Manual (Model SW-NW-C-1pk)

## Skywin SW-NW-C-1pk

# Skywin Toy Action Set Instruction Manual

Model: SW-NW-C-1pk

## 1. INTRODUCTION

Thank you for purchasing the Skywin Toy Action Set. This product is designed to enhance your play experience with foam blasters, offering remote-controlled action. This manual provides essential information for safe and effective use, including setup, operation, and maintenance.

## 2. SAFETY INFORMATION

- Recommended age: 14 years and older. Adult supervision is advised for younger users.
- Do not aim at eyes or face. Use only projectiles designed for this product.
- Keep away from small children due to small parts that may pose a choking hazard.
- Do not modify the product in any way, as this may compromise safety and void the warranty.
- Ensure the play area is clear of obstacles and other people before activation.

## 3. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- Skywin Toy Action Set Unit
- Remote Control
- USB Charging Cable
- Rechargeable Battery
- Trip Wire Feature (Red Spool)
- Small Screwdriver




Figure 3.1: All items included in the Skywin Toy Action Set package.

## 4. SETUP

Follow these steps to set up your Skywin Toy Action Set for first use:

1. **Charge the Toy Unit:** Connect the provided USB charging cable to the toy unit's charging port (located at the back) and a suitable USB power source. The toy unit is powered via a USB cable and includes a rechargeable battery.
2. **Install Remote Control Batteries:** The remote control requires 2 AA batteries (not included). Open the battery compartment on the remote control and insert the batteries, ensuring correct polarity.
3. **Power On:** Ensure both the toy unit and the remote control are powered on.

4. **Loading Ammunition:** Open the toy unit and carefully load your preferred compatible ammunition (e.g., water pellets, foam darts, gel balls) into the designated compartment.
5. **Positioning:** Place the toy unit in your desired location. The adjustable metal legs allow for perfect aiming.
6. **Optional Trip Wire Setup:** For trip wire activation, connect the trip wire to the designated attachment points on the toy unit and extend it across the play area.

## VERSATILE USAGE

Compatible with Water Pellets, Nerf Rival Balls, Nerf Elite, Boomco Cutdown Darts, Airsoft Bbs, And Gell Balls



Figure 4.1: Loading ammunition into the Skywin Toy Action Set.



Figure 4.2: Scan this QR code for a detailed video tutorial on setup and operation. You can also visit [skywin.info/pages/toy-claymore](https://skywin.info/pages/toy-claymore).

Your browser does not support the video tag.

Video 4.1: Official demonstration of the Skywin Toy Action Set, including setup and firing.

---

## 5. OPERATING INSTRUCTIONS

The Skywin Toy Action Set offers two primary modes of operation: remote control and trip wire activation.

### 5.1 Remote Control Operation

The battery-operated remote control provides zero-delay responsiveness for immediate activation.

1. Ensure both the toy unit and the remote control are powered on.
2. Position yourself at a safe distance from the toy unit. The remote has a wide range of up to 20 feet.
3. Press the activation button on the remote control to trigger the toy unit.



Figure 5.1: Remote control for the Skywin Toy Action Set.



Figure 5.2: The toy unit can be activated from a wide range.

## 5.2 Trip Wire Operation

For automatic activation, use the trip wire feature:

1. Ensure the trip wire is securely attached to the toy unit and stretched across the desired activation path.
2. When the trip wire is disturbed, the toy unit will automatically activate.

## 6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Skywin Toy Action Set:

- **Battery Care:** Always remove AA batteries from the remote control when not in use to prevent

drainage. Avoid overcharging the toy unit's internal battery.

- **Cleaning:** Wipe the toy unit and remote control with a dry, soft cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the product in a cool, dry place away from direct sunlight and extreme temperatures.

---

## 7. TROUBLESHOOTING

If you encounter issues with your Skywin Toy Action Set, refer to the following common solutions:

- **Toy Unit Not Firing:**
  - Ensure the toy unit is fully charged.
  - Check if the toy unit is powered on.
  - Verify that ammunition is loaded correctly and not jammed.
- **Remote Control Not Responding:**
  - Ensure the remote control has fresh AA batteries and is powered on.
  - Confirm the toy unit is powered on.
  - If connection issues occur, turn both the toy unit and remote control off for 5-10 seconds, then power them back on to re-establish connection.
  - Ensure you are within the effective range of the remote control (up to 20 feet).
- **Trip Wire Not Activating:**
  - Ensure the trip wire is correctly attached to the toy unit's activation mechanism.
  - Check for any obstructions preventing the trip wire from moving freely.

---

## 8. SPECIFICATIONS

Feature	Detail
Brand	Skywin
Model Number	SW-NW-C-1pk
UPC	689299854824
Color	Green
Material Type	Metal, Plastic
Item Dimensions (L x W x H)	11.02 x 9.65 x 3.11 inches
Power Source	Battery, USB
Supported Battery Types	AA batteries for remote control (not included), internal rechargeable battery for toy unit

Number of Batteries (Remote)	2 AA batteries required
Assembly Required	Yes
Age Range Description	Adult (Manufacturer Minimum Age: 180 months)

---

## 9. WARRANTY AND SUPPORT

Skywin is committed to providing quality products. For any questions, concerns, or support needs regarding your Skywin Toy Action Set, please contact our customer service. While specific warranty details are not provided in this manual, we stand by the quality of our products. Please retain your proof of purchase for any warranty claims.

For further assistance, please visit the Skywin website or contact our support team through the retailer where you purchased the product.