



[Manuals.plus](#) /

> [IKON](#) /

> IKON IK-1607TE 16-inch 60 Watt Stand Fan User Manual

IKON IK-1607TE

IKON IK-1607TE 16-inch 60 Watt Stand Fan User Manual

Model: IK-1607TE

Overview	Safety Instructions	Setup & Assembly	Operation Warranty & Support	Maintenance
	Troubleshooting	Specifications		

1. PRODUCT OVERVIEW

This manual provides comprehensive instructions for the safe and efficient operation of your IKON IK-1607TE 16-inch 60 Watt Stand Fan. Please read this manual thoroughly before initial use and retain it for future reference.

The IKON IK-1607TE is a modern, freestanding electric fan designed for indoor use in areas such as living rooms and home offices. It features 3 speed settings and convenient touch panel controls.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, observe the following:

- Read all instructions before using this fan.
- Ensure the power supply voltage matches the rating label on the fan.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Do not immerse the fan, plug, or cord in water or other liquids.
- Unplug the fan from the outlet when not in use, before cleaning, or before moving.

- Do not allow children to operate or play with the fan unsupervised.
- This fan is for indoor use only. Do not use outdoors.
- Do not insert fingers or foreign objects into any openings.
- Place the fan on a stable, level surface to prevent tipping.

3. SETUP AND ASSEMBLY

Before assembly, ensure all components are present and undamaged. Refer to the diagram below for component identification.

3.1 Package Contents:

- Fan Head Assembly
- Adjustable Stand Pole
- Round Base
- Power Cord (integrated)
- User Manual

3.2 Assembly Steps:

1. Carefully unpack all components from the packaging.
2. Place the round base on a flat, stable surface.
3. Insert the adjustable stand pole into the opening on the base. Secure it firmly using the provided fastening mechanism (e.g., a screw or twist-lock, typically located underneath the base).
4. Attach the fan head assembly to the top of the adjustable stand pole. Ensure it clicks securely into place or is fastened with any provided screws/knobs.
5. Adjust the height of the fan by loosening the height adjustment collar on the stand pole, setting to the desired height, and then tightening the collar firmly.
6. Ensure all connections are tight and secure before plugging the fan into a power outlet.





Figure 1: Fully assembled IKON IK-1607TE 16-inch Stand Fan. The image shows the fan head with a protective grille, an adjustable stand pole, and a stable round base. Note: The product description indicates a bladeless design, while this image depicts a fan with visible blades and a grille. Please refer to the product specifications for the most accurate description of your specific model.

4. OPERATING INSTRUCTIONS

The IKON IK-1607TE fan features intuitive touch panel controls located on the fan body.

4.1 Power On/Off:

- Plug the power cord into a standard electrical outlet.
- Press the **Power button** (usually indicated by ● or ■ symbol) on the touch panel to turn the fan ON.
- Press the **Power button** again to turn the fan OFF.

4.2 Speed Settings:

- While the fan is ON, press the **Speed button** (often indicated by a fan icon or "SPEED") to cycle through the 3 available speed settings: Low, Medium, and High.
- The current speed setting may be indicated by LED lights on the control panel.

4.3 Oscillation Function:

- Press the **Oscillation button** (often indicated by an oscillating arrow icon) to activate the fan's oscillation feature, which allows it to rotate from side to side, distributing air over a wider area.
- Press the **Oscillation button** again to stop the oscillation at the desired direction.

5. CARE AND MAINTENANCE

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your fan.

- **ALWAYS UNPLUG THE FAN** from the power outlet before cleaning or performing any maintenance.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or harsh chemicals, as these may damage the finish.
- For bladeless fans, periodically use a soft brush or vacuum cleaner with a brush attachment to remove dust from air intake and outlet vents.
- Ensure all parts are completely dry before plugging the fan back in.
- When storing the fan, keep it in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

6. TROUBLESHOOTING GUIDE

If you experience issues with your fan, please consult the following troubleshooting guide before contacting customer service.

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Power cord not securely plugged in.	Check if the power outlet is working. Ensure the power cord is firmly plugged into the outlet and the fan.
Weak or no airflow.	Air intake/outlet vents are blocked. Fan is on a low speed setting.	Check for and remove any obstructions from the vents. Increase the fan speed using the control panel.
Unusual noise during operation.	Fan not on a level surface. Loose components.	Place the fan on a flat, stable surface. Check all assembly points to ensure they are securely fastened.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	IKON
Model Number	IK-1607TE
Power	60 Watts
Size	16 inches
Number of Speeds	3
Control Type	Touch Panel
Fan Type	Stand Fan (Pedestal Fan)
Color	Black
Special Feature	Bladeless
Power Source	Electric
Recommended Use	Living Room, Home Office
Installation Type	Freestanding
Material	Plastic
Indoor/Outdoor Use	Indoor

8. WARRANTY AND CUSTOMER SUPPORT

For information regarding the product warranty, please refer to the warranty card included with your purchase or contact your retailer. If you require technical assistance, troubleshooting beyond this guide, or have questions about your IKON IK-1607TE Stand Fan, please contact IKON customer service.

Please have your model number (IK-1607TE) and purchase date available when contacting support.