

[Manuals.plus](#) /

> [Homeweeks](#) /

> Homeweeks 300ml Essential Oil Diffuser (Model JSQ-MB) User Manual

Homeweeks JSQ-MB

Homeweeks 300ml Essential Oil Diffuser (Model JSQ-MB) User Manual

Your guide to setting up, operating, and maintaining your aromatherapy diffuser.

INTRODUCTION

Thank you for choosing the Homeweeks 300ml Essential Oil Diffuser. This device combines the benefits of a humidifier, aromatherapy diffuser, and night light to enhance your home or office environment. Please read this manual carefully before use to ensure proper operation and maintenance.

IMPORTANT SAFETY INSTRUCTIONS

- Always place the diffuser on a flat, stable surface.
- Do not fill water beyond the maximum fill line.
- Use only clean tap water or distilled water.
- Do not use corrosive detergents to clean the diffuser.
- Keep out of reach of children and pets.
- Unplug the device before cleaning or refilling.
- Ensure the power adapter is dry before plugging it in.
- Do not block the mist outlet.
- If the diffuser is not in use for a long period, empty the water tank and clean it.

PACKAGE CONTENTS

- 1 x Homeweeks 300ml Aroma Diffuser
- 1 x Power Adapter
- 1 x Remote Control
- 1 x User Manual (this document)

PRODUCT OVERVIEW

The Homeweeks 300ml Essential Oil Diffuser features a compact design with a wood-grain base and a white top. It

includes intuitive controls for mist and light functions, along with a remote for convenient operation.

Small & Compact Design Suitable for personal home space



Image: HomeweekS 300ml Essential Oil Diffuser, showcasing its compact size (4.72 inches wide, 3.74 inches high) and wood-grain base.

SETUP INSTRUCTIONS

1. Place the diffuser on a stable, level surface.
2. Remove the top cover by lifting it upwards.
3. Connect the power adapter to the DC jack at the bottom of the diffuser.
4. Fill the water tank with clean water up to the maximum water level line (300ml capacity).
5. Add 3-5 drops of your preferred essential oil into the water tank (optional).
6. Replace the top cover, ensuring it is securely seated.
7. Plug the power adapter into a wall outlet.



For Your Better Life

Have Diffusers in Multiple Rooms

- Waterless Auto-off
- Strong / Weak Mist
- Whisper Quiet
- 8 Color Lights
- BPA Free



Image: The diffuser with its top cover removed, revealing the water tank. The power cord is shown connected to the base.

OPERATING INSTRUCTIONS

The diffuser can be operated using the buttons on the front or the included remote control.

Mist Control

- Press the "Mist" button (or "ON/OFF" on remote) to turn on the mist.
- Press repeatedly to cycle through mist modes: 1H (1 hour), 3H (3 hours), 6H (6 hours), ON (continuous).
- The diffuser features adjustable cool mist modes (strong/weak mist).
- It has a waterless auto-off function for safety.

Mood Creating Lights

8 colorful night lights bring you relaxation



Cycle Color



Fixed Color



Dim/Bright Light

Image: The diffuser emitting mist, with indicators for 1H, 3H, 6H, and ON timer settings visible on the base.

Light Control

- Press the "Light" button (or "Light" on remote) to turn on the LED light.
- Press repeatedly to cycle through 8 different colors.
- You can choose to cycle colors, fix a single color, or adjust brightness.
- The lights can function as a night light.

Comfortable Enjoy for Whole Night



Waterless Auto-off



Whisper-quiet



Image: Multiple diffusers shown in different colors, illustrating the 8 colorful night light options.

Remote Control Functions

The remote control provides convenient access to all diffuser functions:

- **ON/OFF:** Turns the diffuser on or off.
- **Intermittent:** Sets mist to intermittent mode.
- **Continuous:** Sets mist to continuous mode.
- **Timing (1H, 3H, 6H):** Sets the operating timer.
- **Big/Small:** Adjusts mist intensity.
- **Light:** Controls the LED light color and brightness.

Cute Design

Suitable for kids, as a gift



Image: A person using the remote control to operate the diffuser, highlighting the convenience of remote operation.

MAINTENANCE AND CLEANING

Regular cleaning is essential to ensure optimal performance and longevity of your diffuser.

1. Unplug the diffuser from the power outlet.
2. Remove the top cover and empty any remaining water from the tank.
3. Wipe the inside of the water tank and the ultrasonic disc at the bottom with a soft cloth or cotton swab.
4. For stubborn residue, use a small amount of white vinegar on a cloth to gently clean the tank and disc, then rinse thoroughly with clean water.
5. Ensure all parts are completely dry before reassembling or storing the diffuser.
6. Clean the diffuser after every 5-6 uses or every 3-5 days.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or weak mist	Insufficient water; water level too high; ultrasonic disc dirty; mist outlet blocked.	Ensure water is between min and max lines. Clean the ultrasonic disc. Check if the mist outlet is clear.
Diffuser turns off unexpectedly	Water tank is empty (auto-off feature); timer setting reached.	Refill water tank. Check timer settings.
Unusual noise	Water level too low; diffuser not on a flat surface.	Add water. Place on a flat, stable surface.

SPECIFICATIONS

- **Brand:** Homeweeks
- **Model Name:** HD-MBA3
- **Item Model Number:** JSQ-MB
- **Color:** White
- **Material:** Polypropylene (PP)
- **Capacity:** 300 Milliliters
- **Power Source:** Corded Electric
- **Special Features:** Automatic Shut-Off, Compact, Multiple Light Setting, Silent Operation, Timer Setting
- **Product Dimensions:** 5.2"L x 5.2"W x 3.9"H
- **Item Weight:** 10.6 ounces
- **Coverage:** 250 square feet

SUPPORT

For any questions or issues regarding your Homeweeks essential oil diffuser, please contact Homeweeks customer support. We are ready to assist you.
Contact information (e.g., email, website) would typically be provided here by the manufacturer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0861XZY3N>

More documents and user manuals: <https://manuals.plus/>