

[Manuals.plus](#) /

› [WONNIE](#) /

› WONNIE 10.5" Car Dual DVD Player Instruction Manual

WONNIE W-1012

WONNIE 10.5" Car Dual DVD Player Instruction Manual

Model: W-1012

Brand: WONNIE

INTRODUCTION AND OVERVIEW

The WONNIE 10.5" Car Dual DVD Player system is designed to provide entertainment for passengers during car journeys. Featuring an upgraded chip for clear images and videos, this portable dual-screen setup allows for synchronized playback of the same movie across both monitors. It includes a main DVD player unit with a rechargeable battery and a slave monitor, offering flexible viewing options. The system supports various media formats and provides multiple connectivity options for enhanced user experience.



Figure 1: The WONNIE 10.5" Dual Car DVD Player system.

WHAT'S IN THE BOX

Please ensure all the following components are present in your package:

- 1 x Main DVD Player
- 1 x Slave Monitor
- 2 x Mounting Brackets
- 2 x Headrest Straps
- 1 x AC Adapter
- 1 x Car Charger
- 1 x AV Cable
- 1 x DC Cable
- 1 x RCA Cable
- 1 x Remote Control
- 1 x User Manual

FEATURES

Dual Screen Synchronized Playback

The system includes a main DVD player and a slave monitor, allowing two viewers to watch the same movie simultaneously. The screens are connected via the provided DC and AV cables to ensure synchronized playback.



DUAL SCREEN CAR DVD PLAYER

Take Joy to Your Kids in Long Road Trip

Two Screens, Play Same Movies





Figure 2: Dual screen setup for synchronized movie viewing in a car.

Long-Lasting Battery and Multiple Charging Options

The main DVD player is equipped with a high-capacity rechargeable battery, providing up to 5 hours of playback when used alone. When both monitors are connected, the battery life is approximately 2.5-3 hours. The system can be charged using the included AC adapter for home use or the car charger for continuous power on the go.

LONG LASTING BATTERY LIFE

Works Solely Up to **5 Hrs** and Work Together Up to **3 Hrs**



5000 mAh

Up to 5 Hrs

POWER SETUP UP DOWN OK LEFT RIGHT



Built-in Battery



Car Charger



AC Adapter

Figure 3: Battery life and charging methods for the DVD player.

Enhanced Audio Experience

Each monitor features upgraded dual powerful stereo speakers, delivering clearer and more immersive sound. This ensures an enjoyable audio experience for all passengers.

HEAR LOUD AND CLEAR VOICE

Built-in Dual Stereo Speakers, Provide High Quality Sound



Figure 4: Dual stereo speakers for high-quality sound.

Broad Media Compatibility

The DVD player is region-free and supports a wide range of disc formats including CD, DVD, CD-R/RW, DVD -R/+R, DVD+RW/-RW, VCD, SVCD (RW), and CD-R (RW). Please note that Blu-ray discs and MP4 files are not supported. Additionally, it features USB and SD card slots (max 32GB FAT32, 720*576 pixels for video) for playing digital media such as pictures (JPG, JPEG), audio (MP3/WMA), and videos (VOB, AVI, MPEG 1, MPEG 2, XVID, MPG, 3GP, DAT).

MULTIPLE FORMATS SUPPORTED

Play DVD/CD Discs from All Region and Various Media Files



DVD Formats:

DVD, DVD+R, DVD-R, DVD+RW, DVD-RW, CD, CD+R, CD-R, CD+RW, CD-RW, VCD, SVCD (Blu-Ray Disc Not Supported)



Video Formats:

VOB, AVI, MPEG1, MPEG2, XVID



Audio Formats:

MP3, WMA



Image Formats:

JPG, JPEG



Figure 5: Supported media formats and external storage options.

Last Memory Function

The last memory function allows the player to resume playback from where you left off, ensuring you don't miss any part of your movie or show.

SETUP

Installation Methods

The WONNIE Dual DVD Player offers two convenient installation methods for car headrests:

1. **Mounting Brackets:** Use the customized mounting brackets for a secure and stable installation. These screw together around the headrest posts, and the monitor then screws onto the bracket. This method allows for angle adjustment.




Figure 6: Step-by-step installation using mounting brackets.

2. **Headrest Straps:** For a quicker and more flexible setup, utilize the provided headrest straps. These straps allow you to easily attach the monitors to the headrests and move them between seats or vehicles as needed.

For a visual guide on installation and features, please watch the official product video below:

Your browser does not support the video tag.

Video 1: WONNIE 10.5" Dual Car DVD Player with 2 Headrest Mount - This video demonstrates the installation process using both mounting brackets and headrest straps, along with an overview of the player's features.

OPERATING INSTRUCTIONS

Loading a Disc

The player features a clamshell design for easy disc loading. Simply open the main DVD player unit, insert your desired CD or DVD disc, and close the lid. The player will automatically begin reading the disc.

Connecting to a TV

To enjoy your content on a larger screen, connect the main DVD player to a TV using the provided RCA cable. Plug one end of the RCA cable into the AV OUT port of the DVD player and the other end into the AV IN port of your television. Switch your TV's input source to AV mode.

SYNC PLAYBACK TO TV

Easily Connect to TV with Provided RCA Cable



Figure 7: Connecting the DVD player to a TV for larger screen viewing.

Your browser does not support the video tag.

Video 2: Sync Playback to a Large TV Screen - This video demonstrates how to connect the DVD player to a television using the RCA cable and enjoy synchronized playback.

Connecting to a Projector

For a cinematic experience, you can connect the DVD player to a projector. Use the AV cable to connect the AV OUT port of the DVD player to the AV IN port of your projector. Ensure your projector is set to the correct input source.

Your browser does not support the video tag.

Video 3: Get a Movie Theater Effect via Connecting Your Projector - This video illustrates how to connect the DVD player to a projector for a larger viewing experience.

Adjusting Volume

The volume can be adjusted using the included remote control. Point the remote at the main DVD player and use the volume up/down buttons to set your desired audio level.

MAINTENANCE

To ensure the longevity and optimal performance of your WONNIE Dual DVD Player, follow these maintenance guidelines:

- Keep the units clean by wiping them with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- Handle discs carefully by the edges to prevent scratches. Store discs in their cases when not in use.
- Avoid exposing the units to extreme temperatures, direct sunlight for prolonged periods, or high humidity.
- Ensure all cables are securely connected but do not force them into ports.
- When not in use for extended periods, fully charge the main player's battery and store it in a cool, dry place.

TROUBLESHOOTING

If you encounter any issues with your WONNIE Dual DVD Player, please refer to the following common troubleshooting steps:

- **No Power:**
 - Ensure the AC adapter or car charger is securely plugged into both the unit and the power source.
 - Check if the power outlet or car's cigarette lighter socket is functioning correctly.
 - Verify the main player's battery is charged.
- **No Picture on Slave Monitor:**
 - Confirm the DC cable and AV cable are correctly connected between the main player and the slave monitor.
 - Ensure the main player is powered on and playing content.
- **No Sound or Low Sound:**
 - Increase the volume using the remote control or the unit's controls.
 - Check if headphones are plugged in, which might mute the speakers.
 - If connected to an external device (TV/projector), ensure the external device's volume is also adjusted and its input is correctly selected.
- **Disc Not Reading:**
 - Ensure the disc is clean and free of scratches or smudges. Wipe gently with a soft, lint-free cloth from the center outwards.
 - Verify the disc format is supported (e.g., not Blu-ray).
 - Try a different disc to determine if the issue is with the player or the disc.
- **Remote Control Not Working:**
 - Check and replace the batteries in the remote control.
 - Ensure there are no obstructions between the remote and the player's IR sensor.
 - Point the remote directly at the main DVD player unit.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	W-1012
Screen Size	10.5 Inches
Display Type	LCD
Product Dimensions	12 x 10.5 x 5.1 inches
Item Weight	5.96 pounds
Battery Type	1 Lithium Ion battery (included)
Main Player Battery Life	Up to 5 hours (single monitor)
Dual Monitor Battery Life	Approx. 2.5-3 hours
Supported Disc Formats	CD, DVD, CD-R/RW, DVD -R/+R, DVD+RW/-RW, VCD, SVCD (RW), CD-R (RW) (Excludes Blu-ray)
Supported Digital Media	USB & SD (max 32GB FAT32, 720*576 pixels for video); JPG, JPEG, MP3, WMA, VOB, AVI, MPEG 1, MPEG 2, XVID, MPG, 3GP, DAT
Color	Black

WARRANTY AND SUPPORT

WONNIE provides a 12-month warranty for quality-related issues from the date of purchase. For any product inquiries, missing parts, or issues with received items, please contact WONNIE customer service via the "Get Product Support" option on the Amazon Station Email or the After-sales Email. Our support team is available 24/7 to assist you.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0862697XK>

More documents and user manuals: <https://manuals.plus/>