

KAFF HBR 784C

KAFF HBR 784C Built-in Hob/Hobtop Instruction Manual

Model: HBR 784C

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before installing or using this appliance. Keep this manual for future reference. Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information, consult a qualified installer, service agency, or the gas supplier.

- **Gas Safety:** Ensure proper ventilation. In case of a gas leak, immediately shut off the gas supply, open windows, and do not operate any electrical switches or appliances. Contact a qualified technician.
- **Electrical Safety:** This appliance must be properly grounded. Do not use extension cords.
- **Burn Hazard:** Burner flames and cooking surfaces become hot during use. Allow surfaces to cool before cleaning or touching.
- **Children Safety:** Keep children away from the appliance during operation and when it is cooling down. Do not allow children to play with the controls.
- **Flammable Materials:** Do not store or use flammable materials near the hob.
- **Proper Use:** Use the appliance only for its intended purpose of cooking food.

2. PRODUCT OVERVIEW

The KAFF HBR 784C is a versatile 4-burner built-in hob or hobtop designed for modern kitchens. It features an 8mm thick black tempered glass surface, powerful brass burners, and automatic electric ignition for convenient cooking.



2 Triple Ring and 2 Dual Ring Burner

Image: The KAFF HBR 784C Built-in Hob/Hobtop, showcasing its sleek black tempered glass surface and four brass burners.

Key Features:

- **Type:** Built-in Hob / Hobtop
- **Size:** 78 CM
- **Ignition Type:** Automatic Electric Ignition
- **Glass Type:** 8 mm Bevelled Black Tempered Glass
- **Pan Support:** Matt Enameled Pan Support
- **Burners:** 4 Brass Burners (2 Triple Ring, 2 Dual Ring) with High Efficiency Heavy Duty Brass Burner Coated in Black
- **Controls:** Ergonomic Easy Grip Metal Knobs
- **Drip Tray:** Stainless Steel

3. INSTALLATION

3.1 Unpacking

Carefully remove the hob from its packaging. Inspect the appliance for any damage. Do not discard packaging materials until you are satisfied with the product and its operation. Ensure all components listed in the 'What's in the Box' section are present.

3.2 Placement (Built-in vs. Hobtop)

This appliance can be used as a built-in hob, integrated into your kitchen countertop, or as a hobtop placed directly on the counter. Ensure the surface is stable and level.



Image: The KAFF HBR 784C demonstrating its dual functionality as both a built-in hob and a hobtop.

3.3 Dimensions

For built-in installation, ensure your countertop cutout matches the specified inner cutting size. The outer dimensions are for the hob's overall footprint.

- **Inner Cutting Size:** 685mm x 475mm
- **Outer Size:** 780mm x 520mm



Image: Detailed diagram illustrating the inner cutting dimensions (685x475 mm) and outer dimensions (780x520 mm) for proper installation.

3.4 Gas Connection

Gas connection must be performed by a qualified and authorized technician in accordance with local regulations and safety standards. Ensure the gas supply pressure is compatible with the appliance.

3.5 Electrical Connection

The hob requires an electrical connection for the automatic electric ignition. Connect the appliance to a properly grounded 230 Volt AC power supply. Do not use adapters or extension cords.

4. OPERATION

4.1 Burner Types

The KAFF HBR 784C is equipped with four high-efficiency brass burners: two triple-ring burners for intense heat and two dual-ring burners for versatile cooking.




Image: A detailed view of the hob's two triple-ring and two dual-ring brass burners, designed for various cooking needs.

4.2 Automatic Electric Ignition

To ignite a burner:

1. Push down the corresponding control knob.
2. Rotate the knob counter-clockwise to the 'Ignite' position (usually marked with a flame symbol). You will hear a clicking sound as the igniter sparks.
3. Once the flame ignites, hold the knob down for a few seconds to allow the thermocouple to heat up and activate the flame failure device.
4. Release the knob and adjust the flame to your desired intensity. If the flame extinguishes, repeat the process.



Image: A close-up view highlighting the auto electric ignition system, showing the igniter pin next to the burner.

4.3 Flame Control

The hob features ergonomic easy-grip metal knobs for precise control over the flame intensity. Rotate the knob clockwise for a lower flame and counter-clockwise for a higher flame. Always ensure the flame is stable and blue.



Image: The easy-grip metal control knobs, designed for comfortable and precise flame adjustment.

5. CLEANING AND MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your hob. Always ensure the appliance is cool and disconnected from the power supply before cleaning.

5.1 General Cleaning (Glass Top)

The 8mm thick black tempered glass surface is designed for easy cleaning. Use a soft cloth and a mild detergent or glass cleaner. Avoid abrasive cleaners, scouring pads, or harsh chemicals that can scratch or damage the glass.




Image: A close-up of the durable 8mm thick black tempered glass, emphasizing its smooth, easy-to-clean surface.

5.2 Burner and Pan Support Cleaning

Remove the matt enameled pan supports and brass burners. Wash them with warm soapy water. For stubborn stains, a non-abrasive scrub brush can be used. Ensure all parts are completely dry before reassembling them on the hob.

5.3 Drip Tray Cleaning

The stainless steel drip tray collects spills and overflows. Remove the drip tray and wash it with warm soapy water. Dry thoroughly before placing it back.



Image: A close-up of the stainless steel drip tray, designed to catch spills and simplify cleaning.

6. TROUBLESHOOTING

If you encounter issues with your hob, refer to the following common troubleshooting steps. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply, power outage, igniter dirty/wet, knob not held long enough.	Check gas supply, check power, clean igniter, hold knob for 3-5 seconds after ignition.
Irregular or yellow flame	Burner parts not seated correctly, burner ports clogged, incorrect gas type.	Ensure burner caps and rings are correctly placed. Clean burner ports. Contact technician if gas type is suspected.
Gas smell detected	Gas leak.	Immediately shut off gas supply, open windows, do not operate electrical switches. Contact a qualified technician.

7. SPECIFICATIONS

Feature	Detail
Model Number	HBR 784C
Colour	Black
Material	Stainless Steel (base), Tempered Glass (top)
Special Features	8mm Thick Black Tempered Glass, Auto Electric Ignition
Number of Burners	4 (2 Triple Ring, 2 Dual Ring)
Controls Type	Knob
Voltage	230 Volts
Power Source Type	Electric (for ignition)
Item Dimensions (D x W x H)	85.1D x 58.4W x 17.8H Centimeters (Note: Product dimensions for installation are 780x520mm outer, 685x475mm inner cutting)
Item Weight	19 Kilograms
Included Components	1x Built-in Hob, 1x Instruction Manual, 1x Warranty Card

8. WARRANTY AND CUSTOMER SUPPORT

8.1 Manufacturer's Warranty

The KAFF HBR 784C Built-in Hob/Hobtop comes with the following warranty:

- **2 Years Warranty:** On Glass, Ignition Wire, Switch, Bypass & Generator.
- **5 Years Warranty:** On Burners.

Please retain your purchase receipt and warranty card for any warranty claims.

8.2 Customer Support

For any queries, service requests, or technical assistance, please contact KAFF customer care:

- **Manufacturer:** KAFF Appliances India Private Limited
- **Customer Care (Toll-Free):** 18001802221

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question