

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› **INFILAND** /

› **INFILAND Galaxy Tab S6 Lite Case Instruction Manual**

INFILAND Galaxy Tab S6 Lite Case

INFILAND Galaxy Tab S6 Lite Case Instruction Manual

Model: Galaxy Tab S6 Lite Case

1. PRODUCT OVERVIEW

This INFILAND case is designed to provide protection and enhanced functionality for your Samsung Galaxy Tab S6 Lite 10.4 Inch tablet. It is compatible with the 2020 and 2022 release models: SM-P610, SM-P615, SM-P613, and SM-P619.

HAPPY WORK, ENJOY LIFE.

May you accompany me every
morning and evening



This image illustrates the precise compatibility of the INFILAND case, confirming it fits the Samsung Galaxy Tab S6 Lite 10.4 inch (models SM-P610, SM-P615, SM-P613, SM-P619) and does not fit the Samsung Galaxy Tab S6 10.5 inch (models SM-T860, SM-T865).

2. INSTALLATION GUIDE

Follow these steps to properly install your Samsung Galaxy Tab S6 Lite into the INFILAND case:

1. **Open the Case:** Lay the case flat on a clean surface with the interior facing upwards.
2. **Align the Tablet:** Carefully align your Samsung Galaxy Tab S6 Lite with the hard shell frame of the case. Ensure the camera cutout and port openings on the case match those on your tablet.
3. **Secure the Tablet:** Gently press the tablet into the hard shell frame until it snaps securely into place. Verify that all edges of the tablet are fully enclosed by the case frame.
4. **Check Fit:** Confirm that all buttons, ports, and the camera remain accessible and unobstructed.

For a visual demonstration of the installation process and key features, please refer to the official product video below:

Your browser does not support the video tag.

3. KEY FEATURES

- **Automatic Wake/Sleep Function:**

The case features a built-in smart sensor that automatically wakes your tablet when the front flap is opened and puts it to sleep when closed. This helps to extend standby time and reduce battery drain.



This image demonstrates the smart sleep/wake functionality, highlighting how the case helps conserve battery life by automatically adjusting the tablet's power state.

- **Multi-Angle Stand:**

The foldable front cover allows for multiple viewing angles, providing a stable bracket for comfortable reading, typing, or media consumption. An anti-slip strip ensures the tablet remains securely in position.



This image displays the case configured as a multi-angle stand, emphasizing its stable design for various viewing needs.

- **Magnetic Closure Buckle:**

A magnetic closure buckle keeps the case securely closed when not in use, preventing accidental openings and providing additional protection for the screen.

- **S Pen Magnetic Adsorption:**

The case design accommodates the S Pen, allowing it to magnetically attach to the tablet's designated area while remaining protected within the case's closure.

- **Precision Cutouts:**

Designed with precise cutouts, the case ensures full access to all ports, buttons, and the camera without needing to remove the tablet from the case.



PRECISION CUTOUT

This image illustrates the precision cutouts of the case, ensuring unhindered access to the tablet's ports and controls.

- **Three Layers of Protection:**

The case is constructed with multiple layers to provide anti-collision, anti-scratch, and anti-splash protection, safeguarding your tablet from daily wear and tear.



THREE LAYERS OF PROTECTION TO YOUR TABLT.

It always provide anti-collision, anti-scratch and anti-splash protection for your tablet.

This image highlights the multi-layered construction of the case, designed to offer comprehensive protection for the tablet.

4. CARE AND MAINTENANCE

To ensure the longevity and appearance of your INFILAND case, follow these care instructions:

- **Cleaning:** Use a soft, damp cloth to wipe the exterior of the case. Avoid harsh chemicals or abrasive cleaners, as these can damage the material.
- **Drying:** Allow the case to air dry completely after cleaning. Do not expose it to direct sunlight or high heat.
- **Storage:** When not in use, store the case in a cool, dry place away from extreme temperatures.
- **Avoid Sharp Objects:** Keep the case away from sharp objects to prevent scratches or punctures.

5. TROUBLESHOOTING

If you encounter any issues with your INFILAND case, consider the following:

- **Tablet Not Fitting:** Ensure your tablet model is a Samsung Galaxy Tab S6 Lite 10.4 Inch (SM-P610/SM-P615/SM-P613/SM-P619). The case is not compatible with other tablet models.
- **Auto Wake/Sleep Not Working:** Verify that the tablet is correctly seated in the case and that the front flap is fully closing. Ensure there are no obstructions preventing the magnetic sensor from engaging.
- **Stand Instability:** Make sure the tablet is placed firmly against the anti-slip strip when using the stand feature. Adjust the angle to find a stable position on a flat surface.

- **S Pen Not Secure:** Confirm the S Pen is placed in its designated magnetic adsorption area on the tablet. The case's design helps secure it when the flap is closed.

If problems persist, please contact customer support for further assistance.

6. SPECIFICATIONS

Feature	Detail
Brand	INFILAND
Compatible Devices	Samsung Galaxy Tab S6 Lite 10.4 Inch (Models: SM-P610, SM-P615, SM-P613, SM-P619)
Item Weight	11.2 ounces
Package Dimensions	9.6 x 6.5 x 0.6 inches
Form Factor	Case
Shell Type	Hard

7. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the INFILAND official website or contact the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.