

[Manuals.plus](#) /

› [Invacare](#) /

› Invacare 9000 SL Wheelchair User Manual

Invacare 9SL_PTO_34745

Invacare 9000 SL Wheelchair User Manual

Model: 9SL_PTO_34745

1. PRODUCT OVERVIEW

The Invacare 9000 SL Wheelchair is designed for durability and user comfort, featuring a lightweight carbon steel frame and high-quality components. This manual provides essential information for the safe and effective use of your wheelchair.

Key Features:

- **Contemporary Frame Design:** Lightweight carbon steel frame with dual axle positions for adjustable seat-to-floor heights (17.5" or 19.5"). Urethane front and rear tires on "no flex" wheels.
- **Durable Construction:** High-strength carbon steel frame and black nylon upholstery with heavy-duty inner liners to prevent stretching.
- **Weight Capacity:** Supports up to 250 lbs.
- **Adjustable Dimensions:** 16-inch seat width and 16-inch seat depth.
- **Armrest and Legrest Details:** Space-saver, desk-length arms for easy access to tables. Front riggings (leg rests and footrests) are sold separately.

Product Images:



Invacare 9000 SL Wheelchair, side view.



Invacare 9000 SL Wheelchair highlighting nylon upholstery, desk-length armrests, and urethane rear tires.



Invacare 9000 SL Wheelchair in folded position, front view.



User seated comfortably in an Invacare 9000 SL Wheelchair indoors.



User in an Invacare 9000 SL Wheelchair
outdoors on a boardwalk.

2. SAFETY INFORMATION

Always read and understand all instructions before using the Invacare 9000 SL Wheelchair. Failure to do so could result in injury or damage.

General Safety Precautions:

- Ensure all parts are securely fastened before each use.
- Do not exceed the maximum weight capacity of 250 lbs.
- Engage wheel locks when transferring in or out of the wheelchair.
- Avoid sudden movements or leaning excessively, which could cause tipping.
- Regularly inspect tires, brakes, and frame for wear or damage.
- Seek assistance for transfers if needed to prevent falls.

3. SETUP AND ASSEMBLY

Unpacking:

Carefully remove the wheelchair from its packaging. Inspect for any signs of damage during transit. Retain packaging for future storage or transport.

Opening the Wheelchair:

1. Place the wheelchair on a flat, stable surface.
2. Grasp the seat rails and push downwards and outwards until the wheelchair is fully open and the seat is flat.
3. Ensure the cross-braces are fully extended and locked into place.

Attaching Armrests (if detached):

The desk-length arms are designed for easy removal and attachment. To attach, align the armrest posts with the receptacles on the frame and push down until they click into place. To remove, press the release buttons (typically located near the base of the armrest posts) and lift the armrests straight up.

Attaching Legrests/Footrests (Sold Separately):

If you have purchased separate legrests or footrests (e.g., T94HEP, T94HAP, T94HCP, T93HAP, T93HCP), align their attachment pins with the receivers on the front of the wheelchair frame. Swing the legrest outwards, insert the pins, and then swing it inwards until it locks securely. Ensure both legrests are firmly attached before use.

4. OPERATING INSTRUCTIONS

Using the Wheel Locks:

To engage the wheel locks, push the lock levers forward until they firmly press against the tires. To disengage, pull the levers backward. Always engage both wheel locks when the wheelchair is stationary, especially during transfers.

Propelling the Wheelchair:

For self-propulsion, grasp the handrims and push forward evenly. For assisted propulsion, push the handgrips on the back of the wheelchair. Ensure the user's feet are on the footrests to prevent dragging.

Adjusting Seat-to-Floor Height:

The dual axle design allows for two seat-to-floor height options: 17.5 inches or 19.5 inches. Consult a qualified technician or the detailed instructions provided with your wheelchair for specific steps on adjusting the axle position. This adjustment typically involves repositioning the rear wheel axle.

Folding the Wheelchair for Transport/Storage:

- 1. Ensure footrests are swung out or removed.
- 2. Grasp the center of the seat upholstery (or the pull strap if present) and lift upwards.
- 3. Push the armrests inwards to fully collapse the frame.
- 4. Secure any loose components before transport.

5. MAINTENANCE AND CARE

Cleaning:

Clean the frame with a damp cloth and mild detergent. The nylon upholstery can be wiped down with a damp cloth. Avoid abrasive cleaners or solvents that may damage the materials.

Regular Inspection:

- Check all nuts and bolts regularly and tighten as necessary.
- Inspect tires for wear and tear. Urethane tires are designed for durability but should be checked for cracks or punctures.
- Verify that wheel locks engage securely and hold the wheels firmly.
- Ensure armrests and footrests (if applicable) attach and detach smoothly and securely.
- Check upholstery for rips, tears, or excessive stretching.

Storage:

Store the wheelchair in a dry, clean environment away from direct sunlight and extreme temperatures. Folding the wheelchair can save space during storage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Wheel locks not holding	Adjustment needed; worn tires.	Adjust the lock mechanism. If tires are worn, consider replacement.
Wheelchair difficult to propel	Debris in axles; loose components.	Clean axles. Tighten all fasteners.
Seat upholstery stretching/sagging	Normal wear over time; heavy use.	The heavy-duty inner liner is designed to minimize this. If excessive, contact Invacare support for potential replacement options.
Armrests loose or difficult to attach/detach	Debris in receptacles; worn release buttons.	Clean receptacles. Ensure release buttons are fully depressed. If worn, contact support.

7. SPECIFICATIONS

- **Model:** 9SL_PTO_34745
- **Brand:** Invacare
- **Frame Material:** Carbon Steel
- **Upholstery Material:** Black Nylon with heavy-duty inner liner
- **Seat Width:** 16 inches
- **Seat Depth:** 16 inches
- **Seat-to-Floor Height Options:** 17.5 inches or 19.5 inches (adjustable via dual axle)
- **Armrests:** Desk-Length, Space-Saver, Padded
- **Front Casters:** 8 inches
- **Rear Wheels:** 24 inches with composite handrims, "no flex" urethane tires
- **Weight Capacity:** 250 lbs
- **Approximate Product Weight:** 39.4 lbs
- **Package Dimensions:** 37 x 34 x 12.5 inches

8. WARRANTY AND SUPPORT

Manufacturer's Warranty:

Invacare products are manufactured to exacting standards and undergo thorough inspection. Specific warranty details are typically provided with the product at the time of purchase. Please refer to your warranty card or the official Invacare website for comprehensive warranty information.

Customer Support:

For technical assistance, parts, or warranty inquiries, please contact Invacare Customer Service:

Phone: 1 (800) 333-6900

You can also visit the official Invacare website for additional resources and support.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question