

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Maegoo](#) /
- › [Maegoo Wireless Game Controller User Manual \(Model 135\)](#)

Maegoo 135

Maegoo Wireless Game Controller User Manual

Model: 135

INTRODUCTION

This manual provides detailed instructions for setting up and operating your Maegoo Wireless Game Controller. Please read this guide carefully before use to ensure proper functionality and a satisfactory gaming experience. The controller is designed for compatibility with Android devices, Windows PCs, PlayStation 3, Smart TVs, and TV Boxes.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Maegoo Wireless Game Controller
- 1 x USB Cable
- 1 x 2.4G USB Dongle
- 1 x Retractable Bracket
- 1 x User Manual

SETUP

Android Device Connection (Bluetooth)

1. Press and hold the "A" button + "HOME" button for 5 seconds. LED1 indicator will flash rapidly.
2. On your Android device, search for "Gamepad Plus V3" in the Bluetooth settings and select it to pair. After successful pairing, LED1 will remain steadily lit.
3. The controller supports direct play for games like Arena of Valor and PUBG Mobile.

Note: Once connected, press the HOME button for 5 seconds to reconnect in the future.

PC / PlayStation 3 / Smart TV / TV Box Connection (2.4G Wireless)

1. Plug the 2.4G USB dongle into a USB interface on your PC, PlayStation 3, Smart TV, or TV Box.
2. Press and hold the "LB" button + "HOME" button for 5 seconds. LED1 and LED2 indicators will flash rapidly.

3. Once connected, LED1 and LED2 will remain steadily lit.

Note: The default gamepad mode for PC is X-input 360. To switch to D-input mode, press and hold "SELECT" + "START" simultaneously.



Image: The Maegoo Wireless Game Controller demonstrating compatibility with Android 6.0+, iOS 11.3-13.3.1, Windows 7/8/10, PlayStation 3, and Smart TV/TV Box devices.

OPERATING INSTRUCTIONS

Custom Key Mapping for Mobile Games

For mobile games that do not support direct controller input, you can use the **ShootingPlus V3** application to customize key positions. This allows you to map controller buttons to on-screen touch controls.

- Search for "ShootingPlus V3" in your device's app store (Google Play Store for Android, Apple App Store for iOS).
- Download and install the latest version of the application.
- Follow the in-app instructions to correctly map the buttons before playing.

Note: Adjust the sensitivity of the control buttons within the game settings as needed.

Custom Keys Mapping for Mobile Games



ShootingPlus V3



Google Play



App Store



**Using ShootingPlus V3
APP to customize the
key position and to
play more games!!!**

**ShootingPlus V3 APP
can be Downloaded
on Google Play or
APP Store**

Image: The controller with a phone attached, illustrating the custom key mapping feature for mobile games using the ShootingPlus V3 app.

Dual Vibration Function

The controller features built-in dual motors that provide vibration feedback. This function enhances immersion by allowing you to feel in-game actions such as impacts, crashes, and explosions.



Image: The controller highlighting its dual vibration function, shown with a racing game on a TV screen.



Image: A user demonstrating the Maegoo Wireless Game Controller during a soccer game on a television, highlighting its use in a typical gaming setup.

Battery Life and Power Saving

The controller is equipped with a built-in 500mAh lithium battery. A full charge provides approximately 13-15 hours of continuous use. To conserve power, the gamepad will automatically enter power-saving mode and shut down if there is no operation for about 5 minutes.

Lithium Battery **Playing Time** **Standby Time**
500mAh **13-15Hours** **30 Days**



Image: Visual representation of the controller's battery specifications: 500mAh lithium battery, 13-15 hours playing time, and 30 days standby time.

Ergonomic Design and Retractable Bracket

The wireless game controller features an ergonomic design with a comfortable grip made from high-quality plastic. The retractable bracket can securely hold mobile phones up to 6 inches wide, providing a convenient setup for mobile gaming.



Image: Labeled diagram of the controller, detailing its components including the retractable bracket, L1&L2/R1&R2 buttons, Select/Start buttons, joysticks, D-Pad, A/B/X/Y buttons, Home button, and LED indicators. The bracket supports phones from 3.5 to 6 inches.

MAINTENANCE

- Keep the controller dry and away from moisture.
- Avoid exposing the controller to extreme temperatures.
- Clean the controller with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the controller in a safe place when not in use to prevent damage.

TROUBLESHOOTING

- **Controller not connecting:**
 - Ensure the controller is fully charged.
 - Verify you are using the correct pairing method (Bluetooth for Android, 2.4G dongle for PC/PS3/TV).
 - For Bluetooth, ensure your device's Bluetooth is enabled and the controller is in pairing mode.
 - For 2.4G, ensure the USB dongle is securely plugged in and the controller is in 2.4G pairing mode.
 - Try restarting both the controller and the device you are trying to connect to.

- **Buttons not responding or incorrect input:**

- Check if the controller is correctly paired and connected.
- For PC, ensure the correct input mode (X-input or D-input) is selected for the game.
- For mobile games, ensure the ShootingPlus V3 app is configured correctly for key mapping.
- Test the controller with another game or device to isolate the issue.

- **Vibration not working:**

- Ensure the game you are playing supports vibration feedback.
- Check in-game settings to ensure vibration is enabled.

SPECIFICATIONS

Operating Voltage	DC 3.7V
Operating Current	30 mA
Charging Voltage/Current	DC 5V/300 mA
Wireless Transmission Distance	≤ 8 meters
Standby Time	30 days
Battery Capacity	500mAh
Compatible Devices	Android 6.0+, Windows 7/8/10, PlayStation 3, Smart TV, TV Box
Connectivity Technology	Bluetooth, 2.4G USB Dongle
Dimensions	19.4 x 14.1 x 7.1 cm
Weight	370 grams

WARRANTY INFORMATION

Please refer to the product packaging or the retailer's website for specific warranty details. Typically, electronic products come with a limited warranty covering manufacturing defects. Keep your proof of purchase for any warranty claims.

SUPPORT

For further assistance, technical support, or inquiries regarding your Maegoo Wireless Game Controller, please contact the retailer or manufacturer directly. Contact information can usually be found on the product packaging or the official Maegoo website.

You may also visit relevant online forums or communities for user-generated solutions and tips.