

Elo 2202L

Elo 2202L 22-inch Touchscreen Monitor Instruction Manual

Model: 2202L (E126096)

This manual provides essential information for the setup, operation, and maintenance of your Elo 2202L Touchscreen Monitor.

1. INTRODUCTION

The Elo 2202L is a 22-inch touchscreen monitor designed for various applications requiring interactive display solutions. It features a compact form factor, a clean design, and Elo's TouchPro PCAP technology, offering wide viewing angles, clear image quality, and accurate 10-touch response.

This monitor is suitable for environments such as point-of-sale, information kiosks, digital signage, and hospitality, providing a tablet-like experience for users.

2. WHAT'S IN THE BOX

Upon unpacking, ensure all the following items are present:

- Elo 2202L 22-inch Touchscreen Monitor
- Monitor Stand Base
- Stand Attachment Piece
- HDMI Cable
- USB-A to USB-B Cable (for touch functionality)
- Power Adapter
- User Manual (this document)

Video: Unboxing and initial setup of a 22-inch touchscreen monitor, demonstrating included components and basic connections.

3. SETUP INSTRUCTIONS

Follow these steps to set up your Elo 2202L Touchscreen Monitor:

1. **Attach the Stand:** Securely attach the stand attachment piece to the back of the monitor, then connect the monitor to the stand base. Ensure all connections are firm.
2. **Connect Power:** Plug the power adapter into the monitor's power input port and then into a wall outlet.
3. **Connect Video:** Use the provided HDMI cable to connect the monitor's HDMI input to your computer's HDMI output.
4. **Connect Touch Functionality:** Connect the USB-A end of the USB cable to your computer and the USB-B end to the monitor's USB input port. This enables the touch features.
5. **Power On:** Press the power button on the monitor. Your computer should detect the new display.



Image: Front view of the Elo 2202L 22-inch Touchscreen Monitor, showcasing its sleek design.

4. OPERATING THE MONITOR

4.1 Touchscreen Functions

The Elo 2202L supports 10-point multi-touch, allowing for intuitive interaction similar to a tablet. You can use gestures such as tapping, swiping, pinching, and zooming directly on the screen.

4.2 Adjusting Display Settings

The monitor features accessible control buttons, typically located on the side or bottom edge, for adjusting various settings:

- **Power:** Turns the monitor on or off.
- **Menu:** Accesses the On-Screen Display (OSD) menu.
- **Navigation Buttons:** Used to navigate through OSD menu options and adjust values (e.g., brightness, contrast, volume).
- **Input Select:** Changes the video input source (e.g., HDMI, VGA).

Refer to the on-screen menu for detailed options including color temperature, aspect ratio, and touch mode

calibration.

4.3 Multiple Display Modes

When connected to a computer, you can configure the monitor to operate in different display modes:

- **Duplicate Displays:** Shows the same content on both your primary display and the Elo 2202L.
- **Extend Displays:** Expands your desktop across both displays, allowing you to drag windows between them.
- **Show Only on 1/2:** Displays content only on one selected monitor.

These settings are typically managed through your operating system's display settings (e.g., Windows Display Settings or macOS System Preferences).

5. MAINTENANCE

To ensure the longevity and optimal performance of your Elo 2202L monitor, follow these maintenance guidelines:

- **Cleaning the Screen:** Use a soft, lint-free cloth lightly dampened with a non-abrasive, ammonia-free glass cleaner. Do not spray cleaner directly onto the screen.
- **Cleaning the Casing:** Wipe the monitor casing with a soft, dry cloth. Avoid harsh chemicals or abrasive materials.
- **Ventilation:** Ensure the monitor's ventilation openings are clear and unobstructed to prevent overheating.
- **Storage:** When not in use for extended periods, store the monitor in a cool, dry place, ideally in its original packaging.

6. TROUBLESHOOTING

If you encounter issues with your monitor, try the following solutions:

- **No Display:**
 - Check if the power cable is securely connected to both the monitor and the power outlet.
 - Verify the video cable (HDMI) is properly connected to both the monitor and your computer.
 - Ensure the correct input source is selected on the monitor via the OSD menu.
- **Touch Function Not Working:**
 - Confirm the USB-A to USB-B cable is securely connected between the monitor and your computer.
 - Restart your computer.
 - Check your operating system's device manager for any issues with touch drivers.
- **Image Quality Issues:**
 - Adjust brightness, contrast, and color settings through the OSD menu.
 - Ensure your computer's display resolution is set to the recommended 1920 x 1080 pixels.

7. SPECIFICATIONS

Feature	Detail
Brand	Elo
Model Number	E126096 (2202L)

Screen Size	21.5 Inches (Standing screen display size)
Resolution	1920 x 1080 Pixels (FHD 1080p)
Aspect Ratio	16:9
Screen Surface Description	Glossy
Total USB Ports	2
Product Dimensions	1.7 x 20.7 x 12.9 inches
Item Weight	10.47 pounds
Manufacturer	Elo Touch Solutions, Inc.
First Available Date	March 28, 2020



8. WARRANTY AND SUPPORT





Your Elo 2202L Touchscreen Monitor is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Elo website.

For technical support, troubleshooting assistance, or service inquiries, please contact Elo customer support through their official channels. Contact information can typically be found on the manufacturer's website or in the product documentation.

© 2023 Elo Touch Solutions, Inc. All rights reserved.

Related Documents - 2202L

	<p>19.5-inch Touchscreen Monitor Kit Installation Instructions</p> <p>Detailed installation instructions for the Elo 19.5-inch Touchscreen Monitor Kit by SEL, including component lists, step-by-step assembly, specifications, and technical support information.</p>
	<p>Elo IntelliTouch/SecureTouch Touchscreen Guide</p> <p>Comprehensive guide to installing, integrating, and troubleshooting Elo IntelliTouch and SecureTouch touchscreen technologies. Covers component installation, technical specifications, and troubleshooting for various Elo controllers.</p>

 <hr data-bbox="129 322 301 327"/>	<p>Elo Touch Solutions ET1002L, ET1502L, ET2002L Touchscreen Monitors User Manual</p> <p>User manual for Elo Touch Solutions ET1002L, ET1502L, and ET2002L touchscreen monitors, covering installation, operation, maintenance, safety, and regulatory information.</p>
	<p>Elo Self-Service Stand Assembly Instructions</p> <p>Assembly instructions for the Elo Self-Service Stand, including hardware lists and step-by-step guidance for attaching various components like display brackets, USB hubs, and printers.</p>
	<p>Elo ET1502LM Touch Monitor User Manual</p> <p>User manual for the Elo ET1502LM touch monitor, covering product description, installation, mounting, operation, technical support, safety, regulatory information, and warranty.</p>
	<p>Elo ET0702L Touch Monitor User Manual</p> <p>Comprehensive user manual for the Elo ET0702L Touch Monitor, covering product description, installation, mounting, operation, technical support, safety, maintenance, regulatory information, and warranty details.</p>