Baby Born 829271

Baby Born Highchair Model 829271 Instruction Manual

For Zapf Creation Baby Born Dolls

Visit the Baby Born Store

Introduction

Thank you for choosing the Baby Born Highchair, Model 829271. This high-quality accessory is designed to provide an engaging play experience for children with their Baby Born dolls. The highchair features a comfortable seat, a sturdy tray, and a modern design with wood-effect legs. This manual provides essential information for assembly, safe use, and maintenance of your product.



Image: The fully assembled Baby Born Highchair, featuring a pink seat with a bear and duck design, a white tray, and four wood-effect legs with white feet.

Safety Information

Please read all safety instructions before assembly and use. Keep this manual for future reference.

- **Recommended Age:** This product is suitable for children aged 3 years and older.
- **Adult Supervision:** Always ensure children are supervised during play, especially during assembly.
- **Assembly:** Adult assembly is required. Ensure all parts are securely fastened before allowing a child to play with the highchair.
- **Intended Use:** This highchair is designed exclusively for Baby Born dolls (43 cm and 36 cm) and similar sized dolls. It is not intended for use with real infants or pets.
- **Small Parts:** The product may contain small parts before assembly. Keep these away from young children to prevent choking hazards.
- **Stability:** Place the highchair on a flat, stable surface to prevent tipping.



Image: A section of the product packaging displaying safety certifications and symbols, including the recommended age of 3+ and a '0-3' crossed out symbol, indicating it is not suitable for children under 3 years.

Package Contents

The Baby Born Highchair package includes the following components:

- Highchair seat (pink)
- Highchair tray (light pink/white)
- Four wood-effect legs
- Connecting ring/support for legs
- Assembly hardware (screws, etc.)

Setup and Assembly

Assembly of the Baby Born Highchair is required and should be performed by an adult. Please follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify that all components listed in the 'Package Contents' section are present.
2. **Attach Legs:** Securely attach the four wood-effect legs to the underside of the highchair seat. Ensure they are firmly in place and stable.
3. **Install Connecting Ring:** Connect the legs using the provided connecting ring or support structure to enhance stability.
4. **Attach Tray:** Slide or clip the highchair tray into its designated position on the front of the seat. Ensure it is locked securely.
5. **Final Check:** Before use, gently shake the assembled highchair to confirm all connections are secure and the structure is stable.



Image: A child carefully placing a Baby Born doll into the assembled highchair, demonstrating the final stage of setup before play.

Operating Instructions

Using the Baby Born Highchair is straightforward and designed for imaginative play.

- **Placing the Doll:** Gently place your Baby Born doll (43 cm or 36 cm) into the highchair seat. The seat is designed to comfortably accommodate these doll sizes.
- **Using the Tray:** The light pink tray provides a surface for feeding your doll with play food, drawing, crafting, or playing with small toys.
- **Interactive Play:** Encourage children to engage in role-playing scenarios such as feeding, storytelling, and creative activities with their doll in the highchair.



Image: A child interacting with a Baby Born doll seated in the highchair, using a yellow bowl and spoon to simulate feeding.

Maintenance and Care

To ensure the longevity and cleanliness of your Baby Born Highchair, follow these care instructions:

- **Cleaning:** Wipe the highchair seat, tray, and legs with a damp cloth and mild soap if necessary. Avoid abrasive cleaners or harsh chemicals.
- **Drying:** Ensure all parts are thoroughly dry before storing or allowing further play.
- **Storage:** Store the highchair in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Inspection:** Periodically check all connections and parts for wear or damage. Discontinue use if any part is broken or compromised.

Troubleshooting

If you encounter any issues with your Baby Born Highchair, consider the following:

- **Instability:** If the highchair feels wobbly, re-check all leg connections and ensure the connecting ring is properly installed and tightened. Make sure it is placed on a flat, even surface.
- **Tray Not Securing:** Ensure the tray is correctly aligned with its attachment points and pushed firmly into place until it clicks or locks.
- **Damaged Parts:** If any part is broken or missing, do not attempt to repair it with non-original parts. Contact customer support for assistance.

Specifications

Feature	Detail
Model Number	829271
Product Dimensions	9.84 x 9.84 x 19.69 inches (25 x 25 x 50 cm)
Item Weight	1.63 pounds (0.74 kg)
Material	Plastic seat/tray, Wood-effect legs
Color	Pink
Recommended Age	3 years and up
Doll Compatibility	43 cm and 36 cm dolls
UPC/EAN	4001167829271

Note: The maximum weight recommendation of 15 kg found in some specifications refers to general highchair standards and is not applicable to this doll accessory. This product is intended for doll play only.

Warranty and Support

For any questions, concerns, or support regarding your Baby Born Highchair, please contact Zapf Creation customer service. Information may be available on the official Baby Born website or through your retailer.
Please retain your proof of purchase for any warranty claims.

Recycling and Disposal

When the product reaches the end of its useful life, please dispose of it responsibly according to local recycling guidelines. The packaging materials, primarily cardboard (PAP), should also be recycled.




Image: A portion of the product packaging displaying international recycling symbols, including the 'PAP' symbol for cardboard and a general recycling symbol, indicating responsible disposal.

© 2023 Zapf Creation AG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question