

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [NutriBullet](#) /
- › [NutriBullet NBY-50100 Baby Complete Food-Making System User Manual](#)

NutriBullet NBY-50100

NutriBullet Baby Complete Food-Making System

Model: NBY-50100 | Brand: NutriBullet

PRODUCT OVERVIEW

The NutriBullet Baby Food-Making System is designed to simplify the process of preparing fresh, wholesome baby food. This comprehensive system provides the essential tools needed to create nutritious meals from scratch quickly and efficiently, allowing for easy preparation, storage, and freezing of baby food.



Image: The complete NutriBullet Baby Food-Making System, showcasing the motor base, blending blade, batch bowl, short cup, storage cups with tray, and silicone freezer tray.

WHAT'S INCLUDED

Your NutriBullet Baby Complete Food-Making System includes the following components:

- **200-Watt Motor Base:** The core unit that powers the blending process.
- **Baby Blending Blade:** Specifically designed for pureeing baby food.
- **32-Ounce (900 ml) Batch Bowl with Lid:** For preparing larger quantities of baby food.
- **12-Ounce (355 ml) Short Cup with Handles and Re-sealable Lid:** Ideal for smaller portions or on-the-go feeding.
- **6 Storage Cups with Date Ring Lids and Storage Tray:** Convenient for storing prepared food and tracking freshness.

- **Silicone Freezer Tray with Lid:** For freezing individual portions of baby food.
- **Recipe Book & User Guide:** Provides recipes, tips, and detailed usage instructions.

Image: The 32-ounce batch bowl, designed for preparing larger quantities of baby food.



Image: The 12-ounce short cup with handles, suitable for individual servings.




Image: Six storage cups with date ring lids, organized on their dedicated storage tray for easy tracking of freshness.



Image: The silicone freezer tray, designed for freezing individual portions of baby food for later use.

SETUP

1. Unpack all components from the packaging.
2. Wash all cups, lids, and the blending blade with warm, soapy water before first use. Rinse thoroughly and dry. The motor base should only be wiped clean with a damp cloth.
3. Ensure the motor base is placed on a clean, dry, and level surface.
4. Attach the blending blade securely to your chosen cup (batch bowl or short cup) by twisting it on until tightly sealed.
5. Place the assembled cup onto the motor base, aligning the tabs on the cup with the slots on the base.

OPERATING INSTRUCTIONS

The NutriBullet Baby system offers simple, intuitive operation for preparing baby food:

1. Fill your chosen cup (batch bowl or short cup) with desired ingredients. Do not overfill past the MAX line.
2. Securely twist the baby blending blade onto the cup.
3. Place the assembled cup, blade-side down, onto the motor base.
4. To begin blending, press down firmly on the cup and twist clockwise until the motor activates.
5. Blend until desired consistency is achieved. For best results, blend in short bursts.
6. Once blending is complete, twist the cup counter-clockwise to release it from the motor base.
7. Remove the blending blade and pour the freshly made baby food into storage cups or serve immediately.



Simple, intuitive operation.

Just push and twist to puree, mash, mix, and chop.

Image: Illustrates the process of pouring freshly pureed baby food from the batch bowl into the silicone freezer tray for portioning and freezing.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and hygiene of your NutriBullet Baby system:

- All components, except the motor base, are dishwasher-safe for quick and easy cleanup.
- For manual cleaning, wash cups, lids, and the blending blade with warm, soapy water. Use a brush to clean the blade thoroughly.
- Wipe the motor base clean with a damp cloth. **Do not immerse the motor base in water or any other liquid.**
- Ensure all parts are completely dry before storing.
- The batch bowl and cups are made of non-toxic, BPA-free, super-durable plastic.

what's included.




Image: A hand washing the short cup, demonstrating the ease of cleaning for the system's components.

TROUBLESHOOTING

If you encounter issues with your NutriBullet Baby system, consider the following:

- **Unit Not Turning On:** Ensure the unit is properly plugged into a working electrical outlet. Verify that the cup and blade assembly are securely twisted onto the motor base.
- **Leaking:** Check that the blending blade is tightly twisted onto the cup. Ensure the gasket on the blade is properly seated and not damaged. Do not overfill the cup.
- **Inconsistent Blending:** Ensure ingredients are cut into small, manageable pieces. Add a small amount of liquid if ingredients are too thick. Blend in short pulses rather than continuous operation.
- **Overheating:** If the motor stops during use, unplug the unit and allow it to cool down for at least 15 minutes before attempting to use it again. Avoid continuous blending for extended periods.

SPECIFICATIONS

Feature	Detail
Brand	NutriBullet
Model Name	NutriBullet Baby
Item Model Number	NBY-50100
Product Dimensions	5.4"D x 5.2"W x 11"H
Item Weight	4.55 pounds
Color	White, Blue, Clear
Bowl Capacity	32 Ounce (900 Milliliters)
Power Source	Corded Electric
Blade Material	Plastic
Dishwasher Safe	Yes (except motor base)
Recommended Uses	Blend, Chop, Mixing, Pureeing
UPC	818049023221

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official user manual provided with your

product or visit the NutriBullet website.
You can also access the User Manual (PDF) [here](#).