

[Manuals.plus](#) /

› [TYC](#) /

› TYC Wireless Mouse TYC-018-5 User Manual

TYC TYC-018-5

TYC Wireless Mouse TYC-018-5 User Manual

Model: TYC-018-5

1. PRODUCT OVERVIEW

The TYC Wireless Mouse is a 2.4GHz rechargeable optical mouse designed for comfort and efficiency. It features silent clicks, adjustable DPI settings, and broad compatibility with various devices through its dual USB and Type-C receiver. This manual provides instructions for setup, operation, maintenance, and troubleshooting.

2. PACKAGE CONTENTS

- TYC Wireless Mouse
- USB Receiver (stored inside the mouse battery cover)
- Type-C Adapter
- USB Charging Cable
- User Manual (this document)

3. SETUP INSTRUCTIONS

3.1. Locating the Receiver

The USB receiver is conveniently stored within the mouse battery cover. Gently open the battery cover on the underside of the mouse to retrieve it.

TECNOLOGÍA AVANZADA DE 2.4 G

Inalámbrico sin demoras



Figure 1: The TYC wireless mouse operating in 2.4G wireless mode, with an illustration of the USB receiver. The image highlights the wireless connectivity to a laptop.

3.2. Connecting to Your Device

1. Remove the USB receiver from its storage compartment in the mouse.
2. **For USB-A Ports:** Plug the USB receiver directly into an available USB-A port on your computer or device.
3. **For Type-C Ports:** Attach the Type-C adapter to the USB receiver, then plug the combined unit into an available Type-C port on your computer or device.
4. Turn on the mouse using the power switch located on its underside.
5. Your device should automatically detect and install the necessary drivers. The mouse will be ready for use within a few seconds.

3.3. Initial Charging

Before first use, it is recommended to fully charge the mouse. Connect the provided USB charging cable to the mouse's

charging port and to a USB power source (e.g., computer USB port, USB wall adapter). A full charge typically takes 1.5-2 hours.



Figure 2: The TYC wireless mouse positioned near a laptop, emphasizing its long-lasting battery. An icon of a battery with a lightning bolt signifies its rechargeable nature.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

Locate the power switch on the underside of the mouse. Slide it to the "ON" position to activate the mouse. Slide it to "OFF" when not in use to conserve battery life.

4.2. DPI Adjustment

The mouse features 3 adjustable DPI levels: 1000, 1200, and 1600. Press the DPI button (usually located behind the scroll wheel) to cycle through these settings. Each press will change the cursor sensitivity, allowing you to select the speed that best suits your task.



**AJUSTE
DPI DE TRES ETAPAS**

Operación suave y receptiva, posicionamiento
preciso durante el movimiento rápido

1000 . 1200 . 1600

Figure 3: A close-up of the TYC wireless mouse, highlighting its three-stage DPI adjustment capability (1000, 1200, 1600). This feature allows for smooth and precise cursor control.

4.3. Silent Click Feature

The TYC Wireless Mouse is designed with special soundless buttons for the left and right clicks. This feature minimizes noise, making it ideal for quiet environments such as libraries, offices, or cafes, ensuring you do not disturb others.

CLIC TRANQUILA Y DURADERA

Mantente enfocado sin molestar a los demás



PORTÁTIL Y COMPACTA

Pequeño y muy portátil



Diseño de
ahorro de energía



Symmetrical for
both hands



Comfortable
grip



Figure 4: A user's hand operating the TYC wireless mouse, with a visual cue for its quiet click functionality. The image also showcases the mouse's compact and portable design, fitting easily into a bag.

4.4. Compatibility

This mouse is compatible with a wide range of operating systems and devices, including Windows 7/8/10/XP, Vista, Mac OS X 10.10 or above, and Chrome OS. It is suitable for laptops, PCs, MacBooks, iMacs, Chromebooks, tablets, and mobile phones with compatible USB or Type-C ports.



Figure 5: A collage displaying the TYC wireless mouse in various usage scenarios, including with a desktop setup and two different laptops, emphasizing its versatility across multiple devices and environments.

5. MAINTENANCE

5.1. Charging the Battery

The mouse features a built-in 450mAh rechargeable battery. When the battery is low, connect the mouse to a power source using the provided USB charging cable. The charging indicator light will typically illuminate during charging and turn off or change color when fully charged. Avoid overcharging for extended periods.

5.2. Cleaning

To clean the mouse, gently wipe its surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish. Ensure no liquid enters the mouse's internal components.

5.3. Storage

When not in use for an extended period, turn off the mouse to preserve battery life. Store the USB receiver inside the mouse's battery compartment to prevent loss.

6. TROUBLESHOOTING

6.1. Mouse Not Responding

- Ensure the mouse is turned on.
- Check if the USB receiver is securely plugged into your device's USB or Type-C port.
- Try plugging the receiver into a different USB or Type-C port.
- Ensure the mouse is charged. Connect it to the charging cable for a few minutes.
- Restart your computer or device.
- Ensure there are no strong wireless interferences nearby (e.g., other 2.4GHz devices).

6.2. Erratic Cursor Movement

- Clean the optical sensor on the underside of the mouse.
- Ensure you are using the mouse on a suitable surface. Highly reflective or transparent surfaces may affect tracking. A mouse pad is recommended.
- Adjust the DPI setting to see if it improves performance.

6.3. Mouse Not Charging

- Verify that the USB charging cable is properly connected to both the mouse and the power source.
- Try using a different USB port or power adapter.
- Ensure the charging cable is not damaged.

7. SPECIFICATIONS

Brand	TYC
Model	TYC-018-5
Connectivity Technology	2.4GHz Wireless (USB Receiver, Type-C Adapter)
Movement Detection Technology	Optical
DPI Levels	1000 / 1200 / 1600
Number of Buttons	6
Special Features	Ergonomic Design, Portable, Wireless, Rechargeable, Silent Click
Battery Capacity	450mAh (Built-in Rechargeable)
Charging Time	Approx. 1.5-2 hours
Compatible Operating Systems	Windows 7/8/10/XP, Vista, Mac OS X 10.10+, Chrome OS
Hand Orientation	Ambidextrous

Color	Black
-------	-------

8. WARRANTY AND SUPPORT

TYC products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official TYC website. Please retain your proof of purchase for warranty claims.

© 2026 TYC. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question