

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Habitdesign](#) /

› [Habitdesign LCX453F Wardrobe with 3 Doors and 4 Drawers \(200x135x52 cm\) Instruction Manual](#)

Habitdesign LCX453F

Habitdesign LCX453F Wardrobe with 3 Doors and 4 Drawers (200x135x52 cm) Instruction Manual

Model: LCX453F

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Habitdesign LCX453F wardrobe. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Important Safety Information

Warning: Follow all assembly and usage instructions to prevent injuries. Regularly check the stability of the furniture. Do not overload drawers and shelves. Do not use sharp objects to clean the furniture.

- Ensure all components are present and undamaged before assembly.
- Assemble the wardrobe on a soft, clean surface to prevent scratches.
- Always use the appropriate tools as specified in the assembly guide.
- It is recommended that two people assemble this wardrobe for safety and ease.
- Secure the wardrobe to the wall using anti-tip hardware (if included) to prevent tipping.

2. PACKAGE CONTENTS

Before starting assembly, verify that all parts listed below are present in your package:

- 3 Shelves (2 adjustable in height)
- 1 Hanging Rail
- Drawers (components for 4 drawers)
- Hardware (screws, dowels, connectors, metal handles)
- Instruction Manual (this document)
- All necessary wooden panels for the wardrobe structure, doors, and drawers.

Note: In case of missing or damaged parts, please contact Habitdesign customer support.

3. SPECIFICATIONS

Dimensions (Height x Width x Depth)	200 cm x 135 cm x 52 cm
Small Drawer Capacity (Height x Width x Depth)	13 cm x 39.5 cm x 45 cm
Large Drawer Capacity (Height x Width x Depth)	13 cm x 84.5 cm x 45 cm
Maximum Supported Weight (Total)	50 kg
Maximum Supported Weight (Hanging Rail)	8 kg
Maximum Supported Weight (Shelf)	8 kg
Maximum Supported Weight (Drawer)	5 kg
Material	High-quality melamine particle board (PEFC certified)
Color	Canadian Oak (Exterior), White (Interior)
Origin	Spain




Figure 1: Wardrobe dimensions (Height: 200 cm, Width: 135 cm, Depth: 52 cm).

4. ASSEMBLY INSTRUCTIONS

Please follow these steps carefully. It is highly recommended to have two people for assembly. A drill may be helpful for pre-drilling pilot holes, as some holes may only be marked.

Step 4.1: Prepare the Area and Identify Components

1. Clear a spacious, clean, and flat area for assembly.
2. Unpack all boxes and lay out the components. Identify each panel and hardware piece using the provided instruction booklet (similar to IKEA style).
3. Separate screws, dowels, and other hardware into labeled groups if possible.

Step 4.2: Assemble the Base and Side Panels

1. Attach the base panel to the side panels using the designated connectors and screws.
2. Ensure all connections are secure and the frame is stable.

Step 4.3: Install Back Panels and Internal Dividers

1. Carefully slide or nail the back panels into place, ensuring they are flush and square with the frame.
2. Install the central vertical dividers and any fixed horizontal shelves according to the diagrams.



Figure 2: Internal structure of the wardrobe with doors open.

Step 4.4: Install Shelves and Hanging Rail

1. Insert the shelf supports into the pre-drilled holes for the adjustable shelves. Place the shelves on top.
2. Attach the hanging rail brackets to the side panels and secure the hanging rail.



Figure 3: Detail of the hanging rail installation.

Step 4.5: Assemble and Install Drawers

1. Assemble each drawer box by connecting the side, front, and back panels. Secure the bottom panel.
2. Install the drawer runners onto the drawer boxes and the corresponding runners inside the wardrobe frame.
3. Attach the metal handles to the drawer fronts. Ensure the edges are smooth to prevent injury.
4. Carefully slide the assembled drawers into their respective compartments.



Figure 4: Example of a drawer handle.

Step 4.6: Attach Doors and Adjust

1. Attach the hinges to the doors and then to the wardrobe frame.
2. Secure the door handles.
3. Adjust the hinges to ensure the doors align properly and close smoothly without gaps. This step may require patience and fine-tuning.

Step 4.7: Final Checks and Securing

1. Verify that all screws and connectors are tightened.
2. If anti-tip hardware is provided, secure the wardrobe to the wall to prevent accidental tipping, especially in households with children.



Figure 5: Fully assembled wardrobe.

5. OPERATING INSTRUCTIONS

- **Doors:** Gently open and close the three hinged doors. Avoid forcing them to prevent damage to hinges or panels.
- **Drawers:** Pull drawers open and push them closed smoothly. Do not overload drawers beyond their specified weight capacity (5 kg per drawer).
- **Adjustable Shelves:** To adjust shelf height, carefully remove the shelf, reposition the shelf supports in the desired holes, and then place the shelf back. Ensure the shelf is level and securely seated.
- **Hanging Rail:** Use the hanging rail for clothes. Do not exceed the maximum weight capacity of 8 kg.




Figure 6: Example of wardrobe interior with items stored.

6. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or sharp objects that could damage the melamine finish.
- **Regular Checks:** Periodically check all screws and fittings to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Moisture:** Protect the wardrobe from excessive moisture and direct sunlight to prevent warping or discoloration.
- **Weight Distribution:** Distribute weight evenly across shelves and drawers to prevent stress on the structure.

7. TROUBLESHOOTING

Problem	Possible Cause / Solution
Wardrobe is wobbly or unstable.	Ensure all screws and connectors are fully tightened. Verify the wardrobe is on a level surface. If applicable, use anti-tip hardware to secure it to the wall.
Doors do not align or close properly.	Adjust the hinges. Most hinges have screws for horizontal, vertical, and depth adjustments. Refer to the specific hinge adjustment instructions in your assembly booklet.

Drawers stick or do not slide smoothly.	Check that drawer runners are correctly installed and aligned. Ensure drawers are not overloaded. Lubricate runners with a silicone spray if necessary.
Missing parts or damaged components.	Contact Habitdesign customer support with your product model number and a description of the issue.

8. WARRANTY AND SUPPORT

Habitdesign products are manufactured with quality and durability in mind. For specific warranty information, please refer to the documentation included with your purchase or visit the official Habitdesign website.

For customer support, assistance with assembly, or to report missing/damaged parts, please contact Habitdesign directly. You can find more information and contact details on the [Habitdesign Brand Store](#). *Please retain your proof of purchase for any warranty claims.*

Related Documents - LCX453F

	<p>Catálogo Detallado de Productos y Precios</p> <p>Explore un extenso catálogo de productos que abarca mejoras para el hogar, artículos de cocina, equipos deportivos, productos para bebés y más. Cada artículo incluye una descripción detallada y precio.</p>
--	---