

Anker A3301

Anker PowerConf A3301 Bluetooth Speakerphone User Manual

1. INTRODUCTION

The Anker PowerConf A3301 is a portable Bluetooth speakerphone designed for clear and efficient conference calls. It features omni-directional voice pickup, smart voice enhancement, and universal compatibility, making it suitable for various communication platforms.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- Anker PowerConf A3301 Speakerphone
- USB-C to USB-A Cable
- Travel Case
- User Manual (this document)
- Safety and Warranty Information

3. PRODUCT OVERVIEW

3.1. Controls and Indicators

The Anker PowerConf A3301 features intuitive controls and indicators for easy operation.

BACKGROUND NOISE REDUCTION

تقليل الضوضاء في الخلفية



Image: Top view of the Anker PowerConf A3301 speakerphone, showing the central control panel with touch buttons for call management, volume, and mute.

- **Call Button:** Answer or end calls. Press and hold for 2 seconds to reject a call.
- **Volume Up/Down Buttons:** Adjust speaker volume.
- **Mute Button:** Mute or unmute the microphone. The indicator light turns red when muted.
- **Power Button:** Turn the device on or off.
- **Bluetooth Button:** Initiate Bluetooth pairing mode.
- **LED Indicators:** Provide visual feedback for power, Bluetooth status, volume level, and microphone mute status.

3.2. Ports

The device includes several ports for connectivity and charging.



Image: Side view of the Anker PowerConf A3301 speakerphone, highlighting the USB-A, Aux Out, and USB-C (Power) ports.

- **USB-C Port (Power):** For charging the speakerphone and connecting to a computer.
- **USB-A Port:** For charging other devices using the speakerphone's internal battery.
- **Aux Out Port:** For connecting to external audio devices.

4. SETUP

4.1. Charging the Speakerphone

Before initial use, fully charge the Anker PowerConf A3301.

1. Connect the provided USB-C cable to the PowerConf's USB-C port.
2. Connect the other end of the cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The LED indicators will show charging progress and turn solid when fully charged.

4.2. Connecting to Devices

The PowerConf A3301 offers both Bluetooth and USB-C connectivity.



Image: Graphic illustrating the dual connectivity options: USB-C for computers and Bluetooth for mobile devices.

4.2.1. Bluetooth Connection

1. Press and hold the Power button for 2 seconds to turn on the PowerConf.
2. Press the Bluetooth button. The LED indicators will flash blue, indicating pairing mode.
3. On your mobile device, enable Bluetooth and select "Anker PowerConf" from the list of available devices.
4. Once connected, the LED indicators will turn solid blue.

4.2.2. USB-C Connection

1. Connect the PowerConf to your computer using the provided USB-C cable.
2. The device will be automatically recognized by your computer, requiring no driver installation.

5. OPERATING THE SPEAKERPHONE

5.1. Making and Receiving Calls

Use the central control panel for call management.

- **Answer Call:** Press the Call button once.
- **End Call:** Press the Call button once during an active call.
- **Reject Call:** Press and hold the Call button for 2 seconds when a call is incoming.
- **Adjust Volume:** Use the Volume Up (+) and Volume Down (-) buttons.
- **Mute Microphone:** Press the Mute button. The LED ring will turn red. Press again to unmute.

5.2. Voice Pickup and Enhancement

The PowerConf A3301 is equipped with 6 omni-directional microphones and smart voice enhancement technology.



Image: Graphic illustrating the automatic voice enhancement feature of the Anker PowerConf A3301.

- The 360° microphone array picks up voices from all directions, suitable for up to 8 people in a room.
- A custom DSP algorithm provides real-time echo cancellation (up to 70 dB) and reduces background noise (by 20 dB) for clear communication.
- Automatic voice balancing adjusts the sound of voices to compensate for differences in volume and distance from the speakerphone.

5.3. Charging Other Devices

The PowerConf A3301 can act as a power bank for your mobile devices.



Image: The Anker PowerConf A3301 speakerphone connected via USB-A to charge a smartphone.

1. Connect your device to the USB-A port on the PowerConf using a compatible charging cable.
2. The integrated Anker PowerIQ technology will charge your device at optimized speeds.

6. MAINTENANCE

6.1. Cleaning

To maintain the device's performance and appearance:

- Wipe the surface with a soft, dry cloth.
- Do not use harsh chemicals or abrasive cleaners.

6.2. Storage

When not in use for extended periods:

- Store the speakerphone in its provided travel case to protect it from dust and damage.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your Anker PowerConf A3301, refer to the following common solutions:

Problem	Possible Cause	Solution
Cannot power on	Low battery	Charge the speakerphone fully.
Cannot connect via Bluetooth	Not in pairing mode / Device too far	Press the Bluetooth button to enter pairing mode. Ensure device is within 10 meters.
Poor audio quality	Interference / Device too far / Muted microphone	Move closer to the speakerphone. Check for obstructions. Ensure microphone is not muted.
Microphone not picking up voice	Microphone muted / Software settings	Ensure the microphone is not muted. Check audio input settings on your computer/device.

8. SPECIFICATIONS

Feature	Detail
Model Number	A3301
Connectivity	Bluetooth 5.0, USB-C
Microphones	6 Omni-directional microphones
Voice Pickup Range	Up to 8 people in a room
Battery Capacity	6700 mAh
Call Time	Up to 24 hours
Dimensions	4.84"D x 4.88"W x 1.18"H
Weight	12 ounces
Material	Plastic

9. WARRANTY AND SUPPORT

Anker provides a limited warranty for this product. Please refer to the included 'Safety and Warranty Information' document for full details regarding your warranty coverage.

For technical support, product information, or warranty claims, please contact Anker customer service through their official website or the contact information provided in your warranty documentation.

Online Support: www.anker.com/support

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question