

- Manuals.plus /
- > [RecPro](#) /
  - > RecPro Charles 67" Double Recliner RV Sofa User Manual

RecPro Charles 67" Double Recliner RV Sofa

# RecPro Charles 67" Double Recliner RV Sofa User Manual

Model: Charles 67" Double Recliner RV Sofa | Brand: RecPro

## INTRODUCTION

This manual provides essential information for the safe and efficient use of your RecPro Charles 67" Double Recliner RV Sofa. Please read these instructions carefully before installation and operation.



Image: The RecPro Charles 67" Double Recliner RV Sofa, showcasing its design and color.

## SAFETY INFORMATION

---

For your safety and to prevent damage to the product, observe the following precautions:

- Keep the sofa away from open flames or high heat sources.
- Supervise children and pets to avoid entrapment risks when using the reclining mechanism or accessing the console storage.
- Ensure adequate clearance around the sofa, especially when reclining, to prevent obstruction or damage.
- Do not exceed the maximum weight limit of 198 pounds per seat.

## SETUP AND INSTALLATION

---

The RecPro Charles RV Sofa features a modular design for easier transport and assembly. While assembly is generally straightforward, it is recommended that two people perform the installation.

### Unpacking and Component Identification:

1. Carefully remove all components from the packaging. The sofa comes in multiple pieces for ease of movement.
2. Verify all parts are present. Each piece is typically stored in a cloth drawstring bag.

### Assembly Steps:

- Position the individual sofa sections in the desired location within your RV. Ensure your door width is at least 22 inches for easy entry.
- Connect the modular sections using the integrated component connectors. These are designed to hook together seamlessly without tools.
- Ensure all connections are secure before use.



*Image: Illustration of the modular design, showing how the sofa sections connect.*

## OPERATING INSTRUCTIONS

---

### Reclining Function:

This sofa features two reclining seats. To recline, gently push back on the seat while engaging the reclining mechanism (typically a lever on the side). The "Zero Wall" design allows the sofa to recline with minimal clearance from the wall (approximately 3 inches).



*Image: The RecPro Charles RV Sofa with both seats fully reclined.*

### **Console and Cupholders:**

The central console includes two cupholders and a storage compartment. Lift the console lid to access the storage area. Ensure the lid is securely closed when not in use.



Image: The central console of the sofa with the storage compartment lid open, showing the cupholders.

## CARE AND MAINTENANCE

---

### Upholstery Cleaning:

The Suprima cloth upholstery is durable and designed for longevity. For cleaning, follow these guidelines:

- **Spot Cleaning:** For small spills or stains, use a clean cloth with mild soap and water. Blot the area gently; do not rub vigorously.
- **General Cleaning:** The upholstery cleaning code recommends hand washing or professional dry cleaning. Consult a professional upholstery cleaner for deep cleaning to maintain fabric integrity.
- **Removable Seat Cushion Covers:** The seat cushion covers are removable for easier cleaning. Follow the care instructions on the label.

### General Care:

- Vacuum regularly to remove dust and debris.
- Avoid direct sunlight exposure for prolonged periods to prevent fading.
- Periodically check all connections and mechanisms to ensure they are secure and functioning correctly.

## TROUBLESHOOTING

---

If you encounter any issues with your RecPro Charles RV Sofa, please refer to the following common solutions:

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem                                    | Possible Cause                                               | Solution                                                                                                                                                                   |
|--------------------------------------------|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Reclining mechanism not engaging smoothly. | Obstruction, mechanism misalignment, or lack of lubrication. | Check for any objects obstructing the mechanism. Ensure the sofa is not pressed too tightly against a wall. Apply a silicone-based lubricant to moving parts if necessary. |
| Sofa sections feel loose.                  | Connectors are not fully engaged.                            | Re-engage the modular connectors between the sections, ensuring they are securely locked.                                                                                  |
| Unusual noises during operation.           | Loose fasteners or friction in moving parts.                 | Inspect all visible fasteners and tighten if loose. Lubricate moving parts of the reclining mechanism.                                                                     |

If the issue persists after attempting these solutions, please contact RecPro customer support.

## PRODUCT SPECIFICATIONS

| Feature                         | Detail                                                    |
|---------------------------------|-----------------------------------------------------------|
| Brand                           | RecPro                                                    |
| Model                           | Charles 67" Double Recliner RV Sofa                       |
| Color                           | Fossil                                                    |
| Type                            | Loveseat                                                  |
| Product Dimensions (D x W x H)  | 37.5"D x 67"W x 38"H                                      |
| Reclined Length                 | 62.5 Inches                                               |
| Furniture Wall Clearance        | 3 Inches                                                  |
| Minimum Required Door Width     | 22 Inches                                                 |
| Item Weight                     | 166 Pounds                                                |
| Weight Capacity Maximum         | 198 Pounds per seat                                       |
| Seating Capacity                | 2                                                         |
| Upholstery Fabric Type          | Linen (Suprima Cloth)                                     |
| Frame Material Type             | Wood                                                      |
| Seat Fill Material              | Foam                                                      |
| Assembly Required               | No (Component Connector Assembly: Installation Required)  |
| Recommended People for Assembly | 2                                                         |
| Additional Features             | Recliner, Space Saving, Storage (Console with Cupholders) |




Image: Diagram showing the key dimensions of the RecPro Charles 67" RV Sofa.

## WARRANTY INFORMATION

The RecPro Charles 67" Double Recliner RV Sofa comes with a **Limited Warranty**. For specific details regarding coverage, duration, and claims procedures, please refer to the warranty documentation included with your purchase or contact RecPro customer support directly.

## CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please contact RecPro customer service:

- **Manufacturer:** RecPro
- **Online Store:** Visit the official [RecPro Store on Amazon](#) for product information and support.
- **General Inquiries:** Refer to the contact information provided in your product packaging or on the official RecPro website.

© 2025 RecPro. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

#### Answered questions about this manual

**Does RecPro provide a drawing showing the frame footprint for the Charles 70-inch Power Recliner RV Sofa to ensure it fits a 34.375-inch slide depth?**

Based on the specifications for the RecPro Charles series, the standard depth of the unit is 37.5 inches. The manual indicates that the sofa requires a 3-inch clearance from the wall to operate as...

[Read full answer](#)

---

Open the live page

<https://manuals.plus/asin/B086LJF5YX>

More documents and user manuals: <https://manuals.plus/>