

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DEWINNER](#) /

› [DEWINNER Kitchen Faucet with Spring Mixer, 360° Swivel, Hot & Cold, Chrome Brass \(Model 733424977596\) Instruction Manual](#)

## DEWINNER 733424977596

# DEWINNER Kitchen Faucet Instruction Manual

Model: 733424977596

Brand: DEWINNER

## INTRODUCTION

Thank you for choosing the DEWINNER Kitchen Faucet. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new faucet. Please read these instructions carefully before beginning installation and retain them for future reference.

This faucet features a durable chrome brass construction, designed for longevity and ease of use. It includes two independent water outlets, a 360° swivel spring mixer, and is suitable for both hot and cold water supply. The materials used are lead-free and nickel-free, adhering to health and safety standards.

## SETUP AND INSTALLATION

The DEWINNER Kitchen Faucet is designed for straightforward installation, even for users without professional plumbing experience. No specialized plumber is required for basic setup.

### Required Tools (Not Included):

- Adjustable wrench
- Screwdriver
- Sealant tape (Teflon tape)
- Bucket or towel for spills

### Installation Steps:

1. **Preparation:** Turn off the main water supply to your kitchen sink. Clear the area under the sink.
2. **Remove Old Faucet:** Disconnect the hot and cold water lines from your old faucet and remove the mounting hardware. Lift the old faucet from the sink.
3. **Mounting Hole:** Ensure your sink has a suitable mounting hole with a diameter between 32-35mm.
4. **Install New Faucet:** Insert the new faucet into the mounting hole. Secure it from underneath the sink using the provided mounting hardware (washers, nuts).

5. **Connect Water Lines:** Attach the hot and cold water supply lines to the corresponding inlets on the faucet. Use sealant tape on threaded connections to prevent leaks. The PEX inner tube ensures hygienic water delivery.
6. **Test:** Slowly turn on the main water supply and check for any leaks. Run both hot and cold water through the faucet to flush out any debris.



**Figure 1:** All components of the DEWINNER Kitchen Faucet laid out, including the main faucet body, pull-down sprayer, hot and cold water lines, and mounting hardware. This image assists in identifying parts during installation.



**Figure 2:** A detailed diagram showing the dimensions of the DEWINNER Kitchen Faucet, including height, spout reach, and handle clearance. This helps in planning the installation space.

## OPERATING INSTRUCTIONS

---

Your DEWINNER Kitchen Faucet offers versatile functionality for various kitchen tasks.

### Water Flow Control:

- The single lever handle controls both water temperature and flow volume.
- Move the handle up to increase flow and down to decrease/turn off.
- Move the handle left for hot water and right for cold water.

### Dual Water Outlets and Spray Modes:

The faucet features two independent water outlets: a main spout and a pull-down spray head. Both can be used simultaneously for enhanced cleaning efficiency.

- **Main Spout:** Provides a steady stream of water for general use.
- **Pull-Down Spray Head:** The unique spring design allows for 360-degree rotation and easy maneuverability. Pull down the spray head for precise rinsing of vegetables or cleaning dishes.
- **Spray Modes:** The spray head offers two distinct modes: an aerated stream for filling and a powerful spray for rinsing. Switch between modes using the button on the spray head.



**Figure 3:** The DEWINNER Kitchen Faucet in operation, demonstrating the use of the pull-down spray head for targeted water delivery. The main spout is also active, showing dual water output.



## Sortie d'eau TWO Spray Stream

Le spray et le jet peut utiliser en même temps



Mode pulvérisation



Mode flux



**Figure 4:** A close-up view illustrating the two distinct spray modes available from the DEWINNER Kitchen Faucet's pull-down sprayer: a focused spray and a wider aerated stream.

## MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your DEWINNER Kitchen Faucet.

### Cleaning:

- Clean the faucet regularly with a soft cloth and mild soap.
- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the polished chrome finish.
- The special plating process helps prevent discoloration and corrosion, but gentle cleaning is still recommended.

### Internal Components:

- The faucet is equipped with a high-quality, anti-splash, silent ceramic cartridge for reliable operation and drip-free performance.
- The ABS aerator helps save up to 30% water. Periodically unscrew and clean the aerator to remove

mineral buildup and maintain optimal flow.

- The superior PEX inner tube is designed for environmental friendliness and hygiene, requiring no special maintenance.



**Figure 5:** Close-up views of various parts of the DEWINNER Kitchen Faucet, including the spray head nozzle, the spring hose, and the base connections, highlighting the quality of construction.

## TROUBLESHOOTING

If you encounter any issues with your DEWINNER Kitchen Faucet, please refer to the common problems and solutions below. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
<b>Low Water Flow</b>	Clogged aerator; partially closed shut-off valve; kinked supply line.	Clean the aerator; ensure shut-off valves are fully open; check supply lines for kinks.

Problem	Possible Cause	Solution
<b>Leaks from Faucet Base</b>	Loose mounting nut; worn O-rings; improper installation.	Tighten mounting nut; inspect and replace O-rings if necessary; re-install following instructions.
<b>Dripping from Spout</b>	Worn ceramic cartridge.	Replace the ceramic cartridge.
<b>No Hot or Cold Water</b>	Supply line shut-off valve closed; water heater issue (for hot water).	Ensure supply line shut-off valves are open; check water heater functionality.
<b>Hose/Pipe Damage</b>	Wear and tear; improper installation causing stress.	Immediately turn off water supply. Inspect all connections and hoses for damage. Replace any damaged parts with genuine DEWINNER components. Ensure hoses are not kinked or under excessive tension during installation.

## SPECIFICATIONS

---

<b>Brand</b>	DEWINNER
<b>Model Number</b>	733424977596
<b>Color</b>	Silver
<b>Style</b>	Modern
<b>Finish</b>	Polished
<b>Material</b>	Copper, Chrome (Faucet Body); Brass Chrome (Handle)
<b>Installation Method</b>	Deck Mounted
<b>Number of Holes</b>	3
<b>Handle Location</b>	Center
<b>Number of Handles</b>	1
<b>Special Features</b>	Lead-free
<b>Components Included</b>	Instruction Manual
<b>Package Dimensions</b>	53.2 x 27.1 x 7.5 cm
<b>Item Weight</b>	2.21 Kilograms

## WARRANTY INFORMATION

---

Specific warranty details for the DEWINNER Kitchen Faucet are not provided in the product information. Please refer to your purchase documentation or contact the seller directly for warranty terms and conditions.

## CUSTOMER SUPPORT

---

DEWINNER is committed to providing responsive customer service. If you encounter any problems during the installation or use of your kitchen faucet, please do not hesitate to contact us.

For assistance, please reach out to the seller or DEWINNER customer support through the platform where you purchased the product. We are always here to help you.