

[Manuals.plus](#) /

› [iProtec](#) /

› iProtec Outdoorsmen 1400 Series Flashlight User Manual

iProtec iProtec Outdoorsmen 1400 Series Flashlight

iProtec Outdoorsmen 1400 Series Flashlight User Manual

MODEL: 6541

Brand: iProtec

Introduction

The iProtec Outdoorsmen 1400 Series Flashlight is a high-intensity lighting tool designed for various applications, from vehicle use to emergency kits. It delivers a powerful 1,400 lumens of light, capable of illuminating objects over 260 meters away. Built with durability in mind, this flashlight features IP67-rated waterproof construction and is impact-resistant, ensuring reliable performance in diverse weather conditions. It offers versatile lighting options with five distinct modes and a convenient zoom function.

Product Overview



Figure 1: Main view of the iProtec Outdoorsmen 1400 Series Flashlight, showcasing its robust design.



Figure 2: Close-up view of the flashlight head, highlighting the lens and textured grip.



Figure 3: View of the flashlight's tail cap, where the power button and lanyard attachment point are located.

Setup

The iProtec Outdoorsmen 1400 Series Flashlight operates on 6 AA batteries, which are included with the product. To install or replace batteries:

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert the 6 AA batteries into the battery stack, ensuring correct polarity (+/-) as indicated inside the battery compartment. The flashlight uses a three-battery stack design.
3. Carefully screw the tail cap back on clockwise until it is securely tightened. Ensure the rubber water seal is properly seated to maintain the flashlight's waterproof integrity.

Operating Instructions

The flashlight features a soft-touch button located on the tail cap for easy operation and mode selection.

- **Power On/Off:** Press the soft-touch button once to turn the flashlight on. Press it again to turn it off.
- **Changing Light Modes:** While the flashlight is on, lightly press the soft-touch button (without fully clicking) to cycle through the 5 light modes:
 - High (1400 Lumens)
 - Medium
 - Low
 - Defensive Strobe
 - Flashing Beacon

Fully click the button to select and lock in the desired mode.

- **Zoom Function:** The flashlight features a 1x to 16x zoom function. To adjust the beam focus, gently slide the head of the flashlight forward or backward. Sliding it forward will narrow the beam for a spotlight effect, while sliding it backward will widen the beam for flood illumination.

Maintenance

To ensure the longevity and optimal performance of your iProtec Outdoorsmen 1400 Series Flashlight, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior of the flashlight with a soft, damp cloth. Do not use abrasive cleaners or solvents. Keep the lens clean for maximum light output.
- **Water Resistance:** The flashlight is IP67-rated waterproof, meaning it can withstand immersion in 1 meter of water for up to 30 minutes. Always ensure the tail cap is securely tightened and the rubber seals are free of debris before exposing the flashlight to water. Periodically inspect the rubber seals for wear and tear.
- **Impact Resistance:** The anodized aircraft-grade aluminum body provides impact resistance from drops up to 1.5 meters. While durable, avoid unnecessary drops to prevent potential damage to internal components.
- **Battery Care:** Remove batteries if the flashlight will not be used for an extended period to prevent leakage and damage.

Troubleshooting

If you encounter issues with your iProtec Outdoorsmen 1400 Series Flashlight, please refer to the following common troubleshooting steps:

- **Flashlight Not Turning On:**
 - Check if the batteries are inserted correctly with the proper polarity.
 - Ensure the batteries are not depleted. Replace with fresh AA batteries if necessary.
 - Verify that the tail cap is fully tightened. A loose tail cap can prevent electrical contact.
- **Dim Light Output:**
 - Batteries may be low. Replace them.
 - Clean the flashlight lens with a soft cloth.
- **Modes Not Cycling Properly:**

- Ensure you are lightly pressing the button to cycle modes, not fully clicking it off and on.
- Check battery levels.

If problems persist after attempting these steps, please contact iProtec customer support.

Specifications

Feature	Detail
Brand	iProtec
Model Name	iProtec Outdoorsmen 1400 Series Flashlight
Model Number	6541
Light Source Type	LED (Cree)
Brightness	1400 Lumens
Beam Distance	Up to 260 Meters
Light Modes	High, Medium, Low, Defensive Strobe, Flashing Beacon
Zoom	1x to 16x
Power Source	6 AA Batteries (Included)
Material	Anodized Aircraft-Grade Aluminum
Water Resistance	IP67 (Waterproof up to 1 meter for 30 minutes)
Impact Resistance	Up to 1.5 meters
Dimensions (Compacted)	7.2 L x 1.375 W (Barrel) & 1.875 L (Head) inches
Dimensions (Extended)	7.75 L inches
Weight	0.95 lbs
Included Components	Flashlight, Lanyard, (6) AA Batteries

Warranty

The iProtec Outdoorsmen 1400 Series Flashlight comes with a 1-year manufacturer's warranty.

Support

For further assistance, technical support, or warranty claims, please visit the official iProtec website or contact their customer service department.

Website: www.iprotec.com