Zilan Aqualotus

Zilan Aqualotus All-Purpose Vacuum Cleaner

User Manual

1. Introduction

Thank you for choosing the Zilan Aqualotus All-Purpose Vacuum Cleaner. This powerful and versatile appliance is designed for both indoor and outdoor cleaning, capable of handling dust, sawdust, debris, dirt, sand, and even liquids. Its advanced water filtration system ensures a cleaner exhaust, trapping allergens and fine particles.
Please read this manual carefully before operating the appliance to ensure safe and efficient use. Keep this manual for future reference.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Ensure the power supply voltage matches the rating label on the vacuum cleaner.
- Do not use the vacuum cleaner on wet surfaces unless specifically designed for wet vacuuming and configured correctly.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Unplug from outlet when not in use and before servicing.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.

- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not handle plug or vacuum cleaner with wet hands.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Product Components



Figure 1: Zilan Aqualotus All-Purpose Vacuum Cleaner with its main components. The image shows the main unit, the transparent water tank, the hose, and various filter parts.



Figure 2: Exploded view illustrating key features and components. This includes the motor unit, filter assembly, water tank, and hose connection. Key specifications like 2000W max power, 8-liter capacity, 2300 mm H2O (196 mbar) suction power, and suitability for indoor/outdoor use are highlighted. The vacuum can be used with or without a dust bag, and features an easy-to-clean water filter.

- **Main Unit:** Contains the motor and control switches.
- **Water Tank:** Transparent reservoir for collecting dust and liquids.
- **Hose:** Flexible hose for connecting attachments.
- **Extension Wands:** For extended reach.
- **Floor Nozzle:** For general floor cleaning (wet/dry).
- **Crevice Tool:** For narrow spaces and corners.
- **Upholstery Tool:** For furniture and delicate surfaces.
- **Water Filter Assembly:** Includes the water filter and HEPA filter for advanced filtration.
- **Wheels:** Three 360-degree rotating wheels for easy maneuverability.



Figure 3: Close-up view of the interchangeable nozzles and accessories provided with the Zilan Aqualotus, including a floor nozzle and two types of crevice tools, along with the transparent dust collection tank.

4. Setup

1. **Unpacking:** Carefully remove all components from the packaging. Check for any damage.
2. **Assemble Wheels:** Attach the three 360-degree rotating wheels to the base of the water tank if they are not pre-assembled.
3. **Prepare Water Tank:** For dry vacuuming with water filtration, fill the water tank with clean water up to the indicated MAX level. Ensure the water filter assembly is correctly seated in the tank. For dry vacuuming without water filtration (using a dust bag, if applicable), ensure the water tank is empty and the appropriate dry filter/bag is installed.
4. **Attach Main Unit:** Place the main motor unit securely onto the water tank, ensuring it clicks into place.
5. **Connect Hose:** Insert the flexible hose into the suction inlet on the main unit until it is firmly connected.
6. **Attach Accessories:** Connect the desired extension wands and nozzle (e.g., floor nozzle, crevice tool) to the end of the hose.

5. Operating Instructions

5.1 Dry Vacuuming (with Water Filter)

1. Ensure the water tank is filled with clean water to the MAX line.
2. Connect the desired dry cleaning attachment (e.g., floor nozzle for hard floors/carpets, crevice tool for tight spaces).
3. Plug the power cord into a suitable electrical outlet.
4. Turn on the vacuum cleaner using the power switch on the main unit.
5. Begin vacuuming. The dust and debris will be drawn into the water, trapping particles and allergens.
6. After use, turn off the vacuum, unplug it, and empty the dirty water tank. Clean the tank and filter components as described in the Maintenance section.

5.2 Wet Vacuuming

The Zilan Aqualotus is designed to pick up liquids. Ensure the water tank is empty before starting wet vacuuming to maximize capacity.

1. Ensure the water tank is empty and clean. Remove any dry filters or dust bags if present.
2. Attach the appropriate wet cleaning nozzle (e.g., the wet floor nozzle).
3. Plug the power cord into a suitable electrical outlet.
4. Turn on the vacuum cleaner.
5. Carefully vacuum up the liquid. Do not overfill the tank; stop if the suction power decreases significantly or if the motor sound changes.
6. After use, turn off the vacuum, unplug it, and immediately empty the dirty liquid. Clean the tank and components thoroughly to prevent odors and mold.

5.3 Blower Function

The vacuum cleaner also features a blower function, useful for clearing debris from hard-to-reach areas or inflating items.

1. Locate the blower outlet on the main unit (usually opposite the suction inlet).
2. Detach the hose from the suction inlet and firmly connect it to the blower outlet.
3. Plug the power cord into a suitable electrical outlet.
4. Turn on the vacuum cleaner. Air will now be expelled through the hose.
5. Direct the airflow as needed.
6. After use, turn off the vacuum and unplug it.



Figure 4: The Zilan Aqualotus vacuum cleaner positioned next to a bed, demonstrating its compact size and ease of use in a typical home environment. The hose and floor nozzle are attached, ready for cleaning.

6. Maintenance

6.1 Emptying and Cleaning the Water Tank

For optimal performance and hygiene, empty and clean the water tank after each use, especially after wet vacuuming.

1. Ensure the vacuum cleaner is turned off and unplugged.
2. Detach the main motor unit from the water tank.
3. Carefully pour out the dirty water/liquid into a drain.
4. Rinse the water tank thoroughly with clean water. You may use a mild detergent if necessary, but rinse well to remove all soap residue.
5. Allow the tank to air dry completely before reassembling or storing.

6.2 Cleaning/Replacing Filters

The Zilan Aqualotus uses a water filter system and a downstream HEPA filter. Regular cleaning of these filters is crucial for maintaining suction power and air quality.

- **Water Filter:** After emptying the water tank, remove the water filter assembly. Rinse it under running water until clean. Ensure all debris is removed. Allow it to dry completely before reinstallation.
- **HEPA Filter:** The HEPA filter should be checked regularly. Tap it gently to dislodge dust. If it appears heavily soiled or suction power is consistently low despite a clean water tank, it may need to be replaced. Refer to the manufacturer's recommendations for replacement frequency. Do not wash the HEPA filter unless explicitly stated by the manufacturer.

6.3 General Cleaning

- Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use harsh abrasives or

solvents.

- Check the hose and attachments for blockages. Clear any obstructions carefully.
- Store the vacuum cleaner in a dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply; Power switch off; Damaged cord/plug.	Check power outlet; Ensure switch is ON; Inspect cord/plug for damage (do not use if damaged, contact service).
Low suction power.	Water tank overfilled/dirty; Filters clogged; Hose/attachments blocked; Tank not properly sealed.	Empty/clean water tank; Clean/replace filters; Clear blockages; Ensure main unit is securely attached to tank.
Water leaking from tank.	Tank not properly sealed; Tank damaged; Water level too high.	Ensure main unit is securely attached; Inspect tank for cracks; Do not exceed MAX fill line.
Unpleasant odor.	Dirty water left in tank; Uncleaned filters.	Empty and thoroughly clean water tank after each use; Clean all filter components.

8. Specifications

- **Brand:** Zilan
- **Model:** Aqualotus
- **Power/Wattage:** 2000 Watt (Max)
- **Voltage:** 230 Volt
- **Capacity:** 8 Liters
- **Suction Power:** 2300 mm H2O (196 mbar)
- **Filter Type:** Water filter, HEPA filter
- **Special Features:** Wet & Dry Vacuuming, Blower Function, Use with or without bag (water filtration), Ergonomic design, 360-degree rotating wheels.
- **Color:** Poseidon Blue (Mainly Black/Blue)
- **ASIN:** B086N4N374

9. Warranty and Support

The Zilan Aqualotus All-Purpose Vacuum Cleaner comes with a**2-year warranty** from the date of purchase. This warranty covers manufacturing defects and material faults under normal use conditions. The warranty does not cover:

- Damage caused by improper use, negligence, or failure to follow instructions in this manual.
- Normal wear and tear, including filters and accessories.
- Damage caused by unauthorized repairs or modifications.
- Commercial use of the product.

For warranty claims or technical support, please contact your retailer or the Zilan customer service department with your proof of purchase.

© 2024 Zilan. All rights reserved.
Model: Aqualotus | ASIN: B086N4N374