Nokia 106 DUAL SIM

Nokia 106 Dual-SIM Cellphone User Manual

Model: 106 DUAL SIM

Introduction

This manual provides essential information for setting up, operating, and maintaining your Nokia 106 Dual-SIM cellphone. Designed for simplicity and reliability, this device offers core mobile communication functionalities.



Image: Front and back view of the Nokia 106 Dual-SIM cellphone, showcasing its compact design and physical keypad.

1. Setup

1.1 Unboxing

Ensure all components are present in the package:

- Nokia 106 Dual-SIM Cellphone

- Battery (800mAh removable)
- Charging Cable (microUSB)



Image: The retail box of the Nokia 106 Dual-SIM, showing key features and contents.

1.2 Battery and SIM Card Installation

1. **Remove Back Cover:** Gently pry open the back cover of the phone.
2. **Insert SIM Cards:** Locate the SIM card slots. This phone supports two SIM cards. Insert your GSM SIM cards into the designated slots with the gold contacts facing down.
3. **Insert Battery:** Place the 800mAh removable battery into its compartment, ensuring the contacts align correctly.
4. **Replace Back Cover:** Press the back cover firmly until it clicks into place.

1.3 Charging the Battery

Connect the supplied microUSB charging cable to the phone's charging port and plug the other end into a compatible power source. The battery indicator on the screen will show charging progress. A full charge provides approximately 7 hours of talk time.

2. Operating Your Phone

2.1 Power On/Off

- **To Power On:** Press and hold the Power/End Call button (red button) until the phone vibrates and the screen lights up.
- **To Power Off:** Press and hold the Power/End Call button until the power off options appear, then select 'Power off'.



Image: Front view of the Nokia 106 Dual-SIM, displaying the screen and keypad for operation.

2.2 Making and Receiving Calls

- **Making a Call:** Enter the phone number using the keypad and press the Call button (green button).
- **Receiving a Call:** When the phone rings, press the Call button to answer. To end a call, press the End Call button.

2.3 Sending and Receiving SMS

Navigate to the 'Messages' menu. Select 'Create message' to compose a new SMS. Enter the recipient's number or select from contacts, then type your message. To read received messages, go to the 'Inbox'.

2.4 Additional Features

- **Contacts:** Store up to 2000 contacts in your phonebook.
- **FM Radio:** Enjoy FM radio by connecting a headset (sold separately) to the microUSB port, which acts as an antenna.
- **Torch:** Activate the built-in LED torch for illumination.
- **Games:** The phone includes classic games like Snake Xenzia.

3. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid liquid cleaners or abrasive materials.
- **Battery Care:** To prolong battery life, avoid exposing the phone to extreme temperatures. Do not leave the battery fully discharged for extended periods.
- **Storage:** If storing the phone for a long time, charge the battery to about 50% and store it in a cool, dry place.

4. Troubleshooting

Problem	Possible Solution
Phone does not turn on.	Ensure the battery is correctly inserted and charged. Connect the charger and try again.
Cannot make or receive calls.	Check if SIM cards are properly inserted. Verify network signal strength. Contact your network provider for service issues.
SIM card not recognized.	Re-insert the SIM card(s). Ensure the SIM card is not damaged.
Battery drains quickly.	Reduce screen brightness. Close unused applications. Limit background activities.

5. Specifications

Feature	Detail
Model	Nokia 106 Dual-SIM (106 DUAL SIM)
Dimensions	111.2 x 49.5 x 14.4 mm (4.38 x 1.95 x 0.57 in)
Weight	70.2 g (2.47 oz)
Display	1.8 inches, TFT, 65K colors, 120 x 160 pixels
RAM	4MB

Feature	Detail
Internal Storage	4MB (non-expandable)
Operating System	Proprietary OS (Series 30+)
Processor	Mediatek MT6261D
Battery	800mAh removable battery
Talk Time	Up to 7 hours
Connectivity	2G GSM (850 / 900 / 1800 / 1900 MHz)
SIM Card Slots	Dual SIM
Charging Port	microUSB 2.0 (charging only)
Human Interface Input	Buttons
Color	Gray



Image: Top view of the Nokia 106 Dual-SIM, showing its compact form factor.

6. Warranty and Support

6.1 Warranty Information

Your Nokia 106 Dual-SIM cellphone is covered by a limited manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

6.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Nokia customer support. Visit the official Nokia website for the most up-to-date contact information, including phone numbers and online support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question