



Manuals.plus /

- › GE /
- › GE GYE22GYNFS 36-inch French Door Counter Depth Refrigerator User Manual

## GE GYE22GYNFS

# GE GYE22GYNFS 36-inch French Door Counter Depth Refrigerator User Manual

Model: GYE22GYNFS | Brand: GE

## 1. INTRODUCTION

Thank you for choosing the GE GYE22GYNFS 36-inch French Door Counter Depth Refrigerator. This appliance is designed to integrate seamlessly into your kitchen with its counter-depth design, offering a sleek, built-in appearance. It features a total capacity of 22.1 cubic feet, including a space-saving ice maker and bright Showcase LED lighting. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new refrigerator.



Figure 1: Front view of the GE GYE22GYNFS Refrigerator.

## 2. SETUP AND INSTALLATION


---

### 2.1 Unpacking and Placement

Carefully remove all packaging materials. Ensure the refrigerator is placed on a level surface. This counter-depth model is designed to align with your kitchen countertops for a flush, integrated look.

### 2.2 Dimensions

Refer to the diagram below for detailed dimensions to ensure proper fit and clearance during installation.



Above Illustration intended for dimensional reference only. Refer to photograph for actual product appearance.

Figure 2: Refrigerator dimensions for installation planning.

## 2.3 Electrical and Water Connections

Connect the refrigerator to a dedicated 120-volt, 60 Hz, 15-amp fused electrical circuit. For the ice maker and water dispenser to function, connect the refrigerator to a cold water supply line according to local plumbing codes.

## 3. OPERATING INSTRUCTIONS

### 3.1 Temperature Control

The refrigerator features TwinChill evaporators, which maintain separate climates in the fresh food and freezer sections to help keep foods fresh. Temperature settings can be adjusted via the internal control panel.

### 3.2 Water and Ice Dispenser

The external dispenser provides filtered water, crushed ice, and cubed ice. Use the control panel above the dispenser to select your desired option. A 'Lock' feature is available to prevent unintended dispensing. The 'Light' button illuminates the dispenser area. A 'Door Alarm' function alerts you if a door is left open.




Figure 3: Water and ice dispenser control panel.

### **3.3 Internal Storage**

The fresh food section features adjustable glass shelves and multiple door bins for flexible storage. Two humidity-controlled drawers and a full-width ClimateZone drawer are located at the bottom for optimal storage of fruits, vegetables, meats, and cheeses.

# ICE IN THE DOOR, SPACE IN THE FRIDGE.



Figure 4: Interior of the fresh food compartment.

## 3.4 Freezer Compartment

The bottom freezer drawer provides ample space for frozen items. It includes an upper slide-out basket and a lower deep storage bin for organized freezing.



Figure 5: Freezer drawer with upper and lower storage.

## 4. MAINTENANCE

---

### 4.1 Cleaning

Clean the interior and exterior surfaces regularly with a mild soap and water solution. The stainless steel finish is designed to resist fingerprints and smudges, making it easier to maintain a clean appearance.



Figure 6: Fingerprint-resistant stainless steel finish.

#### 4.2 Water Filter Replacement

Replace the water filter every six months or when the filter indicator light illuminates to ensure optimal water quality. Refer to the filter compartment for specific instructions on removal and installation.

#### 4.3 Door Gasket Maintenance

Regularly inspect the door gaskets for any signs of wear or damage. Clean them with a damp cloth to ensure a tight seal, which is crucial for energy efficiency and proper cooling.

### 5. TROUBLESHOOTING

If you experience issues with your refrigerator, consult the following common troubleshooting tips before contacting service.

- **No Power:** Check if the refrigerator is plugged in and if the circuit breaker has tripped.
- **Ice Maker Not Producing Ice:** Ensure the ice maker is turned on and the water supply line is connected and not frozen.
- **Water Dispenser Not Working:** Verify the water supply is connected and the water filter is correctly

installed. Check for any lock features activated on the dispenser panel.

- **Refrigerator Not Cooling:** Confirm the temperature settings are correct. Ensure doors are fully closed and gaskets are sealing properly. Avoid overfilling the refrigerator, which can restrict airflow.
- **Unusual Noises:** Some operational noises are normal. If you hear rattling or excessive vibration, check for loose items inside or behind the unit.
- **Door Alarm Constantly On:** Ensure all doors are completely closed. Check for obstructions preventing the door from sealing.

For persistent issues, refer to the detailed troubleshooting guide in your full product manual or contact customer support.

## 6. SPECIFICATIONS

Feature	Specification
Brand Name	GE
Model Info	GYE22GYNFS
Item Weight	336 pounds
Product Dimensions	31.25 x 35.75 x 70.5 inches
Capacity	22.1 Cubic Feet
Annual Energy Consumption	665 Kilowatt Hours Per Year
Refrigerator Fresh Food Capacity	14.92 Cubic Feet
Freezer Capacity	7.16 Cubic Feet
Installation Type	Built-In
Form Factor	French Door
Special Features	Anti bacterial Filter
Color	Stainless Steel
Voltage	120 Volts
Crispers/Drawers	3
Defrost	Hot gas defrost
Door Material Type	Stainless Steel
Shelf Type	refrigerator shelves
Shelves	5
Certification	ADA Compliant, ENERGY STAR Qualified, California Prop 65
Number Of Doors	3

## 7. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase. If you require assistance or service, please contact GE Appliances Customer Support. You can find contact details on the GE Appliances website or in your product registration materials.

GE Appliances is committed to providing quality appliances and support. For further assistance, please visit the official GE Appliances website or contact their customer service line.