

[Manuals.plus](#) /

› [eufy](#) /

› eufy HomeVac H11 Handheld Vacuum Instruction Manual

eufy T2521

eufy HomeVac H11 Instruction Manual

Model: T2521

1. INTRODUCTION

The eufy HomeVac H11 is a lightweight and compact handheld vacuum designed for quick cleanups. Its cordless design and powerful suction make it suitable for various small tasks, including cleaning vehicle interiors and household spills.



Image: The eufy HomeVac H11 handheld vacuum cleaner, showcasing its sleek, compact design.

2. WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- eufy HomeVac H11 unit
- 2-in-1 Crevice Tool
- USB to Micro-USB cable
- User Manual (this document)



Image: The eufy HomeVac H11 with its 2-in-1 crevice tool and USB charging cable.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the HomeVac H11. Connect the provided USB to Micro-USB cable to the charging port on the vacuum and to a compatible USB power adapter (not included). The charging indicator lights will illuminate during charging and turn off when fully charged. Charging typically takes approximately 90 minutes.



Image: Close-up of the eufy HomeVac H11 showing the Micro-USB charging port with a cable connected.

3.2 Attaching Accessories

The 2-in-1 crevice tool can be attached to the nozzle for extended reach and specialized cleaning. Simply push the tool firmly onto the vacuum's suction opening until it clicks into place.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

Press the power button located on the handle to turn the vacuum on. Press it again to turn the vacuum off.

4.2 Cleaning Surfaces

Direct the nozzle towards the debris you wish to clean. For general surfaces, use the standard nozzle. For tight spaces, corners, or between car seats, attach the 2-in-1 crevice tool.



Image: The eufy HomeVac H11 being used to clean crumbs from a car seat and a table surface.

4.3 Suction Power

The HomeVac H11 provides 5,500Pa of suction power, effective for picking up dust, crumbs, and small debris. For optimal performance, ensure the dust collector is not full and the filter is clean.

One-Pass Suction Power



Image: An illustration showing the internal suction mechanism of the eufy HomeVac H11, highlighting its 5,500Pa suction capability.

4.4 Battery Life

A full charge provides approximately 13 minutes of runtime. The LED indicators on the vacuum show the remaining battery level.

Your browser does not support the video tag.

Video: Official eufy demonstration of the HomeVac H11's features and usage.

5. MAINTENANCE

5.1 Emptying the Dust Collector

To maintain optimal suction, empty the dust collector regularly. Twist the dust collector counter-clockwise to detach it from the main unit. Dispose of the collected debris and reattach the dust collector by twisting it clockwise until secure.

5.2 Cleaning the Filter

The filter should be cleaned periodically, especially after vacuuming fine dust or pet hair. Remove the filter from the dust collector and tap it gently to remove loose dirt. For a more thorough cleaning, rinse the filter under running water. Ensure the filter is completely dry before reinserting it into the dust collector and reattaching it to the vacuum.



Image: Close-up of the eufy HomeVac H11's internal filter, showing its design for trapping dust.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power / Does not turn on	Battery is depleted.	Charge the vacuum fully using the provided USB cable.
Weak suction power	Dust collector is full or filter is clogged.	Empty the dust collector and clean the filter. Ensure the filter is completely dry before reassembly.
Short battery life	Battery not fully charged or aging battery.	Ensure the vacuum is fully charged before use. If the issue persists after full charge, contact customer support.
Vacuum stops unexpectedly	Battery is depleted.	Recharge the vacuum.

7. SPECIFICATIONS

Feature	Detail
Brand	eufy
Model Name	eufy HomeVac H11
Model Number	T2521
Special Feature	Compact, Lightweight
Filter Type	Cartridge

Feature	Detail
Power Source	Battery Powered, Cordless
Capacity	16 ounces
Recommended Use	Car, Small household messes
Color	Black
Noise Level	80 dB
Voltage	12 volts
Wattage	40 watts
Item Weight	1.3 pounds
Dimensions (L x W x H)	13.19" x 2.91" x 2.91"
Battery Type	Lithium-Ion
Battery Charge Time	Approximately 90 minutes
Runtime	13 minutes
Connectivity	USB

8. WARRANTY AND SUPPORT

The eufy HomeVac H11 comes with a 2-year manufacturer warranty. For warranty claims, technical support, or further assistance, please refer to the official eufy support channels or the contact information provided in your purchase documentation.

An official User Manual (PDF) is also available for download:[Download PDF Manual](#)

