Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Unbranded EAT63377302

Wireless/WiFi Module EAT63377302 User Manual

Comprehensive guide for the installation, operation, and maintenance of the EAT63377302 Wireless/WiFi Module, compatible with LG 49UK6200PLA and similar devices.

1. Introduction

This manual provides essential information for the proper handling, installation, and use of the EAT63377302 Wireless/WiFi Module. This module is designed to provide wireless connectivity (Wi-Fi) to compatible electronic devices, such as certain LG television models, including the LG 49UK6200PLA. Please read this manual carefully before proceeding with any installation or maintenance.

2. Setup and Installation

The EAT63377302 is an internal component and requires professional installation or careful handling by individuals with experience in electronics repair. Improper installation can damage the module or the host device.

2.1 Safety Precautions

- Always disconnect the host device (e.g., television) from the power supply before beginning any installation or repair work.
- Discharge any static electricity from your body by touching a grounded metal object before handling the module. Consider using an anti-static wrist strap.
- Handle the module by its edges to avoid touching sensitive components.
- Keep small parts and tools away from children.

2.2 Module Identification

The module can be identified by its part number EAT63377302, often found on a label on the metallic shield. It also features two antenna connectors, typically labeled ANT 1 and ANT 2.



Figure 1: EAT63377302 Wireless/WiFi Module. Note the central metallic shield with the part number and the two antenna connection points (ANT 1 and ANT 2).

2.3 Installation Steps

1. Carefully open the casing of the host device (e.g., television) according to its service manual.
2. Locate the designated slot for the wireless module. This may be near the main board.
3. Gently insert the EAT63377302 module into its connector slot, ensuring it is seated firmly and correctly. Do not force it.
4. Connect the antenna cables to the corresponding ANT 1 and ANT 2 connectors on the module. Ensure a secure connection.
5. Secure the module with any screws or clips provided by the host device's design.
6. Carefully reassemble the host device's casing.

3. Operation

Once installed, the EAT63377302 module operates as an integrated component of the host device. Its functionality is managed through the host device's operating system and settings.

3.1 Connecting to a Wireless Network

1. Power on the host device (e.g., LG TV).
2. Navigate to the network settings menu within the device's interface.
3. Select the Wi-Fi or Wireless Network option.
4. The device should scan for available Wi-Fi networks. Select your desired network from the list.
5. Enter the network password (if required) and confirm the connection.
6. Once connected, the device will have internet access via Wi-Fi.

4. Maintenance

The EAT63377302 Wireless/WiFi Module is a sealed electronic component and does not require routine user maintenance. For optimal performance and longevity, ensure the host device is kept clean and free from dust and moisture. Avoid exposing the host device to extreme temperatures or direct physical impact.

5. Troubleshooting

If you experience issues with wireless connectivity after installing the EAT63377302 module, consider the following troubleshooting steps:

Problem	Possible Cause	Solution
No Wi-Fi networks detected.	Module not properly installed or faulty.	Ensure the module is securely seated in its slot and antenna cables are connected. If problem persists, the module may be faulty.
Intermittent Wi-Fi connection.	Weak signal, interference, or loose antenna connection.	Move the host device closer to the Wi-Fi router. Check for sources of interference. Verify antenna cable connections.
Cannot connect to a specific network.	Incorrect password, router issue, or network settings.	Double-check the Wi-Fi password. Restart your Wi-Fi router. Check the host device's network settings.
Device freezes or crashes when using Wi-Fi.	Software conflict or firmware issue.	Ensure the host device's firmware is up to date. Consult the host device's manufacturer for software support.

If these steps do not resolve the issue, it is recommended to consult a qualified technician or the manufacturer of the host device.

6. Specifications

Feature	Detail
Model Number	EAT63377302
Alternative Part Numbers	LGSBWAC72, TWCM-K3050
Version	V1.6
Chipset (Identified from OCR)	MT7662TU
Compatibility	LG 49UK6200PLA (and other compatible LG TV models)
Connectivity	Wireless (Wi-Fi)
Antenna Ports	2 (ANT 1, ANT 2)

7. Warranty Information

Specific warranty terms for the EAT63377302 Wireless/WiFi Module are typically provided by the original seller or the manufacturer of the host device (e.g., LG). Please refer to your purchase documentation or contact the point of sale for detailed warranty coverage and conditions. This module is an internal component, and its warranty may be tied to the warranty of the device it is installed in.

8. Support

For technical support regarding the EAT63377302 Wireless/WiFi Module, it is recommended to contact the seller from whom you purchased the module or the manufacturer of the host device (e.g., LG Customer Service) if the module was part of the original equipment. Provide them with the module's model number (EAT63377302) and the model of your host device (e.g., LG 49UK6200PLA) for efficient assistance.

© 2024 Unbranded Module Documentation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086Q2HG6H

More documents and user manuals: **https://manuals.plus/**